



CX100 ComXpert
Handheld Radio Test Set
Operation Manual



CX100 ComXpert
Handheld Radio Test Set
Operation Manual

22144015 Rev 002



VIAVI Solutions
1-844-GO-VIAVI
www.viavisolutions.com



Revision History

The following table contains a record of this manual's revision history.

Table -1 Revision History

Doc Version	Date	Accepted By
Rev 001	August 22, 2023	Lance Woods
Rev 002	August 21, 2023	Robert Facha

This page intentionally left blank.

Notice

Every effort was made to ensure that the information in this manual was accurate at the time of release. However, information is subject to change without notice, and VIAVI reserves the right to provide an addendum to this manual with information not available at the time that this manual was created.

Copyright/Trademarks

© Copyright 2023 VIAVI Solutions, Inc. All rights reserved. No part of this guide may be reproduced or transmitted, electronically or otherwise, without written permission of the publisher. VIAVI Solutions and the VIAVI logo are trademarks of VIAVI Solutions Inc. (“VIAVI”).

All other trademarks and registered trademarks are the property of their respective owners.

Patent Information

Patented as described at www.viavisolutions.com/patents

Copyright Release

Reproduction and distribution of this guide is authorized for US Government purposes only.

Terms and conditions

Specifications, terms, and conditions are subject to change without notice. The provision of hardware, services, and/or software are subject to VIAVI’s standard terms and conditions, available at www.viavisolutions.com/en/terms-and-conditions

Declaration of Conformity

VIAVI recommends keeping a copy of the Declaration of Conformity that shipped with the unit with the test set at all times.

Warranty Information

Warranty information for this product is available on the VIAVI website at <https://www.viavisolutions.com/en-us/warranty-information>

Low Voltage Directive Compliance

This product was tested and conforms to the Low Voltage Directive, 73/23/EEC as amended by 93/68/EEC.

Japan Radio Law

The GITEKI Mark can be found on the meter in the “System -> File Browser -> Documents” folder.

Federal Communications Commission (FCC) Notice

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment was tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case you will be required to correct the interference at your own expense.

The authority to operate this equipment is conditioned by the requirements that no modifications be made to the equipment unless the changes or modifications are expressly approved by VIAVI.



ALERT

- To comply with FCC RF Exposure compliance requirements, a separation distance of at least 20 cm must be maintained between the antenna of this device and all persons.
- This transmitter must not be co-located in conjunction with any other antenna or transmitter.

Industry Canada Requirements

This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions: 1) This device may not cause interference; and, 2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: 1) l'appareil ne doit pas produire de brouillage; et, 2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

EU WEEE and Battery Directives

This product, and the batteries used to power the product, should not be disposed of as unsorted municipal waste and should be collected separately and disposed of according to your national regulations.

VIAVI has established a take-back processes in compliance with the EU Waste Electrical and Electronic Equipment (WEEE) Directive, 2012/19/EU, and the EU Battery Directive, 2006/66/EC.

Instructions for returning waste equipment and batteries to VIAVI can be found in the WEEE section of [VIAVI's Standards and Policies web page](#)

If you have questions concerning disposal of your equipment or batteries, contact the VIAVI WEEE Program Management team at Global.weee@viavisolutions.com

EU REACH

Article 33 of EU REACH regulation (EC) No 1907/2006 requires article suppliers to provide information if a listed Substances of Very High Concern (SVHC) is present in an article above a certain threshold.

For information on the presence of REACH SVHCs in VIAVI products, see the Hazardous Substance Control section of [VIAVI's Standards and Policies web page](#)

EU CE Marking Directives (LV, EMC, RoHS, RE)

This product conforms with all applicable CE marking directives. Please see EU Declaration of Conformity for details.

EMC Directive Compliance

This product was tested and conforms to the EMC Directive, 2014/30/EU for electromagnetic compatibility.

UK Declaration of Conformity

This product conforms with all applicable UKCA marking directives. Please request UK Declaration of Conformity for further details.

China RoHS Materials Declaration

The China RoHS Materials Declaration is shipped with the product when required.

California Proposition 65

California Proposition 65, officially known as the Safe Drinking Water and Toxic Enforcement Act of 1986, was enacted in November 1986 with the aim of protecting individuals in the state of California and the state's drinking water and environment from excessive exposure to chemicals known to the state to cause cancer, birth defects or other reproductive harm.

For the VIAVI position statement on the use of Proposition 65 chemicals in VIAVI products, see the Hazardous Substance Control section of [VIAVI's Standards and Policies web page](#)

Korea Certification

<p>A급 기기 (업무용 방송통신기자재)</p> <p>Class A Equipment (Industrial Broadcasting & Communications Equipment).</p>	<p>이 기기는 업무용(A급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.</p> <p>This equipment is Industrial (Class A) electromagnetic wave suitability equipment and seller or user should take notice of it, and this equipment is to be used in the places except for home.</p>
---	---

Ordering Information

This manual is a product of the VIAVI Technical Publications Department, issued as part of the CX100 ComXpert Handheld Radio Test Set. The PDF format of this manual is available and distributed with new equipment on a CD-ROM.

- The part number associated with the PDF form of this publication is 22144015
- The material number associated with the CD-ROM is 22144014

Contact Information

Contact the Technical Assistance Center (TAC) for technical support or with any questions regarding this or other VIAVI products.

- Phone: 1-844-GO-VIAVI
- Email: Techsupport.Avcomm@viavisolutions.com

For the latest TAC information, go to:

<https://www.viavisolutions.com/support/technical-product-support>

Software Notifications

DFARS Statement

If software is for use in the performance of a U.S. Government prime contract or subcontract, software is delivered and licensed as “Commercial Computer Software” as defined in DFAR 252.227-7014 (Feb 2014), or as a “Commercial Item” as defined in FAR 2.101(a) or as “Restricted Computer Software” as defined in FAR 52.227-19 (Dec 2007) or any equivalent agency regulation or contract clause. Use, duplication or disclosure of Software is subject to VIAVI Solutions' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (Dec 2007). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

Open Source Disclaimer - IMPORTANT READ CAREFULLY









The CX100 ComXpert includes third party software licensed under the terms of separate open source software licenses. By using this software you agree to comply with the terms and conditions of the applicable open source software licenses. Software originated by VIAVI is not subject to third party licenses. Terms of the VIAVI Software License different from applicable third party licenses are offered by VIAVI alone.

Safety Information

Symbols and Markings

The following symbols and markings are found on the instrument and in product documentation:

Table 1 Symbols and Markings

	This symbol indicates a NOTE that includes important supplemental information or tips related to the main text.
	General Hazard Symbol This symbol represents a general hazard. This symbol may be associated with either a DANGER, WARNING, CAUTION, or ALERT message. See Table 2 for more information.
	Toxic Hazard Symbol This symbol indicates a toxic hazard. Item should only be handled by Qualified Service Personnel. Dispose of item in accordance with local regulations. This symbol may be associated with either a DANGER, WARNING, CAUTION, or ALERT message. See Table 2 for more information.
	ESD Symbol This symbol indicates an item is sensitive to Electrostatic Discharge (ESD). An item identified as ESD sensitive should only be handled by Qualified Service Personnel. This symbol may be associated with either a DANGER, WARNING, CAUTION, or ALERT message. See Table 2 for more information.
	Hot Surface Symbol This symbol represents a hot surface. This symbol may be associated with either a DANGER, WARNING, CAUTION, or ALERT message. See Table 2 for more information.
	Hazardous Voltage Symbol This symbol represents hazardous voltages. This symbol may be associated with either a DANGER, WARNING, CAUTION or ALERT message. See Table 2 for more information.
	CE Compliant This label indicates item meets the requirements of the applicable European Directives.
	WEEE Symbol This symbol indicates the equipment or battery must not be disposed of in a land-fill site or as municipal waste, and should be disposed of according to national regulations. Symbol may be on the equipment, battery, or packaging.

Safety Definitions

This operation manual uses the following terms to indicate conditions or activities which are potential safety hazards:

Table 2 Safety Definitions

Term	Definition
CAUTION	Identifies conditions or activities that, if ignored, can result in equipment or property damage, e.g., Fire
Mise en Garde	Identifiez les conditions ou les activités qui, si ignorées, peuvent entraîner des dommages à l'équipement ou aux biens, p. ex. un incendie
WARNING	Identifies conditions or activities that, if ignored, can result in personal injury or death
Avertissement	Identifiez les conditions ou les activités qui, si ignorées, peuvent entraîner des blessures personnelles voire mortelles

Equipment Usage

This product is designed and tested to comply with the requirements of IEC/EN61010-1 'Safety requirements for electrical equipment for measurement, control and laboratory use' for Class I portable equipment and is for use in a pollution degree 2 environment.

The equipment is designed to operate from MIL-PRF-2800 Class 2.

When moving the equipment from a cold to hot environment, allow the temperature of the equipment to stabilize before it is connected to the supply to avoid condensation forming. The equipment must only be operated within the environmental conditions specified in the performance data.

This product is not approved for use in hazardous atmospheres or medical applications. If the equipment is to be used in a safety-related application, such as avionics or military applications, the suitability of the product must be assessed and approved for use by a competent person.



WARNING

Operating this device in a manner not specified in accompanying documentation may impair the safety protection built into the device.

Avertissement

Utiliser cet appareil de manière non spécifiée dans la documentation d'accompagnement peut nuire au dispositif de protection de sécurité intégré dans l'appareil.

Burn Hazard



CAUTION

- The device casing may become hot to the touch during extended periods of continuous usage
- If bench top operation is not possible, use of temperature resistant gloves is recommended to avoid potential burns

Mise en Garde

- Le boîtier de l'appareil peut devenir chaud au toucher pendant de longues périodes d'utilisation continue
- Si l'opération sur paillasse n'est pas possible, l'utilisation de gants résistants à la température est recommandée pour éviter les brûlures potentielles

Electrical Hazards

AC Adapter/Charger

Approved Part Number: 22054882, Power Supply:AC2DC;90-264VAC; 47-63HZ,12VDC



CAUTION

- Use only the AC Adapter/Charger supplied with the product. Contact VIAVI for approved replacement parts
- Do not use the AC Adapter/Charger outdoors or in a wet or damp location
- Only connect the AC Adapter/Charger to the correct mains voltage indicated on the ratings label
- Do not use AC Adapter/Charger in temperatures above +40 C (104 F) or at altitude above 3000 meters (9842 ft)

Mise en Garde

- Utilisez uniquement l'adaptateur / chargeur CA fourni avec l'instrument
- N'utilisez pas l'adaptateur / chargeur CA à l'extérieur ou dans un endroit mouillé ou humide
- Connectez uniquement l'adaptateur / chargeur CA à la tension secteur correcte indiquée sur l'étiquette des caractéristiques nominales
- N'utilisez pas l'adaptateur secteur/chargeur à des températures supérieures à +40 C (104 F) ou à une altitude supérieure à 3000 mètres (9842 pieds)

Power Cord

Approved Part Number: 22054882, Adapter Cord US/NAmerica



CAUTION

- Do not use the power cord if it is damaged or frayed. Replace damaged power cords with cable of the same ratings
- Do not position the power cord in a manner that makes it difficult to disconnect from the main voltage
- Do not allow anything to rest on the power cord
- Do not locate the product where persons can walk on or trip over the power cord

Mise en Garde

- N'utilisez pas le cordon d'alimentation s'il est endommagé ou effiloché. Remplacez les cordons d'alimentation endommagés par des câbles de même puissance
- Ne placez pas le cordon d'alimentation de manière à rendre difficile la déconnexion de la tension secteur
- Ne laissez rien reposer sur le cordon d'alimentation
- Ne placez pas le produit à un endroit où des personnes pourraient marcher ou trébucher sur le cordon d'alimentation

Equipment Grounding Protection



CAUTION

- This device is intended to be used with a three wire grounding-type plug while charging
- Failure to use properly grounded power cord/plug may result in electrical shock to personnel or damage to the device
- Do not alter the power cord that is provided with the device

Mise en Garde

- Cet appareil est conçu pour être utilisé avec une fiche de mise à la terre à 3 fils (une fiche contenant une broche de mise à la terre)
- Le fait de ne pas utiliser le cordon d'alimentation / la prise correctement mis à la terre peut entraîner un choc électrique pour le personnel ou endommager l'appareil
- Ne modifiez pas le cordon d'alimentation fourni avec l'appareil

Input Overload

Refer to product labeling and safety documentation for maximum input ratings.



CAUTION

Do not overload input connectors. Refer to product Safety and Compliance Specifications or the product data sheet for maximum input ratings.

Mise en Garde

Identifiez les conditions ou les activités qui, si ignorées, peuvent entraîner des dommages à l'équipement ou aux biens, p. ex. un incendie.

Residual Current



WARNING

The supply filter contains capacitors that may remain charged after the device is disconnected from the power supply. The residual energy is within the approved safety requirements, however, a slight shock may be felt if the plug pins are touched immediately after removal.

Avertissement

Le filtre d'alimentation contient des condensateurs qui peuvent rester chargés une fois l'appareil débranché de l'alimentation électrique. L'énergie résiduelle est dans les limites des exigences de sécurité approuvées. Par contre, un léger choc électrique peut être ressenti si l'on touche les broches de la prise immédiatement après son débranchement.

Battery Safety Information

Battery Storage, Handling and Disposal



CAUTION

- To avoid risk of fire and burns, do not tamper with the battery
- Do not open, crush or incinerate the battery
- Do not use or store the battery in temperatures that exceed the manufacturer's specifications
- Follow manufacturer's instructions for battery storage and use
- The battery included with the product is only to be used with the CX100

Mise en Garde

- Pour éviter tout risque d'incendie et de brûlure, ne modifiez pas la batterie
- Ne pas ouvrir, écraser ou incinérer la batterie
- N'utilisez pas et ne stockez pas la batterie à des températures dépassant les spécifications du fabricant
- Suivez les instructions du fabricant pour le stockage et l'utilisation de la batterie
- La batterie fournie avec le produit ne doit être utilisée qu'avec l'appareil CX100

Battery Replacement

Approved Part Number: 22071316-002, Battery, Lithium Ion, 7.3V, 13Ah, OneExpert



CAUTION

Only replace the battery with the VIAVI approved replacement part. Contact VIAVI for approved replaced parts.

Mise en Garde

Remplacez la batterie uniquement par la pièce de rechange approuvée par VIAVI. Contactez VIAVI pour les pièces remplacées approuvées.

Toxic Hazards



WARNING

Some of the components used in this device may include resins and other materials which give off toxic fumes if incinerated. Dispose of such items appropriately.

Avertissement

Certains des composants utilisés dans cet appareil peuvent comprendre des résines et d'autres matériaux qui produisent des émanations toxiques lorsqu'ils sont incinérés. Éliminez adéquatement de tels éléments.

Beryllia



Beryllia (beryllium oxide) is used in the construction of some of the components in this equipment.

This material, when in the form of fine dust or vapor and inhaled into the lungs, can cause a respiratory disease. In its solid form, as used here, it can be handled safely, however, avoid handling conditions which promote dust formation by surface abrasion.

Use care when removing and disposing of these components. Do not put them in the general industrial or domestic waste or dispatch them by post. They should be separately and securely packed and clearly identified to show the nature of the hazard and then disposed of in a safe manner by an authorized toxic waste contractor.

Beryllium Copper



CAUTION

Some mechanical components within this instrument are manufactured from beryllium copper. Beryllium copper represents no risk in normal use. The material should not be machined, welded or subjected to any process where heat is involved.

Beryllium copper must NOT be disposed of by incineration. Beryllium copper must be disposed of as "special waste" per local regulations.

Mise en Garde

Certains composants mécaniques de cet instrument sont fabriqués à partir de cuivre au béryllium. Le cuivre au béryllium ne présente aucun risque en utilisation normale. Le matériau ne doit pas être usiné, soudé ou soumis à un processus impliquant de la chaleur.

Le cuivre au béryllium ne doit PAS être éliminé par incinération. Le cuivre au béryllium doit être éliminé en tant que «déchet spécial» conformément aux réglementations locales.

Lithium



CAUTION

A Lithium Ion battery is used in this equipment. Lithium is a toxic substance. The following warnings concerning Lithium Ion Batteries must be observed:

- Do not crush, incinerate or dispose of in normal waste
- Do not short circuit or force discharge since this might cause the battery to vent, overheat or explode

Mise en Garde

Une batterie au lithium-ion est utilisée dans cet équipement. Le lithium est une substance toxique.

Les avertissements suivants concernant les batteries au lithium-ion doivent être respectés:

- Ne pas écraser, incinérer ou jeter avec les déchets normaux
- Ne pas court-circuiter ni forcer la décharge car cela pourrait entraîner la ventilation, la surchauffe ou l'explosion de la batterie

Electrostatic Discharge (ESD)



CAUTION

This device is ESD sensitive and should only be serviced by Qualified Service Personnel.



Mise en Garde

Cet appareil est sensible aux décharges électrostatiques et ne doit être réparé que par du personnel de service qualifié.

Case/Cover Removal



CAUTION

Do not operate this device with the case/cover open. Removing rear cover exposes the operator to surfaces with excessive heat. Opening the case/cover exposes the operator to electrical hazards which can result in damage to the device.

Mise en Garde

N'utilisez pas cet appareil avec le boîtier/couvercle ouvert. Le retrait du capot arrière expose l'opérateur à des surfaces soumises à une chaleur excessive. L'ouverture du boîtier/couvercle expose l'opérateur à des risques électriques pouvant endommager l'appareil.



CAUTION

This device does not contain user serviceable parts. Servicing should only be performed by Qualified Service Personnel.

Mise en Garde

Cet appareil ne contient pas de pièces pouvant être entretenues par l'utilisateur. L'entretien doit seulement être effectué par du personnel de service qualifié.

Electromagnetic Interference (EMI)

This product complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this product may not cause harmful interferences, and (2) this product must accept any interferences received, including interference that may cause undesired operation.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Use properly shielded and grounded cables and connectors in order to meet FCC emission limits



CAUTION

Signal generators can be a source of Electromagnetic Interference (EMI) to communication receivers. Some transmitted signals can cause disruption and interference to communication services out to a distance of several miles. Users of this equipment should scrutinize any operation that results in radiation of a signal (directly or indirectly) and should take necessary precautions to avoid potential communication interference problems.

Mise en Garde

Les générateurs de signaux peuvent constituer une source d'interférences électromagnétiques (IME) pour les récepteurs radio. Certains signaux émis peuvent provoquer des interférences et des interruptions des communications sur une distance de plusieurs kilomètres. Les utilisateurs de cet équipement doivent examiner soigneusement tout fonctionnement provoquant le rayonnement d'un signal (direct ou indirect) et ils doivent prendre les dispositions nécessaires afin d'éviter des problèmes potentiels d'interférences sur les communications.



Table of Contents

Revision History	R-1
• Software Notifications	1-v
Chapter 1 Overview of the CX100	1-1
1.1 About the CX100 ComXpert	1-2
1.2 Device Features and Capabilities	1-3
1.2.1 CX100 RF Features and Capabilities	1-3
1.2.2 OneExpert Platform and System Features	1-4
1.3 Principles of Operation	1-4
1.3.1 OneExpert Platform Overview	1-4
1.3.2 RF Application Module	1-5
1.3.3 Device Software	1-5
1.4 Front Panel Controls	1-5
1.4.1 LCD	1-6
1.4.2 Function Keys	1-6
1.4.3 Arrow Buttons	1-6
1.4.4 OK Button	1-6
1.4.5 Back Button	1-6
1.4.6 Home Button	1-6
1.4.7 Utility Tray Button	1-6
1.4.8 Power Button	1-7
1.5 CX100 Connectors	1-7
1.5.1 DUPLEX Connector	1-8
1.5.2 ANT/SWR Connector	1-8
1.5.3 10 MHz Frequency Reference I/O Connector	1-9
1.5.4 Audio In Connector	1-9
1.5.5 Audio Out Connector	1-9
1.5.6 USB-C Type Connector	1-9

1.5.7	USB Connector	1-9
1.5.8	Ethernet Connector	1-10
1.5.9	DC Input Connector	1-10
1.6	LED Indicators	1-12
1.6.1	Sync LED	1-12
1.6.2	Network LED	1-12
1.6.3	Error LED	1-13
1.6.4	Battery LED	1-13
1.6.5	Charge Status LED	1-13
Chapter 2	Getting Started: Setup and Operation	2-1
2.1	Upon Receipt	2-2
2.1.1	Unpack the Equipment	2-2
2.1.2	Inspect the Equipment	2-2
2.1.3	Verify Contents	2-3
2.1.4	Prepare for First Time Use	2-4
2.1.5	Verify Operation	2-5
2.2	Powering the Device	2-6
2.2.1	AC Power Operation	2-6
2.2.2	Battery Operation	2-7
2.3	Power On/Off Procedures	2-7
2.3.1	Turning the Device ON	2-7
2.3.2	Turning the Device OFF	2-8
2.4	Device Control and Operation	2-8
2.4.1	Local Operation	2-8
2.4.2	Remote Operation	2-8
2.5	UI Navigation, Control and Layout	2-8
2.5.1	Screen Navigation and Control	2-9
2.5.2	Soft-keys	2-10
2.5.3	Selecting Functions and Applications	2-11
2.5.4	Screen Layout	2-12
2.5.5	System Status UI Indicators	2-14
Chapter 3	System and Utility Function Descriptions	3-1
3.1	Introduction	3-3
3.1.1	Accessing System Settings	3-3
3.1.2	Date and Time Panel	3-4
3.1.3	Remote Operation Panel	3-5
3.1.4	Wireless Personal Area Network (WPAN) Settings Panel	3-6
3.1.5	International Settings Panel	3-6
3.1.6	Network Software Update panel	3-7
3.1.7	USB Software Update Panel	3-8
3.1.8	Hardware & Software Revisions Panel	3-9

- 3.1.9 Software Options Panel 3-9
- 3.1.10 Hardware Options Panel 3-9
- 3.1.11 Calibration Screen 3-10
- 3.1.12 Home Screen Settings 3-10
- 3.1.13 Save Location Settings 3-10
- 3.1.14 Restore Factory Defaults Settings 3-11
- 3.1.15 Power Off Screen 3-11
- 3.1.16 Template Management Screen 3-11
- 3.1.17 Screen & Power Management 3-12
- 3.1.18 Sounds Screen 3-12
- 3.1.19 Theme 3-12
- 3.1.20 User Information 3-13
- 3.1.21 Help 3-13
- 3.1.22 Notifications 3-13
- 3.1.23 System Network Screen 3-13
- 3.1.24 Web Browser 3-17
- 3.1.25 File Browser 3-17
- 3.1.26 USB File Browser 3-18
- 3.2 Utility Functions 3-19
 - 3.2.1 Accessing Utility Functions 3-19
 - 3.2.2 Save Report Button 3-19
 - 3.2.3 View Report 3-20
 - 3.2.4 Screen Shot 3-20
 - 3.2.5 Network Button 3-20
 - 3.2.6 Wireless Personal Area Network (WPAN)® Button 3-20
 - 3.2.7 Volume Button 3-20
 - 3.2.8 Help 3-20
 - 3.2.9 Tutorial 3-21
 - 3.2.10 Workflow Manager 3-21
 - 3.2.11 Templates 3-21

- Chapter 4 Configuring System Settings 4-1**
 - 4.1 Locating Device’s Unit ID 4-2
 - 4.2 Configuring Device Settings 4-2
 - 4.2.1 Restore Factory Defaults 4-2
 - 4.2.2 Configuring International Settings 4-3
 - 4.2.3 Setting Date and Time 4-4
 - 4.2.4 Change Display Content and Settings 4-6
 - 4.2.5 Configure Device Power Settings 4-7
 - 4.2.6 User Information 4-7
 - 4.2.7 Specifying File Save Location 4-8
 - 4.2.8 Setting the Volume 4-8

4.3	Configuring 10 MHz Frequency Reference	4-9
4.4	Establishing a Network Connection	4-10
4.4.1	Establishing an Ethernet Connection	4-10
4.4.2	Establishing a WiFi Connection	4-13
4.5	Remotely Operating the Device	4-16
4.5.1	Establishing VNC Viewer Connection	4-16
4.5.2	Ending a Remote Operation Session	4-17
4.6	Establishing a Wireless Personal Area Network (WPAN) Connection	4-17
4.6.1	Enabling Wireless Personal Area Network (WPAN) Connectivity	4-17
4.6.2	Connecting to a Wireless Personal Area Network (WPAN) Device	4-17
4.7	Updating the Device's Software	4-18
4.7.1	Software Availability	4-18
4.7.2	Methods of Updating Software	4-18
4.8	Hardware/Software Versions and Options	4-20
4.8.1	Viewing Hardware/Software Revision Information	4-20
4.8.2	Viewing Option Information	4-20
4.8.3	Installing Options	4-20
4.9	Capturing a Screen Shot	4-21
4.10	Enabling Password Protection	4-21
4.11	Creating UI Shortcut	4-21
4.12	Customizing the Web Browser	4-22
Chapter 5	RF Instrument Function Descriptions	5-1
5.1	Overview of the RF Instrument	5-2
5.2	RF Test	5-3
5.2.1	RF Test Modes of Operation	5-3
5.2.2	Test Setup Summary Panel	5-4
5.2.3	RF Generator	5-5
5.2.4	Modulation Generator	5-7
5.2.5	RF Receiver	5-10
5.2.6	AF Function Generator	5-14
5.2.7	RF Test Meters	5-16
5.2.8	Digital Plots Panel	5-30
5.2.9	RF Analyzer	5-32
5.2.10	AF Analyzer	5-43
5.3	Spectrum Analyzer	5-50
5.3.1	Introduction	5-50
5.3.2	Spectrum Analyzer Screen Layout	5-50
5.4	VSWR/DTF	5-59
5.4.1	Introduction	5-59
5.4.2	VSWR/DTF Screen Layout and Behavior	5-59
5.4.3	VSWR Test Function	5-59

5.4.4	DTF Test Function	5-64
5.4.5	Cable Database (DB)	5-68
5.5	Autotest Function	5-71
5.5.1	Autotest Screen Layout	5-71
5.5.2	Autotest Soft-key Panel	5-72
5.5.3	Autotest Controls and Settings	5-73
5.5.4	Automated Self Test	5-73
5.6	SCA Capability	5-75
5.6.1	Launch SCA Autotest	5-75
5.6.2	SCA Controls and Settings	5-75
5.7	Settings	5-76
5.7.1	Frequency Reference	5-76
Chapter 6	Performing Tests and Measurements	6-1
6.1	CX100 Self Test Procedure	6-2
6.1.1	Scope of Test	6-2
6.1.2	Equipment Needed	6-2
6.1.3	Running Self-test	6-2
6.2	FM Transmitter Testing	6-3
6.2.1	Scope of Test	6-3
6.2.2	UUT Parameters/Characteristics	6-3
6.2.3	Equipment Needed	6-4
6.2.4	Test Setup	6-4
6.2.5	Gathering Test Data	6-8
6.3	AM Transmitter Testing	6-10
6.3.1	Scope of Test	6-10
6.3.2	UUT Parameters/Characteristics	6-10
6.3.3	Equipment Needed	6-10
6.3.4	Test Setup	6-11
6.3.5	Gather Test Data	6-15
6.3.6	Test UUT Power and Frequency	6-15
6.3.7	Test UUT Modulation Level and Distortion	6-15
6.4	FM Receiver Performance Tests	6-16
6.4.1	Scope of Test	6-16
6.4.2	UUT Parameters/Characteristics	6-16
6.4.3	Equipment Needed	6-16
6.4.4	Test Setup	6-17
6.4.5	Configure the CX100 Meters	6-19
6.4.6	Gather Test Data	6-21
6.5	AM Receiver Tests	6-22
6.5.1	Scope of Test	6-22
6.5.2	UUT Parameters/Characteristics	6-22

6.5.3	Required Equipment	6-22
6.5.4	Configuring the Equipment	6-23
6.5.5	Configure CX100 Meters	6-25
6.5.6	Gather Test Data	6-27
6.6	Performing VSWR/DTF Testing	6-28
6.6.1	Scope of Test	6-28
6.6.2	UUT Parameters/Characteristics	6-28
6.6.3	Equipment Needed	6-28
6.6.4	Calibrate the CX100 Before VSWR Testing	6-28
6.6.5	To Perform VSWR Test	6-30
6.7	Performing Distance to Fault (DTF) Tests	6-31
6.7.1	Scope of Test	6-31
6.7.2	UUT Parameters/Characteristics	6-31
6.7.3	Equipment Needed	6-31
6.7.4	Configuring the Equipment	6-32
Chapter 7	Managing Files and Reports	7-1
7.1	Generating Reports	7-2
7.1.1	Custom Report Fields	7-2
7.1.2	Enforcing Report Entry	7-3
7.1.3	Saving a Report	7-3
7.1.4	Viewing a Report	7-4
7.2	Managing Files	7-4
7.2.1	Accessing the File Browser	7-4
7.2.2	Selecting Files or Folders	7-5
7.2.3	Opening Files or Folders	7-5
7.2.4	Copying and Pasting Files or Folders	7-5
7.2.5	Downloading Files via Web Browser	7-6
7.2.6	Uploading Files Using FTP/HTTP	7-6
7.3	Viewing the User's Guide on the Device	7-6
Chapter 8	Care, Maintenance, and Troubleshooting	8-1
8.1	Recharging the Battery	8-2
8.2	Replacing the Battery	8-2
8.3	Storing the Module	8-2
8.4	Shipping Instructions	8-2
8.4.1	Return Material Authorization (RMA)	8-3
8.4.2	Tagging the Device	8-3
8.4.3	Shipping Containers	8-3
8.4.4	Freight Costs	8-3
8.4.5	Packing Procedure	8-4
8.5	Operator Level Maintenance	8-5
8.5.1	Visual Inspections	8-5

8.5.2 External Cleaning 8-5
8.5.3 Updating Software 8-6
8.5.4 CX100 ComXpert Self Test Procedure 8-6
8.6 Troubleshooting 8-7
8.6.1 Troubleshooting Symptom Index 8-7
8.6.2 Troubleshooting Procedures 8-8

Appendix A Specifications A-1

A.1 RF Generator Specifications A-2
A.2 Modulation Generator Specifications A-3
A.3 Audio Frequency (AF) Function Generator Specifications A-4
A.4 RF Receiver Specifications A-5
A.5 Measurement Specifications A-6
A.5.1 RF Power Measurement Specifications A-6
A.5.2 RF Counter Specifications A-6
A.5.3 FM Measurement Specifications A-7
A.5.4 AM Measurement Specifications A-7
A.5.5 Distortion Measurement Specifications A-7
A.5.6 SINAD Measurement Specifications A-8
A.5.7 Signal to Noise (SNR) Measurement Specifications A-8
A.5.8 AF Counter Specifications A-8
A.6 AF Analyzer Specifications A-9
A.6.1 Frequency Domain Specifications A-9
A.6.2 Time Domain Specifications A-10
A.7 VSWR and DTF Measurement Specifications A-10
A.8 Audio Filter Specifications A-11
A.9 RF Analyzer Specifications A-11
A.10 Spectrum Analyzer Specifications A-12
A.11 Zero-Span Analyzer Specifications A-13
A.12 Connector Specifications A-13
A.13 Frequency Standard and Timebase Specifications A-15
A.14 Power Specifications A-16
A.15 Hardware Specifications A-16
A.16 Environmental Specifications A-17
A.17 Safety and Compliance Standards A-18

Appendix B Module and Battery Replacement Procedures B-1

B.1 Intended Audience B-2
B.2 Battery Replacement Information B-2
B.3 Tool Requirements B-2
B.4 Safety Information B-2

	B.4.1 ESD Precautions	B-2
	B.4.2 Battery Handling and Disposal	B-3
	B.5 Removing the RF Module	B-4
	B.6 Installing the RF Module	B-6
	B.7 Removing the Battery	B-7
	B.8 Installing the Battery	B-7
Appendix C	DTF Cable DB - Cable Values	C-1
Appendix D	Keyboard Mapping	D-1

List of Figures

Figure	Title	Page#
Figure 1-1 . . .	CX100 ComXpert Handheld Radio Test Set	1-2
Figure 1-2 . . .	CX100 Controls and Buttons	1-5
Figure 1-3 . . .	CX100 RF Input/Output Connectors	1-7
Figure 1-4 . . .	Platform Controls and Connectors	1-9
Figure 1-5 . . .	DC Input Connector Location	1-11
Figure 1-6 . . .	CX100 Front Panel LEDs	1-12
Figure 1-7 . . .	CX100 Battery LED	1-13
Figure 2-1 . . .	Test Screen Layout Examples	2-12
Figure 2-2 . . .	Home Screen Example	2-12
Figure 3-1 . . .	System Settings Menu Access	3-3
Figure 3-2 . . .	CX100 Utility Tray - Example	3-19
Figure 5-1 . . .	RF Test Mode Menus	5-3
Figure 5-2 . . .	RF Test Setup Summary Panel	5-4
Figure 5-3 . . .	Meter “Block” Content Diagram	5-16
Figure 5-4 . . .	Opening Meter Configuration Window	5-17
Figure 5-5 . . .	VSA Block Diagram	5-24
Figure 5-6 . . .	RF Analyzer Panel Layout	5-32
Figure 5-7 . . .	RF Analyzer Marker Controls	5-39
Figure 5-8 . . .	Identifying Marker Data Fields	5-40
Figure 5-9 . . .	Marker Indicator Line - Drag and Drop	5-42
Figure 5-10 . . .	AF Analyzer Frequency Domain Tab Layout	5-43
Figure 5-11 . . .	AF Analyzer Time Domain Tab Layout	5-47
Figure 5-12 . . .	Spectrum Analyzer Screen Layout	5-50

Figure 5-13 . . . VSWR Screen Components 5-60

Figure 5-14 . . . DTF Tab Layout 5-64

Figure 5-15 . . . Cable DB tab Components 5-68

Figure 5-16 . . . AutoTest Screen Layout and Functions 5-71

Figure 6-1 . . . FM Transmitter Test Setup Diagram 6-4

Figure 6-2 . . . AM Transmitter Test Setup Diagram 6-11

Figure 6-3 . . . FM Receiver Test Setup Diagram 6-17

Figure 6-4 . . . AM Receiver Test - Setup Diagram 6-23

Figure 6-5 . . . VSWR Calibration Setup Diagram 6-28

Figure 6-6 . . . Calibration running and complete 6-29

Figure 6-7 . . . VSWR Test Setup Diagram 6-30

Figure 6-8 . . . DTF Test Setup Diagram 6-32

Figure 6-9 . . . DTF (Distance to Fault) and Calibration 6-33

Figure 6-10 . . . Return Loss 6-34

Figure B-1 . . . RF Module Removal Process Diagrams B-4

Figure B-2 . . . Separating RF Module and Base B-5

Figure B-3 . . . Base Unit - RF Module Removed B-5

Figure B-4 . . . CX100 RF Module Installation Diagram B-6

Figure B-5 . . . Battery Cover Screw Location B-7

Figure B-6 . . . Battery Cables and Release Clip B-7



List of Tables

Table	Table Title	Page #
Table E-1	Revision History	E-1
Table 1	Symbols and Markings	vii
Table 2	Safety Definitions	viii
Table 1	Text and Symbol Conventions	iii
Table 2-1	Standard Items	2-3
Table 2-2	CX100Accessory Kit #TBD	2-3
Table 2-3	Types of Soft-keys	2-10
Table 2-4	System Status UI Indicators	2-14
Table 3-1	Date and Time Controls and Settings	3-4
Table 3-2	Remote Operation and VNC Controls and Settings	3-5
Table 3-3	Wireless Personal Area Network Controls and Settings	3-6
Table 3-4	Network Software Update Controls and Settings	3-7
Table 3-5	USB Software Update Controls and Settings	3-8
Table 3-6	Hardware & Software Revision Data	3-9
Table 3-7	Software Options Controls and Settings	3-9
Table 3-8	Save Location Settings	3-10
Table 3-9	Restore Defaults Settings	3-11
Table 3-10	Screen and Power Management Settings	3-12
Table 3-11	Network Controls and Settings	3-14
Table 3-12	IPv4/IPv6 Dual Stack Network Controls and Settings	3-15
Table 3-13	IPv4 Network Controls and Settings	3-15
Table 3-14	IPv6 Network Controls and Settings	3-16
Table 5-1	RF Generator Controls and Settings	5-5
Table 5-2	Modulation Generator Controls and Settings	5-7
Table 5-3	External Modulation Controls and Settings	5-9

Table 5-4	RF Receiver Controls and Settings	5-10
Table 5-5	AF Generator Controls and Settings	5-14
Table 5-6	Meter Limit Status Indicators	5-18
Table 5-7	Audio Meter Controls and Settings	5-21
Table 5-8	Demod Meter Controls and Settings	5-22
Table 5-9	Digital Meter General Settings	5-25
Table 5-10	Digital Meter Modulation Settings	5-26
Table 5-11	Digital Meter Equalizer Settings	5-26
Table 5-12	Digital Measurement Filter Settings	5-27
Table 5-13	Equalizer Soft-key Panel	5-28
Table 5-14	RF Power Meter Controls and Settings	5-29
Table 5-15	Constellation Plot Soft-key Panel	5-30
Table 5-16	Constellation Plot Controls and Settings	5-31
Table 5-17	RF Analyzer Soft-keys	5-33
Table 5-18	RF Analyzer Display Settings	5-34
Table 5-19	RF Analyzer Instrument Settings	5-36
Table 5-20	RF Analyzer Marker Controls and Settings	5-39
Table 5-21	Marker Data Field Description	5-40
Table 5-22	AF Analyzer Frequency Domain Soft-keys	5-44
Table 5-23	Frequency Domain Instrument Settings	5-45
Table 5-24	AF Analyzer Time Domain Soft-keys	5-48
Table 5-25	AF Analyzer Time Domain Instrument Settings	5-48
Table 5-26	Spectrum Analyzer Soft-keys	5-51
Table 5-27	Spectrum Analyzer Display Settings	5-52
Table 5-28	Spectrum Analyzer Instrument Settings	5-54
Table 5-29	VSWR Soft-keys	5-61
Table 5-30	VSWR Display Settings	5-62
Table 5-31	VSWR Instrument Settings	5-63
Table 5-32	DTF Soft-keys	5-65
Table 5-33	DTF Instrument Settings	5-66
Table 5-34	Cable DB Soft-keys	5-69
Table 5-35	Cable DB Controls and Settings	5-69
Table 5-36	Autotest Soft-keys	5-72
Table 5-37	Autotest Controls and Settings	5-73
Table 5-38	Frequency Reference Controls/Settings	5-76
Table 6-1	FM Transmitter Test - UUT Settings	6-3
Table 6-2	FM Transmitter Test - RF Receiver Settings	6-5
Table 6-3	FM Transmitter Test - AF Function Generator Settings	6-7
Table 6-4	AM Transmitter Test - UUT Settings	6-10

Table 6-5	CX100 Settings - RF Receiver Settings	6-11
Table 6-6	AM Transmitter Test - AF Function Generator Settings	6-13
Table 6-7	FM Receiver Test - UUT Parameters	6-16
Table 6-8	CX100 Settings - RF Generator Settings	6-17
Table 6-9	FM Receiver Test- Modulation Generator Settings	6-18
Table 6-10	FM Receiver Test - Meter Settings	6-19
Table 6-11	AM Receiver Test - UUT Parameters	6-22
Table 6-12	AM Receiver Test - RF Generator Settings	6-23
Table 6-13	AM Receiver Test - Modulation Generator Settings	6-24
Table 6-14	AM Receiver Test - Meter Settings	6-25
Table 6-15	VSWR Test - Example Cable Characteristics	6-28
Table 6-16	CX100 VSWR Test Settings	6-30
Table 6-17	DTF Test - Example Cable Characteristics	6-31
Table 6-18	DTF Test Settings	6-32
Table A-1	RF Generator Specifications	A-2
Table A-2	Modulation Generators	A-3
Table A-3	AF Function Generator	A-4
Table A-4	RF Receiver Specifications	A-5
Table A-5	RF Power Meter Specifications	A-6
Table A-6	RF Counter Specifications	A-6
Table A-7	FM Measurement Specifications	A-7
Table A-8	AM Measurement Specifications	A-7
Table A-9	Distortion Meter Specifications	A-7
Table A-10	SINAD Meter Specifications	A-8
Table A-11	SNR Meter Specifications	A-8
Table A-12	AF Counter Specifications	A-8
Table A-13	AF Analyzer Frequency Domain	A-9
Table A-14	AF Analyzer Time Domain	A-10
Table A-15	VSWR/DTF Specifications)	A-10
Table A-16	Audio Filters	A-11
Table A-17	RF Analyzer Specifications	A-11
Table A-18	Spectrum Analyzer Specifications	A-12
Table A-19	Zero Span Analyzer Specifications	A-13
Table A-20	ANT/SWR Connector Specifications	A-13
Table A-21	DUPLEX Connector Specifications	A-14
Table A-22	Audio In Connector Specifications	A-14
Table A-23	Audio Out Connector Specifications	A-14
Table A-24	Ethernet Connector Specifications	A-14
Table A-25	USB Connector Specifications	A-15

Table A-26 DC Input Connector Specifications	A-15
Table A-27 Frequency Standard I/O	A-15
Table A-28 Power Specification	A-16
Table A-29 Battery Specifications	A-16
Table A-30 Dimensions and Weight	A-16
Table A-31 Environmental Specifications	A-17
Table A-32 Miscellaneous Standards	A-18
Table B-1 Battery Replacement Tool Requirements	B-2
Table C-1 RG-115A Cable Values	C-1
Table C-2 RG-142B Cable Values	C-1
Table C-3 RG-174 Cable Values	C-1
Table C-4 RG-213 Cable Values	C-2
Table C-5 RG-214 Cable Values	C-2
Table C-6 RG-223 Cable Values	C-2
Table C-7 RG-400 Cable Values	C-2
Table C-8 RG-55 Cable Values	C-2
Table C-9 RG-55A Cable Values	C-2
Table C-10 RG-55B Cable Values	C-3
Table C-11 RG-58 Cable Values	C-3
Table C-12 RG-58A Cable Values	C-3
Table C-13 RG-58B Cable Values	C-3
Table C-14 RG-58C Cable Values	C-3
Table C-15 RG-58foam Cable Values	C-3
Table C-16 RG-8 Cable Values	C-4
Table C-17 RG-8A Cable Values	C-4
Table C-18 RG-8foam Cable Values	C-4
Table C-19 USER Cable Values	C-4
Table D-1 Computer to CX100 Keyboard Mapping	D-1



Preface

This preface contains the following product information:

- Intended Audience ii
- Product Nomenclature ii
- Related Information ii
- Contact Information iii
- Conventions iii

Purpose and Scope

This document contains safety information and instructions for installing and operating the CX100 ComXpert Handheld Radio Test Set.

Type of Manual:	Operation Manual
Equipment Name and Model Number:	CX100 ComXpert Handheld Radio Test Set
Purpose of Equipment:	CX100 ComXpert is used for testing radios and related equipment.

Intended Audience

This manual is intended for personnel who are familiar with radio test systems and associated equipment and terminology.

Product Nomenclature

Common Name	Official Nomenclature
CX100	CX100 ComXpert Handheld Radio Test Set
OneExpert	OneExpert™ Platform

Terminology

The terms CX100 and device are used throughout this manual to refer to the CX100 ComXpert.

The term OneExpert and OneExpert base are used throughout this manual to refer to the OneExpert™ Platform base unit.

Related Information

This is the operation manual for the CX100 ComXpert Handheld Radio Test Set. This manual contains product safety information, specifications, setup procedures, and detailed descriptions of CX100 functions.

This manual is distributed with new products on a CD-ROM. Check the VIAVI website for availability of this and other product publications.

Contact Information

Contact the Technical Assistance Center (TAC) for technical support or with any questions regarding this or another VIAVI products.

- Phone: 1-844-GO-VIAVI

For the latest TAC information, go to:

<http://www.viavisolutions.com/en/services-and-support/support/technical-assistance>

Conventions

This guide uses typographical and symbols conventions as described in the following table.

Table 1 Text and Symbol Conventions

Item(s)	Example(s)
Buttons, keys, switches, or connectors on the device (hardware components).	Press the On button. Press the Enter key. Flip the Power switch to the on position.
Buttons, links, menus, menu options, tabs, or fields on a UI (software components).	Click Start . Click File > Properties . Click the Properties tab. Type the name of the probe in the Probe Name field.
References to external publications appear in <i>this typeface</i> .	See <i>Newton's Telecom Dictionary</i> .
Text that must be entered exactly as shown.	Type a: <code>\set.exe</code> in the dialog box.
A vertical bar means "or": only one option can appear in a single command.	platform a b c

This page intentionally left blank.

Overview of the CX100

This chapter describes CX100 ComXpert controls, connectors, functions and capabilities. This chapter reviews the following topics:

- [About the CX100 ComXpert](#) 1-2
- [Device Features and Capabilities](#) 1-3
- [Principles of Operation](#). 1-4
- [Front Panel Controls](#) 1-5
- [CX100 Connectors](#). 1-7
- [LED Indicators](#) 1-12

1.1 About the CX100 ComXpert

The CX100 ComXpert is a hand-held communications test set that supports bench and field radio testing. The CX100 provides the capabilities needed to test a variety of radios, as well as commercial radio applications. The CX100 is capable of performing high power measurements, as well as fault finding for antennas, power amplifiers and interconnects.

The CX100 ComXpert is powered by an internal, rechargeable battery that provides up to 3 hours of continuous operation. The CX100 is equipped with a DC input connector that supports battery charging and use of an AC power adapter for connection to an AC power supply.



Figure 1-1 CX100 ComXpert Handheld Radio Test Set

The CX100 ComXpert uses the VIAVI OneExpert Platform to support system functions such as network connectivity, power management and software updates. The RF Application Module supports the device's RF test and measurement functions.

The CX100 ComXpert is designed for ease of use, reliability and long service life. The modular platform design allows the base platform to be expanded to incorporate other application modules which may be developed to support continuing industry advancements.

1.2 Device Features and Capabilities

This section identifies key features and capabilities supported by the CX100 ComXpert.

1.2.1 CX100 RF Features and Capabilities

The CX100 provides test and measurement capabilities that can be used to evaluate the transmit and receive performance of a radio system (radio, antenna, base station), locate faults in antennas, power amplifiers and cables. The CX100 supports the following test and measurement capabilities:

- 1 MHz to 6 GHz frequency range with up to 100 MHz instantaneous bandwidth
- Measurement limit checks, user selectable measurement types (maximum, minimum, live and average) for all meters
- Built-in-Test (BIT) and diagnostics for internal validation and testing
- Capable of receiving and recording RF signals for off-line analysis or playback
- RF Spectrum Analyzer supports up to 6 GHz frequency with 20 MHz instantaneous bandwidth
- Asynchronous, swept RF Analyzer
- Audio Analyzer supports DC up to 100 kHz with spectral and scope displays.
- Digital signal analyzer with EVM and constellation measurements
- Frequency and Amplitude modulation meters
- Frequency Counter and Frequency Error meters
- RF Power Meter supports 20 W continuous; 200 W with an external attenuator
- Parametric Distortion and SINAD meters
- AM/FM/PM modulation and demodulation
- VSWR and DTF measurements
- Two internal Audio Frequency (AF) Function Generators
- Two internal Modulation Generators; one External Modulation Generator
- Self-Test and Diagnostics for internal validation and testing
- Remote access and operation using VNC viewing application
- Dedicated high power RF output port and high power RF input port
- Dedicated high sensitivity, low power RF input port and low RF output port
- Fast tuning speed and wide range of Resolution Bandwidth (RBW) allowing high accuracy analysis

1.2.2 OneExpert Platform and System Features

The OneExpert platform supports the following hardware and system features:

- Rechargeable battery supports ~3 hours continuous use
- Capacitive Liquid Crystal Display (LCD) with user adjustable back-light and contrast
- Field upgradeable software and option installation
- One Ethernet connector
- One 3.0 USB connector
- WiFi and GPS (timing) receivers
- Sleep mode (battery power saving mode)

1.3 Principles of Operation

The CX100 ComXpert uses the VIAVI OneExpert platform to support system functionality, and the RF Application Module as the basis for RF test and measurement functions.

1.3.1 OneExpert Platform Overview

The VIAVI OneExpert platform base contains a processor, backplane interface, Liquid Crystal Display (LCD), front panel controls, and a rechargeable battery. The base processor is responsible for managing system level functions such as network connectivity, file management and software upgrade procedures. The base processor is also responsible for managing the device's power consumption/power saving functions and the device's battery charging processes.

The LCD and front panel controls provide the user interface for controlling and operating the device. The mechanical components of the OneExpert base provide access to the device's USB and Ethernet ports as well as the DC Input port. The backplane provides the interface between the OneExpert base unit and RF Application Module.

1.3.2 RF Application Module

The CX100's RF Application Module supports the device's RF test and measurement functions. The RF Application Module's mechanical housing contains the device's RF and audio input and output connectors. The RF Application Module contains a PCB Assembly that is responsible for processing and routing signals through the module.

1.3.3 Device Software

The CX100 ships from the factory with the current version of Software (SW) and Firmware (FW) installed on the device. The **Hardware & Software Revisions Panel** displays the version of the software and firmware installed on the device. See section 3.1.8, "Hardware & Software Revisions Panel", on page 3-9 for information.

Routine maintenance checks should be performed to ensure the device has been upgraded to the latest production software release. See section 4.7, "Updating the Device's Software", on page 4-18 for software upgrade procedures. In the event a software update is needed, CX100 software can be upgraded in the field, and can be updated using a network connection or a USB device. CX100 software also supports field-installed software options.

1.4 Front Panel Controls

Front panel controls and buttons are used to operate and control the device. Many of the functions performed using the front panel buttons are supported using the touchscreen.



Figure 1-2 CX100 Controls and Buttons

1.4.1 LCD

The Liquid Crystal Display (LCD) is a capacitive touchscreen that operates similarly to a mobile device. The touchscreen supports gestures such as press to open/select/activate, press and hold, press and drag, swipe sideways and pinch to zoom.

1.4.2 Function Keys

The **Function Keys** select functions or UI content associated with each key position. When there are soft-keys located on the UI above the **Function Keys**, the soft-keys and corresponding hard key will perform the same function.

1.4.3 Arrow Buttons

The **Arrow buttons** are used to navigate through menu selections and fields on the UI.

1.4.4 OK Button

The **OK button** is used to accept/confirm a changed setting or to proceed to the next menu. Use the **Back button** to close a menu or exit a data field without changing the current setting.

1.4.5 Back Button



The **Back button** is used to exit a menu or to go back to the previous menu or content. If a data field is selected for editing, selecting the **Back button** exits the data field, canceling an unconfirmed change.

1.4.6 Home Button



Pressing the **Home button** returns to the device's main/home screen. The **UI Home button** performs the same action.

1.4.7 Utility Tray Button



Pressing the **Utility Tray button** opens a panel on the UI that is referred to as the **Utility Tray**. The **Utility Tray** contains buttons that access functions to save test reports, turn network or Wireless Personal Area Network (WPAN) functions on or off, or enable/disable remote operation.



The **Utility Tray** can also be opened using the **Tray soft-key** located at the top of the UI. See section 3.2, “Utility Functions”, on page 3-19 for additional information.

1.4.8 Power Button

The **Power Button** is used to turn the device on and off. The device is turned on or off by pressing and holding the button for approximately 3 seconds.



NOTE

The CX100 can be configured to emit a beep at power up/power down. See section 4.2.5.2, “Beep at Power Up/Down”, on page 4-7) for information.

1.5 CX100 Connectors




Figure 1-3 CX100 RF Input/Output Connectors



CAUTION

Do not overload input connectors. Refer to product specifications or the product data sheet for maximum input ratings.

Mise en Garde

Ne surchargez pas les connecteurs d'entrée. Reportez-vous aux spécifications du produit ou à la fiche technique du produit pour connaître les valeurs d'entrée maximales.

1.5.1 DUPLEX Connector

The **DUPLEX connector** is a combined (duplex) N-type connector. This connector is selectable as the RF Generator output and/or the RF Receiver input connector.

DUPLEX Input Connector

The **DUPLEX connector** should be selected as the RF Input connector when performing high power measurements.

DUPLEX Output Connector

The **DUPLEX connector** should be selected as the RF output connector when the lowest level of RF Generator output is needed.

1.5.2 ANT/SWR Connector

The **ANT/SWR connector** is a TNC connector and is selectable as either an RF Input or RF Output connector.



NOTE

The **ANT/SWR connector** does not support duplex input/output capabilities. When the **ANT/SWR connector** is selected as the RF output connector, the system disables the connector's receive capabilities.

ANT/SWR as Input Connector

The **ANT/SWR connector** should be selected as the RF Input connector for the following test conditions:

- To perform over the air testing using an external antenna.
- When test parameters require maximum input sensitivity.
- When measuring low level RF signals.

ANT/SWR as Output Connector

The **ANT/SWR connector** should be selected as the RF output connector for the following test conditions:

- To output high power RF signals.
- VSWR/DTF testing.

1.5.3 10 MHz Frequency Reference I/O Connector

The **10 MHz Frequency Reference I/O connector** is a SMB connector and is used to connect the CX100 to an external frequency standard, or to output the internal frequency standard from the CX100 to other equipment.

The 10 MHz frequency reference is configured from the **Frequency Reference Configuration window**. See section 4.3, “Configuring 10 MHz Frequency Reference”, on page 4-9 for setup information.

1.5.4 Audio In Connector

The **Audio In connector** is a BNC type connector that serves as the RF Instrument’s primary AF, Digital and external modulation input connector. The **Audio In connector** is selected on the AF Analyzer panel.

1.5.5 Audio Out Connector

The **Audio Out connector** is a BNC type connector that serves as the RF Instrument’s primary AF generator and digital output connector.

1.5.6 USB-C Type Connector

This connector is reserved for future development.

1.5.7 USB Connector

The **USB connector** is used for transferring test results from the device to a USB drive, for transferring test scripts or digital waveform files to the device, or for performing USB software/firmware upgrade.




Figure 1-4 Platform Controls and Connectors



NOTE

The **USB** and **Ethernet connectors** are protected from environmental factors, such as dust, by rubber access covers; these covers should be closed securely when the connectors are not in use.

1.5.8 Ethernet Connector

The **Ethernet connector** is used to connect the CX100 to a network for the purpose of performing tasks such as file transfer, software updates, and remotely controlling to the device. See [Figure 1-4](#).

See [section 4.4.1.1, “Enable Network Connectivity”, on page 4-10](#) for instructions to connect the device to a network.

1.5.9 DC Input Connector

The **DC Input connector** is a +12 VDC connector located on the bottom end of the device. This connector is used to connect the CX100 to the AC adapter in order to power the device and to charge the device’s internal battery.

The **Charge Indicator LED** is located next to the **DC Input connector**. See [section 1.6.5, “Charge Status LED”, on page 1-13](#) for a description of this indicator.



Figure 1-5 DC Input Connector Location



NOTE

The **DC Input connector** is protected from environmental factors such as dust by rubber access flaps; keep the access flap closed securely when the connector is not in use.

1.6 LED Indicators

CX100 front panel LED's indicate system activity and status.



Figure 1-6 CX100 Front Panel LEDs



NOTE

The **Sync** and **Network LEDs** alternately blink green when in sleep mode (power saving mode).

1.6.1 Sync LED

The **Sync LED** indicates modem synchronization status.

- Blinking green indicates that the modems are training.
- Solid green indicates that the modems are synchronized and ready for use (reached Showtime).



NOTE

The **Sync** and **Network LEDs** alternately blink green when in sleep mode (power saving mode).

1.6.2 Network LED

The **Network LED** indicates network connectivity status.

- Blinking green indicates that the unit is trying to acquire an IP address.
- Solid green indicates when an IP address has been acquired.
- Blinking amber indicates a timeout; the unit was unable to acquire an IP address.
- If the **Network LED** is not illuminated, the network is inactive; either the unit is not connected to the network or it is logged off.

1.6.3 Error LED

The **Error LED** indicates error and alarm conditions. Solid red indicates error and alarm conditions. The type of errors varies depending on the application. Errors are displayed in the **Utility Tray**. See section 3.1.22, “Notifications”, on page 3-13 for information.

1.6.4 Battery LED

The **Battery LED** is a multi-colored LED that indicates battery status.

- Solid green indicates the battery charge is higher than 30% or that an external source is powering the unit.
- Solid amber indicates the battery charge is getting low; the charge is between 10% and 30%.
- Solid red indicates the battery charge is critically low, less than 10%. An audible beep occurs 30 seconds before shutdown.

1.6.5 Charge Status LED

The **Charge Status LED** is located on the bottom of the device next to the DC Input connector. The **Charge Status LED** is a multi-colored LED that indicates the charge status of the device.



Figure 1-7 CX100 Battery LED

- Solid green indicates charging is complete and the battery is fully charged.
- Solid amber indicates the battery is charging.
- Slow flashing red indicates the battery charge is critically low, less than 10%.
- Fast flashing red indicates charging was suspended due to a fault and user intervention is necessary (for example, the wrong charger is attached).
- Solid red indicates charging was suspended due to overheating; no user intervention is necessary. The unit can continue to run; charging resumes when the device temperature drops to within acceptable parameters.

This page intentionally left blank.

Getting Started: Setup and Operation

This chapter contains information to get users started with using the CX100 ComXpert. This chapter reviews the following information and procedures:

- Upon Receipt 2-2
 - Unpack the Equipment 2-2
 - Inspect the Equipment 2-2
 - Verify Contents 2-3
 - Prepare for First Time Use 2-4
 - Verify Operation 2-5
- Powering the Device 2-6
 - AC Power Operation 2-6
 - Battery Operation 2-7
- Power On/Off Procedures 2-7
 - Turning the Device ON 2-7
 - Turning the Device OFF 2-8
- Device Control and Operation 2-8
 - Local Operation 2-8
 - Remote Operation 2-8
- UI Navigation, Control and Layout 2-8
 - Screen Navigation and Control 2-9
 - Soft-keys 2-10
 - Selecting Functions and Applications 2-11
 - Screen Layout 2-12
 - System Status UI Indicators 2-14

2.1 Upon Receipt

The following tasks should be performed when a CX100 is received from the factory:

- Unpack the Equipment
- Inspect the Equipment
- Verify Contents
- Prepare for First Time Use
- Verify Operation

2.1.1 Unpack the Equipment



NOTE

When unpacking the device, use care not to damage the shipping container and packaging materials: materials should be stored for possible future use.

The CX100 battery is a lithium battery that is shipped in special protective packaging. When removing the packaging, use care not to damage the packaging; the protective packaging can be used in the event the battery needs to be shipped.

To Unpack the Device

1. Cut and remove sealing tape from the top of the shipping container.
2. Remove foam inserts and equipment from the shipping container.
3. Remove the CX100 and battery from packing materials.
4. Store packing material and shipping container for possible future use.

2.1.2 Inspect the Equipment

Inspect the equipment for any damage which may have occurred during shipment. Report any damage to VIAVI (see ["Contact Information" on page 1-iii](#)).

2.1.3 Verify Contents

Verify shipment is complete in accordance with packing list. Report any discrepancies to VIAVI.

2.1.3.1 Standard Items

The following items are included with the CX100 ComXpert:

Table 2-1 Standard Items

Item	Description	Qty
	CX100 ComXpert	1
22071316-002	Battery, Lithium Ion, 7.3V, 13Ah, OneExpert	1
22054882	Power Supply:AC2DC;90-264VAC; 47-63HZ,12VDC	1
22022754	Adapter Cord US/NAmerica	1
22144013	CX100 ComXpert Quick Start Guide	1
22144014	CX100 ComXpert Operation CD	1
22142165	Mech; HAND STRAP	1

2.1.3.2 Accessory Kits

The following are optional accessory items that are available for the CX100 ComXpert.



NOTE

Optional accessories may be included as standard items with some system configurations. Refer to the packing list for shipment contents.
Custom accessories (customer specific) are not listed in the following tables.

Table 2-2 CX100Accessory Kit #TBD

Item	Description	Qty
22147149	CHARGER - Vehicular Adapter NATO Plug	1
9138	Antenna, 2-30 MHz	1
9147	Antenna, 225-512 MHz	1
9151	Antenna, 30-90 MHz	1
22147433	Antenna, 1-6 GHz	1
22147031	CONN, ADPTR TNC-M to BNC-F	1

Table 2-2 CX100Accessory Kit #TBD (Continued)

Item	Description	Qty
38240	Attenuator, 20DB, 50W, DC-6 GHZ	1
22147033	Attenuator, 20DB, 200W, DC-6 GHZ	1
22147032	Connector, Adapter, N-F to N-M	1
23770	Connector, Adapter, N-F to BNC-F	2
20327	Connector, Adapter, N-M to BNC-F	2
23769	Connector, Adapter, N-F to BNC-M	2
23773	Connector, Barrel, N-F to N-F	1
23758	Connector, Adapter, TNC-M to BNC-F	3
22149578	Cable, RF, BNC-M to BNC-M, 48 inches	5
22149490	HANDSET, H-250	1
HST-000-346-00	SOFT CARRYING CASE	1
22145305	HARD CARRYING CASE	1
22144016	Guide, PDF, CX100 Test and Measurements	1
22144013	Guide, QuickStart, PP, CX100	1
22144014	Manual, Operation, CD, CX100	1
22144015	Manual, Operation, PDF, CX100	1
22149489	CABLE, USB-C to RS-232	1
22149491	CAL KIT, DC- 6 GHz	1
22149488	CABLE, RF, TNC-M to TNC-M, 48 inches	2

2.1.4 Prepare for First Time Use

Perform the following to prepare the CX100 for verifying operation:

- Install the battery that shipped with the CX100 in the device. [See section B.8, “Installing the Battery”, on page B-7](#) for instructions.
- Remove the protective film from the LCD by pulling up on the tab located at the lower right corner of the film.

2.1.5 Verify Operation



NOTE

The following procedure is used to verify that the CX100 is operating properly; the procedure is not intended to verify that the CX100 is operating to specified performance parameters.

When the CX100 is received from the factory, perform the following before using the device for the first time:

1. Power on the CX100. [See section 2.2, "Powering the Device", on page 2-6](#) for instructions.
2. Verify the **LEDs** located above the display flash on and off in a series of red and green during the boot-up process.
3. When the device is ready for use, verify the **Battery LED** is illuminated.



NOTE

If the **Battery LED** is red, the battery needs charged (see ["To Charge the Battery" on page 2-7](#)).

4. When the display loads, open the **RF Instrument menu** to access the **RF Instrument** functions.
5. Select the **AutoTest button**.
6. Select the **File Field** located at the top of the screen.
7. Select **Self Test** from the test list.
8. Press the **Select All Soft-key**.
9. Press the **Run Selected Soft-key**.
10. Wait while the device performs a series of automated test process. Do not interrupt this process or the self test will fail. Status indicators show when self test is finished.
11. When AutoTest is finished, verify all portions of the test have passed. If any portion of the AutoTest procedure fails, contact VIAVI (see ["Contact Information" on page 1-iii](#)).
The CX100 is now ready for use.

2.2 Powering the Device

The CX100 is designed to be powered by an internal battery or by an external AC power supply.



CAUTION

- Use only the AC Adapter/Charger supplied with the product. Contact VIAVI for approved replacement parts.
- Do not use the AC Adapter/Charger outdoors or in a wet or damp location.
- Only connect the AC Adapter/Charger to the correct mains voltage indicated on the ratings label.

Mise en Garde

- Utilisez uniquement l'adaptateur / chargeur CA fourni avec l'instrument.
- N'utilisez pas l'adaptateur / chargeur CA à l'extérieur ou dans un endroit mouillé ou humide.
- Connectez uniquement l'adaptateur / chargeur CA à la tension secteur correcte indiquée sur l'étiquette des caractéristiques nominales.



WARNING

Improper grounding of equipment can result in electrical shock. To ensure proper grounding, this device should only be connected to a grounded AC Power Supply.

Avertissement

La mise à la terre inadéquate de l'équipement peut entraîner un choc électrique. Pour s'assurer d'une mise à la terre adéquate, cet appareil doit seulement être branché à une alimentation électrique CA mise à la terre.

2.2.1 AC Power Operation

The CX100 can be powered externally using the provided AC Power Adapter to connect the device to a grounded AC power supply. The device automatically initiates recharging the battery when the CX100 is connected to an AC power supply.

To Connect the Device to an AC Power Supply

1. Connect the power cord to the AC Adapter/Charger.
2. Connect the DC connector to the device's **DC Input Connector**. See [section 1.5.9, "DC Input Connector"](#), on page 1-10 for information.
3. Connect the power cord to a grounded AC power supply.



The **AC Current Icon** is displayed at the top of the UI when the device is connected to an AC power supply.

2.2.2 Battery Operation

The CX100 is designed to be powered by an internal battery that supports up to 3 hours of continuous operation. The amount of battery operation time remaining is indicated by the **Battery LED** on the front panel. See section 1.6.4, “Battery LED”, on page 1-13 for information.

The CX100 is designed with a time-out feature which conserves battery power; this feature is referred to as “Battery Saving Mode”. The time-out period is defined on the **Screen and Power Settings panel**. See section 4.2.5.1, “Battery Saving Mode”, on page 4-7 for information.

To Charge the Battery

1. Connect the device to an AC power supply.
2. Verify the device’s **Battery LED** turns amber to indicate the battery is charging.
3. The **Battery LED** turns green when the battery is fully charged.

2.3 Power On/Off Procedures

The CX100 is powered on and off using the **Power button** located on the front panel.



NOTE

The CX100 can be configured to emit a beep at power up/power down. See section 4.2.5.2, “Beep at Power Up/Down”, on page 4-7 for information.

2.3.1 Turning the Device ON

1. Press and release the **Power button**.
2. An initializing indicator is displayed during the boot-up process. Wait while the device completes the boot-up process; this takes several seconds.
3. The **Home screen** is displayed when the device is ready for use.

2.3.2 Turning the Device OFF

1. Press and hold the Front Panel **Power button** for approximately 3 seconds, then release.
2. The device performs a series of power-down processes.
3. When the power down process is finished, the front panel **LEDs** will no longer be illuminated.

2.4 Device Control and Operation

The CX100 can be operated locally using the device's LCD touchscreen and front panel controls, or remotely using a VNC (Virtual Network Computing) viewing application.

2.4.1 Local Operation

The OneExpert User Interface (UI) is designed to be intuitive and easy to use. The Liquid Crystal Display (LCD) is a capacitive touchscreen that operates similarly to a mobile device. The touchscreen supports gestures such as press to open/select/activate, press and hold, press and drag, swipe sideways and pinch to zoom.

2.4.2 Remote Operation

The CX100 can be controlled from a remote location such as a laptop using a VNC viewing application. See the following sections for additional information:

- [See section 4.5, "Remotely Operating the Device", on page 4-16](#) for instructions to configure the device for remote operation.
- [See section 3.1.3, "Remote Operation Panel", on page 3-5](#) for detailed information about remote operation controls and parameters.

2.5 UI Navigation, Control and Layout

This section describes layout of the CX100 User Interface (UI) and how to navigate between system and test applications and functions. The CX100 UI is designed to be intuitive and easy to use. The Liquid Crystal Display (LCD) is a capacitive touchscreen that operates similarly to a mobile device. The touchscreen supports gestures such as press to open/select/activate, press and hold, press and drag, swipe sideways, and pinch to zoom.

2.5.1 Screen Navigation and Control

2.5.1.1 Screen Navigation

Screens are navigated using the following controls and techniques:

- Expandable panels are opened and closed by selecting the directional arrow on the right side of the title bar.
- **Arrow buttons** are used to move up/down, left/right (see [page 1-6](#)).
- Swipe left/right is used to “flip through” screens on multi-tabbed screens (i.e., **VSWR/DTF screen**).
- The **Back Arrow** is used to return to the previously viewed content or to close a running function or application (see [page 1-6](#)).

2.5.1.2 Expanding Function/Application Menus

Menus are expanded and collapsed using one of the following methods:

To Expand a Menu

- Select the triangle on the right side of the menu using the touchscreen.
- OR -
- Use the **Arrow buttons** to highlight the desired function menu, then press the **OK button**.

The triangle on the right side of the menu points down when a menu is expanded.



NOTE

Function and application menu title bars are purple when selected; gray when not selected.

2.5.1.3 Select Menu Item

To Select a Menu Item

- Open the menu and select the menu item. When a menu item is selected using the touchscreen, the selection is activated upon selection and the menu closes.
< or >
- Use the **Arrow buttons** to highlight the desired item; press the **OK button** to confirm. When confirmed, the election is activated and the menu closes.

2.5.1.4 Entering Text and Numeric Data

Some parameters are defined using text or numeric entry fields (for example, test settings or user information). The process is similar to data entry on a mobile device.





To Enter Text or Numeric Data

1. Select (or navigate to) the desired parameter to open the data entry field. A data entry box is displayed.
2. Select (or navigate to) the data entry box. A keypad is displayed on the screen.
3. Use the keypad to enter the data.
4. Select the **Enter/Return button** on the keypad, or press the **OK button**. The data is entered and stored.

2.5.2 Soft-keys

Some CX100 screens contain a soft-key panel at the bottom of the display. The soft-keys are used to access test settings or perform actions. The UI contains the following types of soft-keys.

Table 2-3 Types of Soft-keys

Examples	Type of Soft-key	Description
	Action Soft-key	Identified by a label that implies/defines an action. When pressed, the system performs the action associated with the soft-key.
	State Soft-key	Identified by a label that identifies a parameter and a label that identifies the current state of the parameter. Some State soft-keys also contain a visual indicator to the on/off state of the parameter.
	Selection Soft-key	Identified by a label that identifies the parameter selections. Pressing the button selects between available selections.
	Menu Soft-key	Menu soft-keys are identified by the up arrows on the soft-key. When pressed, the soft-key updates to display a menu that contains controls and setting.

2.5.3 Selecting Functions and Applications

To Open a Function/Application

- Select the button from the function or application button from the menu.

To Close a Function/Application


- Select the **Close button**  to close the function or application.

Function and test application buttons change color to indicate whether or not the function is current initialized (actively running) on the device.




Function Off Indicator


Indicates the function/application is inactive (turned off).



Function Running - Not Highlighted


Indicates the function/application is running in the background; focus is not on the application.

- Selecting the button reopens the function or application.
- Pressing the **Close button**  closes the function or application.



Function Running - Highlighted

Indicates the function/application is running in the background and you currently have focus on the application.

- Selecting the button reopens the function or application.
- Selecting the **Back button**  closes the function or application.

2.5.4 Screen Layout

CX100 screen layout and content changes based on factors such as the selected function, user settings and modes of operation. All screens consist of three main areas: a header, a main display area, and a footer section.




Figure 2-1 Test Screen Layout Examples

Figure 2-2 Home Screen Example

Header Bar

The header bar displays system status indicators such as battery charge status, WiFi status, and the system clock. The header bar also contains the **Utility Tray** button which is used to access system device tools and functions.

Main Display Area

The main display area contains a variety of components; the content that is displayed is based on the current function and action being performed. The area may contain content such as a list of expandable panels, menus, plot fields, or data tables.

Footer Area

When the footer area is present on the screen, the footer area contains either a shortcut area or a soft-key panel.

- The shortcut area is used to provide quick access to frequently used functions. See section 4.11, “Creating UI Shortcut”, on page 4-21 for information.
- Soft-key panels contain controls and functions associated with the currently selected test function.

2.5.4.1 Home Screen

When the CX100 is powered on the **Home screen** is displayed (see [Figure 2-2 on page 2-12](#)). The **Home screen** contains collapsible menus that expand to provide access to the system and test functions that are available on the device.

When the device is received from the factory, the **Home screen** lists the standard and optional functions that are available on the device. The content displayed on the Home Screen can be changed from the **Home Screen Settings panel**. See section 4.2.4.1, “Customizing Home Screen Contents”, on page 4-6 for information.

The **Home screen** footer area can be used to create short cuts to commonly used functions and applications. See section 4.11, “Creating UI Shortcut”, on page 4-21 for information.

2.5.4.2 Test and System Settings Screens

CX100 test screens contain controls, settings and other UI components applicable to the selected test function. The contents of the test screens depends on the selected mode of operation as well as the active test and measurement function. See [Figure 2-1 on page 2-12](#) for an example.

See [Chapter 5 “RF Instrument Function Descriptions”](#) for information about test screens.

See [Chapter 3 “System and Utility Function Descriptions”](#) for information about system and utility screens.

2.5.5 System Status UI Indicators

The following icons are used to indicate status of system functions.

Table 2-4 System Status UI Indicators

Battery Status Icon



The **Battery Status Icon** displays the charge level of the device's internal battery. The charge level is also displayed as a percent next to the indicator.

See [section 2.2.1, "AC Power Operation"](#), on page 2-6 for information about the device's internal battery.

See [section 8.1, "Recharging the Battery"](#), on page 8-2 for battery recharging instructions and relevant safety information.

AC Power Icon



The **AC Power Icon** is displayed when the device is connected to an AC power supply.

See [section 2.2.1, "AC Power Operation"](#), on page 2-6 for safety information and instructions for connecting the device to an AC power supply.

Network Connection Icon



The **Network Connection Icon** is displayed when the device is connected to an active LAN via one of the device's **Ethernet connectors**.

See [section 4.4.1.2, "Establishing an Ethernet Connection"](#), on page 4-10 for instructions for connecting the device to a network via an Ethernet connection.

WiFi Icon



The **WiFi Icon** is displayed when the device is connected to a network via WiFi.

See [section 4.4.2.2, "Connecting to a WiFi Network"](#), on page 4-14 for instructions for connecting the device to a network via a WiFi connection.

System and Utility Function Descriptions

This chapter provides an overview of the device's system and utility functions. System settings control functions such as date and time, screen and power settings, and software updates. Utility functions are used to configure functions such as network connections and file transfers.

This chapter reviews the following topics:

- Introduction 3-3
 - Accessing System Settings 3-3
 - Date and Time Panel 3-4
 - Remote Operation Panel 3-5
 - Wireless Personal Area Network (WPAN) Settings Panel 3-6
 - International Settings Panel 3-6
 - Network Software Update panel 3-7
 - USB Software Update Panel 3-8
 - Hardware & Software Revisions Panel 3-9
 - Software Options Panel 3-9
 - Hardware Options Panel 3-9
 - Calibration Screen 3-10
 - Home Screen Settings 3-10
 - Save Location Settings 3-10
 - Restore Factory Defaults Settings 3-11
 - Power Off Screen 3-11
 - Template Management Screen 3-11
 - Screen & Power Management 3-12
 - Sounds Screen 3-12
 - Theme 3-12
 - User Information 3-13
 - Help 3-13
 - Notifications 3-13

- System Network Screen 3-13
- Web Browser 3-17
- File Browser 3-17
- USB File Browser 3-18
- Utility Functions 3-19
 - Accessing Utility Functions 3-19
 - Save Report Button 3-19
 - View Report 3-20
 - Screen Shot 3-20
 - Network Button 3-20
 - Wireless Personal Area Network (WPAN)® Button 3-20
 - Volume Button 3-20
 - Help 3-20
 - Tutorial 3-21
 - Workflow Manager 3-21
 - Templates 3-21

See [Chapter 4 “Configuring System Settings”](#) for step by step instructions for configuring CX100 system settings, network connections and user settings.

3.1 Introduction

CX100 system settings configure device parameters such as date and time, screen layout and brightness and battery saving mode, network, WiFi and Wireless Personal Area Network (WPAN) access. Utility functions support file management, user setup information and updating the device’s software and firmware.

3.1.1 Accessing System Settings

System settings are accessed from the **System Menu** on the **Home screen** and from the **System Settings** menu.




Figure 3-1 System Settings Menu Access

To Access System Settings Menu

1. Navigate to the **Home screen**.
2. Open the **System** menu.
3. Select the **System Settings** button to open the **System Settings** menu.

3.1.2 Date and Time Panel

The date and time controls and settings are used to configured the device’s internal clock and calendar. The date and time can be configured manually, or configured to synchronize automatically to a central time server.

When **Time Synchronization** is set to **None**, the date and time fields update to editable fields. See section 4.2.3, “Setting Date and Time”, on page 4-4 for instructions.

When **NTP Synchronization** is enabled, Network Time Protocol (NTP) synchronizes the device’s system clock to a central time server. See section 4.2.3.6, “Time Synchronization”, on page 4-5 for instructions.

Table 3-1 Date and Time Controls and Settings

Control/Setting	Description
Time	The CX100’s clock can be set manually by selecting this field. When the field is selected, a configuration window opens which is used to set the device’s clock.
Date	The CX100 calendar can be set manually by selecting this field. When the field is selected, a configuration window opens which is used to set the date.
Date Format	Selecting this field opens a window to select between supported UTC date formats.
Time Format	Selecting this field opens a window to select between 12 hour or 24 hour time format.
Time Zone	Selecting this field opens a window to adjust the device’s clock to reflect a different time zone. The CX100’s clock updates automatically to reflect the selected adjustment.
DST Used	This setting selects whether or not Daylight Savings Time (DST) is used.
Time Synchronization	This setting selects the method used for time synchronization. See section 4.2.3.6, “Time Synchronization”, on page 4-5.
NTP Server Address Type	This setting selects the formatting type used for the Network Time Protocol (NTP) Server IP Address.
NTP Server	This field is the address of the server where the device gets the time, for example 0.us.pool.ntp.org.
NTP Synchronization State	This field indicates if the device is synchronized with the NTP.

3.1.3 Remote Operation Panel

Remote operation settings are used to configure the device for remote operation. See section 4.5, “Remotely Operating the Device”, on page 4-16 for step by step instructions for configuring the device for remote operation.

The VNC parameters are used to configure the device for remote access and operation. See section 4.5.1, “Establishing VNC Viewer Connection”, on page 4-16 for instructions to configure the device for remote operation.

Table 3-2 Remote Operation and VNC Controls and Settings

Control/Setting	Description
Enable HTTP File Server	When this check box is selected, files can be downloaded from the CX100 via a web browser. See section 7.2.5, “Downloading Files via Web Browser”, on page 7-6 for instructions.
Enable VNC Server	This tick box must be selected in order to access the device using a remote UI viewing application.
VNC Password	This field defines a password that will be required when accessing the device remotely using VNC viewing application.
Connected Viewers	This indicates how many users are remotely connected to the device.
Reserve Ethernet Port for Remote Access	This check box enables simultaneous usage of System Network access and Data Test access on the CX100’s Ethernet connectors . System Network access will use Ethernet 1 Connector; Data Testing will use Ethernet 2 Connector. If this option is not selected, either connector can be used for System Network Access.

3.1.4 Wireless Personal Area Network (WPAN) Settings Panel

The **WPAN Settings panel** contains controls that are used to establish and manage a Wireless connection between the CX100 and another compatible device. The **WPAN Settings panel** remains blank until WPAN capability is enabled and a scan is performed.

Table 3-3 Wireless Personal Area Network Controls and Settings

Control/Setting	Description
Enabled Tick Box	The tick box enables and disables the CX100's WPAN function.
Device List	Displays a list of devices that the CX100 detected on the network that are available for WPAN connection.
Scan for Devices Soft-key	This soft-key scans the network to which the CX100 is connected for WPAN enabled devices.

See section 4.6.1, "Enabling Wireless Personal Area Network (WPAN) Connectivity", on page 4-17 for information.

3.1.5 International Settings Panel

International Settings panel contains controls and settings that allows the CX100 to be configured to use local settings such as units of measure, local time zone and temperature units. International settings can be defined by selecting a preset country or by configuring the settings manually.

See section 4.2.2, "Configuring International Settings", on page 4-3 for information.

3.1.6 Network Software Update panel

The **Network Software Update panel** contains the controls and parameters used to update CX100 software when files have been placed in a network location. See section 4.7, “Updating the Device’s Software”, on page 4-18 for step by step instructions for updating the device’s software.

Table 3-4 Network Software Update Controls and Settings

Control/Setting	Description
Update URL	The Update URL field defines the URL address from where the device will download the software. This URL should be accessible to the device without security restrictions.
Username and Password	A user name and password can be created to secure the device against undesired updates.
Force Software Update	When performing a software update, the device determines if a software load is more current than the software currently installed on the device. If the software load is older, or the same version as the software installed on the device, the system determines that there is not a software update available. Selecting the tick box “ Force Software Update ” causes the device to update software regardless of version time/date information.
Update Soft-key	Pressing the Update soft-key starts the software update procedure. An error message is generated if a configuration error (i.e., does not detect software file) prevents the device from updating software.

3.1.7 USB Software Update Panel

The **USB Software Update panel** is used to update the device when files have been placed on a USB Device. See section 4.7.2.1, “USB Update Procedure”, on page 4-18 for instructions.

Table 3-5 USB Software Update Controls and Settings

Control/Setting	Description
No USB File	When a USB is connected to the device, this field updates to allow the user to select the file on the USB device. This field is disabled until the devices detects a USB device connected to one of the USB connectors .
Force Software Update	When performing a software update, the device determines if a software load is more current than the software currently installed on the device. If the software load is older, or the same version as the software installed on the device, the system determines that there is not a software update available. Selecting the tick box “ Force Software Update ” causes the device to update software regardless of version time/date information.
Update Soft-key	The Update soft-key is enabled when a USB device is detected. Pressing the Update soft-key starts the software update procedure. An error message is generated if a configuration error (i.e., does not detect software file) prevents the device from updating software.

3.1.8 Hardware & Software Revisions Panel

The **Hardware & Software Revisions panel** lists identifying information for major hardware components as well as software version for the device. The following data is key product information that may be required when updating or contacting VIAVI for technical support:

Table 3-6 Hardware & Software Revision Data

Content	Description
Base	Version of software installed in OneExpert platform.
RTS	Version of software installed in CX100 RF Application Module.
Unit ID	Serial number of the OneExpert platform.
Assembly ID	Serial number of the CX100 RF Application Module.
Battery Information	Battery type, serial number, and manufacture date.

3.1.9 Software Options Panel

The **Software Options panel** lists any available software options that are supported on the device with the current base unit and application module configuration. This panel is also used to install or update options on the device. [See section 4.8.3, “Installing Options”, on page 4-20](#) for information.

Table 3-7 Software Options Controls and Settings

Field/Control	Description
Options List	Identifies software options that can be installed on the device.
Activation	Activation status field indicates whether or not the option is enabled or “Upgradeable” (needs to be purchased).
Import from USB Soft-key	This soft-key is enabled when a USB device is connected to the device containing software options which can be installed on the device.

3.1.10 Hardware Options Panel

The **Hardware Options panel** lists any hardware options that are available for the current base unit and application module configuration.

3.1.11 Calibration Screen

The **Calibration panel** lists the device’s calibration files. Content includes the name of the component for which the calibration file applies and the calibration date and time stamp.

3.1.12 Home Screen Settings

The tick boxes on the **Home Screen Settings panel** select the functions that are displayed on the CX100 **Home Screen**. Changes are immediate; the device does not need to be rebooted. See [section 4.2.4.1, “Customizing Home Screen Contents”, on page 4-6](#) for information.

3.1.13 Save Location Settings

The instrument can be configured to automatically save test results, screen captures or other files to a user defined location. The controls and settings on the **Save Location panel** are used to define the location where the device’s file manager saves the files.

The CX100 can be configured to save test results, screen captures, or other files to the device’s file system, a connected USB drive, or both (if applicable).

See [section 4.2.7, “Specifying File Save Location”, on page 4-8](#) for information.

Table 3-8 Save Location Settings

Setting	Description
File System	When File System is selected, files are saved to the device’s internal storage directory. Files are accessed from the File Browser screen .
USB Device	When USB device is selected, files are saved to a USB device that is connected to the device. This selection is only available when a USB device is detected.
Both	When Both is selected, files are saved to a USB device and to the device’s internal storage directory. This selection is only available when a USB device is detected.

3.1.14 Restore Factory Defaults Settings

Restoring factory defaults resets test application settings and system settings (such as brightness, contrast, and volume) to their factory default settings. See section 4.2.1, “Restore Factory Defaults”, on page 4-2 for information.

Table 3-9 Restore Defaults Settings

Setting	Description
Remove All Files Under File Browser	When this tick box is selected, any user files located in the File Browser directories will be deleted as part of the restore factory default process.
Clear International Settings	When this tick box is selected, international settings will be cleared and reset as part of the restore factory default process.

3.1.15 Power Off Screen

The **Power Off panel** allows users to power off or reboot the device from a remote location.



NOTE

If the device is using DHCP network connection, the network may assign a new IP Address when the device is rebooted.

3.1.16 Template Management Screen

The Template Management function is used in conjunction with StrataSync, which is not yet supported on the CX100.

3.1.17 Screen & Power Management

The **Screen & Power Management Screen** contains settings that adjust the brightness of the LED backlight, the backlight timeout and the battery saver timeout. See section 4.2.5, “Configure Device Power Settings”, on page 4-7 for procedures.



NOTES

“Idle time” refers to time during which no keys are pressed and no line activity takes place. If the **Power Off Delay** is set to 5 minutes and a 15 minute test is started, the unit will not power down during the test because there is activity on the line (as a result of the test).

Battery Saving Mode is not applicable when the device is connected to an AC power supply.

Table 3-10 Screen and Power Management Settings

Setting	Description
Backlight	This setting adjusts the brightness setting of the LED’s backlight.
Backlight Timeout	This setting defines the amount of time the device can remain idle before the LED’s backlight turns off.
Power Off Delay	The Power Off Delay setting defines how long the instrument remains idle before the instrument automatically powers itself off when operating on battery power.

3.1.18 Sounds Screen

The **Sounds panel** contains settings that configure the device to emit a chime when the **Power button** is pressed to turn the device on or off. See section 4.2.5.2, “Beep at Power Up/Down”, on page 4-7 for information.

3.1.19 Theme

The **UI Theme panel** contains settings that allow users to change the color scheme of the UI. Changes take effect immediately; the device does not need to be rebooted to apply selection.

3.1.20 User Information

The **User Information panel** contains settings used to identify the technician using the device. Information includes the technician's name and ID as well as the StrataSync account ID. The information entered on this panel is used when synchronizing with the StrataSync server. See section 4.2.6, "User Information", on page 4-7 for information



NOTE

StrataSync is not currently supported on the CX100. Support is planned for future development.

3.1.21 Help

The **Help panel** contains VIAVI contact information: phone number; email and website. Help content can also be accessed by pressing the **Help button** located in the **Utility Tray**.

3.1.22 Notifications

Error messages and user notifications are displayed in the **Utility Tray**. When more than one notification message is displayed, an individual message can be deleted by dragging the message off the screen. Pressing the **Clear All button** deletes all notification messages.

3.1.23 System Network Screen

Network connections are used to update the firmware, transfer files, synchronize to the StrataSync server, or control the instrument's user interface remotely. The device supports wired network and intranet, and WiFi connections.

The device supports IPv4, IPv6 and IPv4/IPv6 Dual Stack network modes of operation. The network controls and settings that are displayed on the screen depend on the **Network Mode** and **Address Mode** that are selected (Static or DHCP).

The device is designed to auto-detect when it is connected to an active network via one of the CX100 **Ethernet connectors**.


3.1.23.1 Accessing System Network Screen

The **Network panel** contains parameters that are used to configure the device for network access. The **Network panel** is accessed by selecting the **Network button** from the **System Menu**.

3.1.23.2 Network Controls and Settings

This section describes the controls and settings used to configure the device’s network connection. See section 4.4, “Establishing a Network Connection”, on page 4-10 for step by step instructions for configuring the device for network access.

Table 3-11 Network Controls and Settings

Control/Setting	Description
Network Mode	<p>Selects the method used to assign IP Addresses to the device.</p> <ul style="list-style-type: none"> • IPv4: uses 32-Bit, numeric IP addressing method • IPv6: uses 128-Bit, alphanumeric IP addressing method. • IPv4 and IPv6: uses both addressing methods
IP Address Mode	<p>Selects whether the device connects to the network using a DHCP or Static IP Address.</p> <p>Dynamic Host Configuration Protocol (DHCP)</p> <p>The server of the network to which the device is connecting assigns network uplink IP address, netmask, gateway, and DNS.</p> <p>Static</p> <p>Static mode is used to manually define network IP connections.</p>
<p> NOTE</p> <p>Improperly configuring a static IP address could cause conflicts on your network server. VIAVI recommends contacting your network administrator before configuring the device to use a static IP address.</p>	
IP Address	Address assigned to the device. Format is determined by select Network mode.
Netmask	Netmask Address assigned to the device determines whether the packets are to be routed to other networks or subnetworks.
Gateway	The address for the gateway that is used to route packets that are not on the same subnet.
DNS Server	The address of the Domain Name System (DNS) Server.
Network On/Off Soft-key	Enables or disables network connection using defined settings. Network connectivity can also be enabled or disables using the Network button located in the Utility Tray .

3.1.23.3 IPv4/IPv6 Dual Stack Network Mode Settings

Table 3-12 IPv4/IPv6 Dual Stack Network Controls and Settings

IPv4 Address Mode	Setting
DHCP	No additional settings.
Static	See section 3.1.23.4, “IPv4 Network Mode Settings”, on page 3-15.
Stateless	See section 3.1.23.5, “IPv6 Network Mode Settings”, on page 3-16.

3.1.23.4 IPv4 Network Mode Settings

Table 3-13 IPv4 Network Controls and Settings

IPv4 Address Mode	Setting
Static	IPv4 Address
	<ul style="list-style-type: none"> Enter the device’s IP address (which will be used when accessing the provider network).
	IPv4 Netmask
	<ul style="list-style-type: none"> Enter the netmask address to indicate whether the packets are to be routed to other networks or subnetworks.
Shared	IPv4 Gateway
	<ul style="list-style-type: none"> Enter the address for the gateway that is used to route packets that are not on the same subnet.
	IPv4 DNS Server
	<ul style="list-style-type: none"> Enter the address of the DNS server.
	Share the IP from another interface (for multi interface mode).

3.1.23.5 IPv6 Network Mode Settings

Table 3-14 IPv6 Network Controls and Settings

IPv6 Address Mode	Setting
DHCPv6	No additional settings.
Stateless	IPv6 DNS Address Mode <ul style="list-style-type: none">DHCPv6: <i>no additional settings to specify.</i>Manual: specify the IPv6 DNS Server address. IPv6 DNS Server <ul style="list-style-type: none">Enter the address of the DNS server.
Static	IPv6 Global Address <ul style="list-style-type: none">Enter the device's IPv6 address to access the global network. IPv6 Local Address <ul style="list-style-type: none">Manual: Enter the IPv6 Local Address.Automatic: Address is populated automatically. IPv6 Subnet Prefix Length <ul style="list-style-type: none">Enter the subnet prefix length. IPv6 Gateway <ul style="list-style-type: none">Enter the address for the gateway that is used to route packets that are not on the same subnet. IPv6 DNS Address Mode <ul style="list-style-type: none">DHCPv6: no additional settings to specify.Manual: Enter the IPv6 DNS Server address. IPv6 DNS Server <ul style="list-style-type: none">Enter the address of the DNS server.

3.1.24 Web Browser

The CX100 web browser works in the same manner as a computer or smart device. When the CX100 is connected to a network, the web browser can be used to perform maintenance procedures such as update software, enable options or access additional product documentation on the VIAVI website.

The **Edit** and **Delete Bookmark soft-keys** are used to modify or delete any defined bookmarks.

See [section 4.12, “Customizing the Web Browser”](#), on page 4-22 for information about configuring the Web Browser.

3.1.25 File Browser

The **File Browser** is used to navigate and manage contents of the device’s internal directories or contents of a USB device (when one is attached to the device). The **File Browser panel** is used to copy files to and from the device. See [section 7.2, “Managing Files”](#), on page 7-4 for detailed instructions.

3.1.25.1 File Options Soft-key

The **File Options soft-key** accesses controls for copying, editing and transferring files to and from the device.



NOTE

Functions such as copy, cut, paste and delete are not available for system files.

3.1.25.2 Copy, Cut and Paste File Options

Copy, Cut and Paste options allow user created files to be moved from one file location to another within the device’s file storage system.

3.1.25.3 Upload FTP/HTTP

The CX100 supports Hyper Text Transfer Protocol (HTTP) and File Transfer Protocol (FTP) for transferring files to and from the device. See [section 7.2.6, “Uploading Files Using FTP/HTTP”](#), on page 7-6 for instructions.

3.1.25.4 Copy to USB

Copy to USB is enabled when the CX100 detects a USB device connection. Selecting this button copies selected file(s) to the attached USB device.

When 2 USB devices are connected to the device, the CX100 defaults to the USB device connected to USB 1 Connector.

3.1.25.5 Send to Android Device (WPAN)

When the device is connected to an Android device via WPAN®, files can be transferred directly from the CX100 to the Android device.

3.1.25.6 Show Hidden Files

The CX100 allows users to configure files as “hidden” in order to protect important files from being accidentally deleted. Selecting the **Show Hidden Files** check box displays all hidden files on the device.

3.1.25.7 Rename Soft-key

Pressing the **Rename soft-key** opens a pop-up window that allows users to rename a saved file.testfile.png. The new file name takes effect immediately when entered; no confirmation requested.

3.1.25.8 Delete Soft-key

Pressing the **Delete soft-key** deletes the selected file or directory. A prompt will be displayed prior to deleting files to help prevent users from unintentionally deleting files.

3.1.25.9 Open Soft-key

Pressing the **Open soft-key** opens the selected file or directory.

3.1.26 USB File Browser

The **USB File Browser button** is populated when a USB device is connected to the test set. Pressing the button opens a window which access the contents of the USB device.

[Chapter 7 “Managing Files and Reports”](#) for related information.

3.2 Utility Functions

Utility functions allow the user to perform tasks on the device more conveniently. For example, users can view saved test reports on the device using the View Reports function, or the user can enable a network connection from the **Utility Tray** instead of navigating through menus to the Network Screen.

3.2.1 Accessing Utility Functions

To Open the Utility Tray

1. Press the **Tray button** located on the device's front panel.
- OR -
2. Swipe/pull downward on the **Tray soft-key** located at the top of the UI.

See section 1.4.7, "Utility Tray Button", on page 1-6 for button locations.




Figure 3-2 CX100 Utility Tray - Example

3.2.2 Save Report Button

The **Save Report button** allows you to create reports based on the configuration settings and test results for the currently active test. See section 7.1.3, "Saving a Report", on page 7-3 for details.

3.2.3 View Report

Saved reports can be viewed on the device using the View Report button. See section 7.1.4, “Viewing a Report”, on page 7-4 for details.



NOTE

The View Report button is disabled when there are no reports saved on the device.

3.2.4 Screen Shot

The CX100 provides users with the ability to capture screen shots of content actively displayed on the UI. This function would be useful for capturing shots of signal traces or constellation plots. See section 4.9, “Capturing a Screen Shot”, on page 4-21 for details.

3.2.5 Network Button

The **Network button** is used to enable or disable network connectivity. The **Network button** turns green when network connectivity is enabled. Network connections are configured on the Network Screen. See section 4.4.1, “Establishing an Ethernet Connection”, on page 4-10 for detailed instructions.

3.2.6 Wireless Personal Area Network (WPAN)® Button

The **WPAN® button** is used to enable or disable WPAN capability. The button turns green when Wireless Personal Area Network is enabled. WPAN connections are configured on the **WPAN panel**. See section 4.6, “Establishing a Wireless Personal Area Network (WPAN) Connection”, on page 4-17 for detailed instructions.

3.2.7 Volume Button

The **Volume button** opens a panel that contains settings that control the device’s volume. Changing this setting does not affect the volume of the power button chime setting. See section 3.1.18, “Sounds Screen”, on page 3-12 for information about the power chime.

3.2.8 Help

The **Help button** opens a panel that contains VIAVI contact information: phone number; email and website. Help content can also be accessed by pressing the **Help button** located in the **System Settings menu**.

3.2.9 Tutorial

The **Tutorial function** is used in conjunction with StrataSync which is not yet supported on the CX100.

3.2.10 Workflow Manager

Workflow Management function is used in conjunction with StrataSync which is not yet supported on the CX100.

3.2.11 Templates

The **Template function** is used in conjunction with StrataSync which is not yet supported on the CX100.1

This page intentionally left blank.

Configuring System Settings

This chapter provides step by step instructions for performing the following:

- [Locating Device's Unit ID](#) 4-2
- [Configuring Device Settings](#) 4-2
- [Configuring 10 MHz Frequency Reference](#) 4-9
- [Establishing a Network Connection](#) 4-10
- [Remotely Operating the Device](#) 4-16
- [Establishing a Wireless Personal Area Network \(WPAN\) Connection](#) 4-17
- [Updating the Device's Software](#) 4-18
- [Hardware/Software Versions and Options](#) 4-20
- [Capturing a Screen Shot](#) 4-21
- [Enabling Password Protection](#) 4-21
- [Creating UI Shortcut](#) 4-21
- [Customizing the Web Browser](#) 4-22

See [Chapter 3 "System and Utility Function Descriptions"](#) for detailed descriptions of the system settings and parameters.

4.1 Locating Device's Unit ID

The CX100's unit identifier (ID) is located on the **Hardware & Software Revisions panel**. See section 4.8.1, "Viewing Hardware/Software Revision Information", on page 4-20 for information. The Unit ID number matches the unit serial number on the product's label.

4.2 Configuring Device Settings

This section provides instructions for configuring the device's system settings. See Chapter 3 "System and Utility Function Descriptions" for detailed descriptions of the functions.

4.2.1 Restore Factory Defaults

The following procedure describes how to reset the CX100 to factory default settings.



NOTE

Restoring factory defaults resets test application settings and system settings (such as remote and VNC settings, brightness, contrast, and volume), and powers down the unit.

To Restore Factory Default Settings

1. Navigate to the **Restore Factory Settings** panel (System Settings > Restore Factory Defaults).
2. At prompt, select any additional action(s) to be performed.
3. Press the **OK button** to continue.
4. Press the **Reboot button** to acknowledge the information in the prompt and to restore the device to factory default settings.
5. Reboot the device to activate the default settings.

4.2.2 Configuring International Settings

4.2.2.1 Preset International Settings

To Select Preset Country Settings

1. Navigate to the **International Settings panel** (Systems Settings > International Settings).
2. Select the **Country button** to open the preset country list. Select the desired preset country from the list. When a preset country is selected, the system automatically configures the remaining International Settings to selections appropriate for the selected country.
3. A user prompt window is displayed notifying the user that the device must be rebooted to apply the settings. Select the **OK button** to continue.
4. Reboot the device (turn off the power, then turn it back on).
5. The international settings are configured and the user interface is localized.

4.2.2.2 Manually Configure International Settings

To Manually Configure International Settings

1. Navigate to the **International Settings panel** (Systems Settings > International Settings).
2. If desired, select a preset country that has settings closest to desired settings.
3. The system will display a user prompt window indicating the device must be rebooted in order for the new settings to be applied.
4. Press the **OK button** to continue.
5. Change additional settings as desired, selecting the **OK button** at each prompt to continue configuring settings.
6. Press the **Back function key** to exit the menu.
7. When all settings have been configured as desired, reboot the device to apply all changes.

4.2.3 Setting Date and Time

The CX100 contains an internal clock that can be set to provide accurate time stamps for test results.



NOTE

Time Synchronization must be set to None in order to edit Time and Date settings.

4.2.3.1 To Set the Time

To Set the Device's Clock

1. Navigate to the **Date and Time panel** (System Settings > Date and Time).
2. Select the **Time button**.
3. Adjust the dials to select the hour, minutes, and AM or PM.
4. Press the **OK button** to apply the selected time.

4.2.3.2 Set the Date

To Set the Device's Calendar

1. Navigate to the **Date and Time panel** (System Settings > Date and Time).
2. Select the **Date button**.
3. Use the arrows to set the month and year.
4. Select the day on the calendar.
5. Press the **Set button** to apply the selected date.

4.2.3.3 Select Date Format

To Select the Date Format

1. Navigate to the **Date and Time panel** (System Settings > Date and Time).
2. Select the **Date Format button**.
3. Select **MM/DD/YYYY** or **DD/MM/YYYY** format. Change is applied at time of selection.

4.2.3.4 Select Time Format

To Select the Time Format

1. Navigate to the **Date and Time panel** (System Settings > Date and Time).
2. Select the **Time Format button**.
3. Select **12 Hour** or **24 Hour**. Change is applied at time of selection.

4.2.3.5 Select Time Zone

To Select the Time Zone

1. Navigate to the **Date and Time panel** (System Settings > Date and Time).
2. Select the **Time Zone button**.
3. Select the desired time zone.



NOTE

If Daylight Savings Time (DST) is used in your area, select the **DST Used** check box to enable DST. A check mark indicates DST is enabled.

4.2.3.6 Time Synchronization

1. Navigate to the **Date and Time panel** (System Settings > Date and Time).
2. Select the desired setting for Time Synchronization (**None or NTP**).
3. If **NTP** is selected, specify the following NTP Parameters:
 - **NTP Server Address type** (IPv4 Address, IPv6 Address, DNS Name)
 - **NTP Server** (the address of the server where the device gets the time, for example 0.us.pool.ntp.org)
4. The **NTP Synchronization State button** indicates if the device has synchronized with the NTP server.
5. The date and time are set. Press the **Back button** to exit the menu.

4.2.4 Change Display Content and Settings

The CX100 UI can be configured according to user preferences and requirements.

4.2.4.1 Customizing Home Screen Contents

To Change Home Screen Content

1. Navigate to the **Home Screen Settings panel** (Systems Settings > Home Screen).
2. Enable or disable the functions you want listed on the device's **Home screen**. Changes are immediate, does not require device reboot.
3. Press the **Back Arrow** to return to the **System Settings panel**.
4. Press the **Home button** to return to the **Home screen**.
5. The new **Home screen** settings will be saved and applied for future use.

4.2.4.2 Configure Backlight Brightness

To Change Brightness of LCD Display

1. Navigate to the **Screen & Power Management panel** (System Settings > Screen & Power Management button).
2. Select the **Backlight button**.
3. Use the +/- buttons or the vertical slider to adjust the brightness to the desired setting.
4. Press the **OK button** to apply new setting.



NOTE

Use the back arrow to exit without applying a new value.

4.2.4.3 Configure Backlight Timeout

To Change Display Timeout

1. Navigate to the **Screen & Power Management panel** (System Settings > Screen & Power Management button).
2. Select the **Backlight Timeout button**.
3. Select the amount of time to wait before the backlight dims. The new setting is applied when selected.

4.2.5 Configure Device Power Settings

4.2.5.1 Battery Saving Mode

To Set the Power Off Delay

1. Navigate to the **Screen & Power Management panel** (System Settings > Screen & Power Management button).
2. Select the **Power Off Delay button**.
3. Select the amount of idle time to wait before the device automatically powers itself off. The new setting is applied when selected.

4.2.5.2 Beep at Power Up/Down

To Power Up/Down Beep

1. Open the **Sound Settings panel**.
2. Select the **Play Chime on Power Up/Down tick box**.
3. Select the **Power Up/Down Chime Volume** field to adjust volume of the chime to the desired volume.
4. Press the **OK button** to confirm.



NOTE

Change takes effect immediately; the device does not need to be rebooted to apply the change.

4.2.6 User Information

The User Information menu allows users to enter operator information such as the technician's name and ID.

To Specify User Information

1. Navigate to the **User Information** (System Settings > User Information).
2. Enter the desired user information.
3. Press the **Back button** to exit the menu.

4.2.7 Specifying File Save Location

The CX100 can be configured to save test results, screen captures, or other files to the device's file system, a connected USB drive, or both (if applicable).

To Specify Location for Saved Files

1. Navigate to the **Save Location panel** (System Settings > Save Location button).
2. Select the location to which files should be saved.
 - Filesystem
 - USB Device
 - Both (when applicable)
3. Press the **Back button** to exit the menu. Files will be saved to the location (and/or device) specified.

4.2.8 Setting the Volume

The device's volume is adjusted selecting the Volume button from the Utility Tray.

To Adjust Volume Settings

1. Open the **Utility Tray**.
2. Select the **Volume button**.
3. Use the +/- buttons or the vertical slider to adjust the volume to the desired setting.
4. Press the **OK button** to apply new setting. Use the **Back arrow** to exit without applying a new value.
5. Press the **Back button** to exit the menu. The volume is set on the device.

4.3 Configuring 10 MHz Frequency Reference

To Configure CX100 to Use External 10 MHz Frequency Reference

1. Connect a valid 10 MHz frequency reference to the CX100 **10 MHz Frequency Reference I/O connector**.
2. Power on the CX100.
3. Open the **RF Instrument Menu**.
4. Select the **Freq Reference button**.
5. Select **External** from the configuration window.
6. Press the **OK button** to confirm and close the configuration window.

To Configure CX100 as a 10 MHz Frequency Reference Source

1. Connect a 10 MHz frequency reference cable to the CX100 **10 MHz Frequency Reference I/O connector**.
2. Connect the other end to external device.
3. Power on the CX100.
4. Open the **RF Instrument Menu**.
5. Select the **Freq Reference button**.
6. Select **Internal** from the configuration window.
7. Press **OK button** to confirm and close the configuration window.

4.4 Establishing a Network Connection

4.4.1 Establishing an Ethernet Connection



NOTE

When the device is configured for DHCP mode, network information is likely to change when the device is connected, then reconnected to a network. If your procedure requires a known IP, configure the device for Static IP network mode of operation. Wireless Personal Area Network (WPAN) and WiFi interfaces cannot be ON at the same time.

4.4.1.1 Enable Network Connectivity

Network connectivity must be enabled in order to establish a connection to an Ethernet or WiFi network.

To Enable Network Connectivity

1. Open the **Utility Tray**.
2. Select the **Network button**.
3. The button turns green when network connectivity is enabled.

4.4.1.2 Establishing an Ethernet Connection

To Establish an Ethernet Connection to the Device

1. Enable network connectivity on the CX100. [See section 4.4.1.1, “Enable Network Connectivity”, on page 4-10](#) for information.
2. Connect one end of the ethernet cable to one of the CX100's **Ethernet connectors**.
3. Connect the other end of the ethernet cable to an active LAN.
4. Navigate to the **Network panel** (System Settings > Network).
5. Select the **Ethernet button** at the bottom of the screen.
6. The UI updates to show parameters necessary to connect to a LAN.
7. Select **Network Mode button** to display available network mode options.
8. Select desired **Network mode**.

9. Additional settings are required based on the selected **Network Mode** of operation. See one of the appropriate sections to configure the device's IP settings to match the LAN settings:

- See section 4.4.2, "Establishing a WiFi Connection", on page 4-13.
- See section 4.4.1.2.2, "IPv4 Network Mode Settings", on page 4-11.
- See section 4.4.1.2.3, "IPv6 Network Mode Settings", on page 4-12.

4.4.1.2.1 IPv4/IPv6 Dual Stack Network Mode Settings

IP Dual Stack Address Modes	Setting
DHCP	No additional settings
Static	See section 4.4.1.2.2, "IPv4 Network Mode Settings", on page 4-11.
Stateless	See section 4.4.1.2.3, "IPv6 Network Mode Settings", on page 4-12

When all settings have been configured, select the **Network On/Off soft-key** to enable network connectivity. The device establishes an Ethernet connection to the LAN.

4.4.1.2.2 IPv4 Network Mode Settings

IPv4 Address Mode	Setting
DHCP	No additional settings.
Static	IPv4 Address <ul style="list-style-type: none"> • Enter the device's IP address (which will be used when accessing the provider network).
	IPv4 Netmask <ul style="list-style-type: none"> • Enter the netmask address to indicate whether the packets are to be routed to other networks or subnetworks.
	IPv4 Gateway <ul style="list-style-type: none"> • Enter the address for the gateway that is used to route packets that are not on the same subnet.
	IPv4 DNS Server <ul style="list-style-type: none"> • Enter the address of the DNS server.
Shared	Share the IP from another interface (for multi interface mode).

When all settings have been configured, select the **Network On/Off soft-key** to enable network connectivity. The device establishes an Ethernet connection to the LAN.

4.4.1.2.3 IPv6 Network Mode Settings

IPv6 Address Mode	Setting
DHCPv6	No additional settings.
Stateless	IPv6 DNS Address Mode <ul style="list-style-type: none">DHCPv6: <i>no additional settings to specify.</i>Manual: specify the IPv6 DNS Server address.
	IPv6 DNS Server <ul style="list-style-type: none">Enter the address of the DNS server.
Static	IPv6 Global Address <ul style="list-style-type: none">Enter the device's IPv6 address to access the global network.
	IPv6 Local Address <ul style="list-style-type: none">Manual: Enter the IPv6 Local Address.Automatic: Address is populated automatically.
	IPv6 Subnet Prefix Length <ul style="list-style-type: none">Enter the subnet prefix length.
	IPv6 Gateway <ul style="list-style-type: none">Enter the address for the gateway that is used to route packets that are not on the same subnet.
	IPv6 DNS Address Mode <ul style="list-style-type: none">DHCPv6: no additional settings to specify.Manual: Enter the IPv6 DNS Server address.
	IPv6 DNS Server <ul style="list-style-type: none">Enter the address of the DNS server.

When all settings have been configured, select the **Network ON/Off soft-key** to enable network connectivity. The device establishes an ethernet connection to the LAN.

4.4.2 Establishing a WiFi Connection

The WiFi option allows the device to be connection to a wireless network to export reports, screen shots, or job tickets (using FTP), or update the device's firmware.



NOTE

The CX100 supports 2.4 GHz and 5 GHz WiFi.

4.4.2.1 Adding a WiFi Network Profile

The CX100 can save up to 32 WiFi network profiles. If an access point does not broadcast a Service Set Identifier (SSID), a WiFi profile can be created manually. The device will save the profile, then automatically authenticate and establish a connection to the network when the following conditions are met:

- Network connectivity is enabled.
- The network's access point is in range.
- The network is determined to provide the best available access point (based on signal strength and/or encryption supported).



NOTE

The CX100 automatically saves a WiFi network profile after successfully connecting to the WiFi network.

To Add a WiFi Network Profile

1. Enable network connectivity on the CX100. [See section 4.4.1.1, "Enable Network Connectivity", on page 4-10](#) for information.
2. Navigate to the **Network panel** (System button > Network button). The **System Network menu** appears.
3. Select the **WiFi button** located on the soft-key panel. The device immediately scans for WiFi networks and lists each network as an item.
4. Select **Add Network**. The Add WiFi Network controls and settings are displayed.
5. Specify the following settings:

Setting	Value
SSID	The SSID (Service Set Identifier) of the WiFi network.
Password	The password required to authenticate to the network. A password is not required if Key Management is set to None.

Setting	Value
Key Management	Select the Wi-Fi Protected Access (WPA) key management.
Network Mode	Select the Network Mode.
	Additional settings are required based on the selected Network Mode of operation. See the appropriate section to complete network configuration:
	See section 4.4.1.2.2, “IPv4 Network Mode Settings”, on page 4-11.
	See section 4.4.1.2.3, “IPv6 Network Mode Settings”, on page 4-12.
	See section 4.4.1.2.1, “IPv4/IPv6 Dual Stack Network Mode Settings”, on page 4-11.

6. Return to the **System Network panel**. The network profile just created now appears on the list.

4.4.2.2 Connecting to a WiFi Network

The CX100 can be connected to any compatible WiFi network within range of the device for which you have authorized access (and a password for authentication).

To Connect to a WiFi Network

1. Enable network connectivity on the CX100. [See section 4.4.1.1, “Enable Network Connectivity”, on page 4-10](#) for information.
2. Navigate to the **Network panel** (System button > Network button).
3. Select the **WiFi button** located on the soft-key panel.
4. The device automatically scans for WiFi networks and lists each network with the following status:

A lock	Indicates authentication is required to connect to a network.
Saved, In Range	Indicates that a profile for the network has been saved on the device, device is in range of the network and a connection can be established to the device.
Saved, Out of Range	Indicates that a profile for the network has been saved on the device, but the network is out of range and therefore, a connection cannot be established.
Incompatible	Indicates that a connection cannot be established to a network.
Connected	Indicates that the device has established a connection to the network.

The device automatically connects to the network determined to provide the best available access point (based on signal strength and/or encryption supported).

To Connect to a Different WiFi network

1. Select the SSID of the WiFi network.
2. Configure the advanced settings (profile settings), forget a saved network, or connect to the network.
3. Select the **Connect button**.
 - Messages appear briefly indicating that the device is performing a four-way handshake, then authenticating to the network.
 - The status of the connection (Network Up) and details concerning the connection (IP address, netmask, gateway, and DNS server) appear at the top right of the menu.

The device is connected to the WiFi network.

4.5 Remotely Operating the Device

The CX100 remote operation controls and settings allows users to access the CX100 from a computer (desktop or laptop) using a virtual network connection (VNC).

Establishing a VNC connection with the CX100 requires the following:

- A VNC viewing application must be installed on the computer.
- CX100 and computer must be connected to the same network.
- IP address of the CX100.

4.5.1 Establishing VNC Viewer Connection

To View the Device UI Remotely

1. Configure the CX100 for network access. [See section 4.4.1, “Establishing an Ethernet Connection”, on page 4-10](#) for information.
2. Enable VNC capability:
 - a Open the **System Settings Menu**.
 - b Select the **Remote Operation button**.
 - c Select the **VNC button**.
 - d Select the **Enable VNC Server check box**.
 - e Define a **VNC password** (recommended).
 - f Select the **Back button** to return to previous content.
3. Launch the VNC viewing application on the computer.
4. Enter the CX100’s IP address in the VNC viewer’s server address field. Select the OK button to continue.
5. A password entry box appears.
6. Enter the VNC password (found on the Remote Operation menu) and select the **OK button**. The CX100 user interface appears in the VNC viewer.

4.5.1.1 VNC Viewer Connection Failure

If the VNC viewing applications fails to connect to the CX100 and the message “Failed to connect to server” appears, the VNC viewer was not able to communicate with the CX100.

- Verify the IP Address is correct.
- From the computer, ping the CX100 IP address to verify the network link is working. If the link is not working, restart the CX100 and repeat step 3 through step 6.

4.5.2 Ending a Remote Operation Session

To end a remote operation session, close the VNC viewing window on the PC/ laptop.

4.6 Establishing a Wireless Personal Area Network (WPAN) Connection

The WPAN® option allows communication with a paired mobile device or SmartID+.

4.6.1 Enabling Wireless Personal Area Network (WPAN) Connectivity

WPAN functionality must be enabled on the device before a WPAN connection can be established.

To Enable WPAN Connectivity

1. Navigate to the **WPAN panel** (System Settings > WPAN button).
2. **Select the tick box** to enable WPAN.
3. WPAN connectivity is enabled.



NOTE: Wireless Personal Area Network (WPAN) and WiFi interfaces cannot be ON at the same time.

4.6.2 Connecting to a Wireless Personal Area Network (WPAN) Device

The CX100 can be connected to any WPAN device (for which you have authorized access) that is within range of the device.

To Establish a WPAN Connection

1. Enable WPAN on the CX100.
2. Select **Scan for devices button**. The CX100 scans for WPAN devices; located devices are listed on the menu.
3. **Select the device from the menu** that you wish to connect to:
 - If the CX100 successfully authenticates to the device, a message appears indicating that pairing was successful.
 - If the CX100 does not successfully authenticate to the device, a message appears indicating that pairing failed.
4. If pairing was successful, the CX100 can be used with the paired device.

4.7 Updating the Device's Software

4.7.1 Software Availability

Refer to the CX100 product support Web page or contact VIAVI to verify your CX100 contains the most recent software version available.

Software can be downloaded from the product's web page directly to the test set via a network update or the software can be copied to a USB device and updated using the USB update procedure.

[Add link to CX100 web page when available.](#)

4.7.2 Methods of Updating Software

CX100 firmware can be upgraded in the field using one of the following methods:

- Wired network or intranet connection
- WiFi connection
- USB device
- CD-ROM (see note below)



NOTE

Due to security concerns, some customers are not permitted to download software from a public web site. In such cases, software updates are available via CD distribution. Contact Customer Support for information about the availability of software updates in CD format.

4.7.2.1 USB Update Procedure



NOTE

Disconnect Ethernet cable connections before proceeding with this procedure.

To Update the Device - Software Source - USB Device

1. Navigate to the VIAVI product support Web page and download software to a USB device.
2. Connect the CX100 to an AC power supply ensure an uninterrupted supply of power during the update. [See section 2.2.1, "AC Power Operation", on page 2-6](#) for information.

3. Connect the USB device to one of the CX100's **USB connectors**. The device will auto-detect the USB drive.



NOTE

If performing a CD-ROM update, connect the USB to CD-ROM device to one of the CX100's USB connectors and insert the software CD in the CD-ROM device.

4. Navigate to the **USB Software Update panel** (System Settings > USB Software Update).
5. Select the desired firmware file on the USB drive.
6. Select the **Force Software Update check box**.
7. Press the **Update button** to start the upgrade. At prompt, press **Update button** again to confirm.

4.7.2.2 Network Update Procedure

To Update the Device - Software Source - Network Directory

1. Connect the CX100 to an AC power supply to ensure an uninterrupted supply of power during the update. [See section 2.2.1, "AC Power Operation", on page 2-6](#) for information.
2. Establish a network connection. [See section 4.4, "Establishing a Network Connection", on page 4-10](#) for information.
3. Navigate to the **Network Software Update** panel (System Settings > Network Software Update).
4. Select **Update URL** and enter URL from which to download the software (i.e., VIAVI website, internal FTP to which software has been uploaded).
5. Enter user credentials (User name and Password). Select the **Update soft-key**.

4.8 Hardware/Software Versions and Options

4.8.1 Viewing Hardware/Software Revision Information

To View Hardware Revision Information

1. Navigate to the **System Settings** menu.
2. Select the **Hardware/Software Revisions** button. The revisions of the internal components and the software versions is displayed.

4.8.2 Viewing Option Information

To View Hardware or Software Revision Information

1. Navigate to the **System Settings** menu.
2. Select the **Software Options** button or **Hardware Options** button.
A list of available options appears with the status for each option.
 - Enabled: option has been enabled on the device.
 - Upgradeable: option has not yet been purchased/enabled on the device.

4.8.3 Installing Options

This section contains instructions for installing options on the device.

To Install Options from USB

1. Before installing options, upgrade the device to the latest firmware. [See section 4.7, “Updating the Device’s Software”, on page 4-18](#) for information.
2. Copy the option file to a USB device.
3. Connect the USB device to one of the CX100’s **USB connectors**.



NOTE

If performing a CD update, connect the USB to CD-ROM device to one of the CX100’s USB connectors and insert software CD in the CD-ROM.

4. Navigate to the **Software Options** panel (System Settings > Software Options).
5. Select the **Import from USB** soft-key.
6. Select the desired firmware file on the USB drive.
7. Press the **Update** button to start the upgrade. At prompt, confirm the update.
8. Reboot the device. The option is installed.

4.9 Capturing a Screen Shot

To capture an image of the current screen.

To Capture a Screen Shot

1. Access the **Utility Tray** and then select the **Screen Shot button**.
2. Enter a name for the screen shot.
3. The PNG file is saved to the internal file manager.

To Capture the Utility Tray or a Popup Menu

To capture a screen shot of only the **Utility Tray**, or to capture a popup menu, press and hold the **Utility Tray button** for 5 seconds.

4.10 Enabling Password Protection

To Turn on Password Protection

1. Navigate to the **System Settings menu**.
2. Select the **Password Protection button**.
3. Select the **Allow editing** and **Enable Password Protection as necessary**.
4. Press the **Back button** to save and exit the menu.

4.11 Creating UI Shortcut

To add a function to the Shortcut Menu:

1. Navigate to **Home screen**.
2. Select the function button that you want to create a shortcut for.
3. Drag and drop the function button to shortcut area.

4.12 Customizing the Web Browser

To Create a Home Page

1. Open the CX100 **Web Browser** and navigate to the web page that is going to be used as the home page.
2. Press the field located below the Home Page text on the Web Browser Configuration window. If a home page has not yet been created, this field will be labeled “Not set.”
3. Confirm the page URL is correct and if desired, modify the bookmark title.
4. Press the **OK button** to confirm and create the bookmark.

To Add a Bookmark

1. Open the CX100 **Web Browser** and navigate to the web page for which the bookmark will be created.
2. Press the **Bookmarks soft-key**.
3. Press the **Add Bookmark soft-key**.
4. Confirm the page URL is correct and if desired, modify the bookmark title.
5. Press the **OK button** to confirm and create the bookmark.

RF Instrument Function Descriptions

This chapter provides an overview of the CX100 RF Instrument functions. This chapter reviews the following functions:

- [Overview of the RF Instrument](#) 5-2
- [RF Test](#) 5-3
- [Spectrum Analyzer](#) 5-50
- [VSWR/DTF](#) 5-59
- [Autotest Function](#) 5-71
- [SCA Capability](#) 5-75
- [Settings](#) 5-76


See [Chapter 6 “Performing Tests and Measurements”](#) for step by step instructions for configuring basic test functions and for performing test and measurements.

5.1 Overview of the RF Instrument

The RF Instrument Application contains the following test and measurement functions:

- RF Test
- Spectrum Analyzer
- VSWR/DTF
- AutoTest


RF Test Function



RF Test provides the functions necessary to evaluate performance parameters such as a radio's transmit power or receive sensitivity. RF Test supports three modes of operation: Duplex Test, Tx Test and Rx Test. Each mode of operation provides the generate and/or receive functions necessary to support the capabilities supported in the selected mode of operation.

[See section 5.2, "RF Test", on page 5-3](#) for a description of this function.

Spectrum Analyzer Function



The Spectrum Analyzer provides the functions necessary to measure various performance characteristics of an applied (incoming) signal across the full frequency range of the CX100. The Spectrum Analyzer can be used to evaluate performance parameters such as power, harmonics, spurious, sidebands and phase noise of a DUT.

[See section 5.3, "Spectrum Analyzer", on page 5-50](#) for a description of this function.


VSWR/DTF Function



The VSWR/DTF application provides the functions necessary to isolate and troubleshoot cable and network issues or failures.

[See section 5.4, "VSWR/DTF", on page 5-59](#) for a description of this function.


AutoTest Function



Autotest provides an interface to load and run automated test scripts. Users can review data while a test is in progress and save test results for later evaluation. Autotest also allows the user to enable an SCA (Software Communications Architecture) interface on the device.

[See section 5.5, "Autotest Function", on page 5-71](#) for a description of this function.

(RF Instrument) Settings



The Settings button accesses controls and settings that are specific to RF Instrument functions. [See section 5.7, "Settings", on page 5-76](#) for a description of these controls and settings.

5.2 RF Test

RF Test contains a variety of generator and receiver functions which can be used to evaluate the performance of a device under test (DUT). The availability of the functions is determined by the selected test mode of operation. The tabs located at the top of the **RF Test screen** are used to select the mode of operation. [Figure 5-1](#) shows the default view of each of the RF Test mode screens.




Figure 5-1 RF Test Mode Menus

5.2.1 RF Test Modes of Operation

Each RF Test mode supports functions specific to the selected mode of operation. For example, Rx Test Mode contains parameters necessary to test the receive performance of the DUT. [Figure 5-1](#) provides a visual reference to the functions supported in each mode of operation.

Duplex Test Mode

Duplex Test mode supports full duplex capabilities, providing simultaneous access to both RF Generator and RF Receiver functions. Duplex mode would typically be used to test radios that are capable of duplex operation.

Tx Test Mode

Tx (Transmit) Test mode provides access to the instrument's RF Receiver functions. Tx Test Mode could be used to evaluate radios that are only capable of transmit operation.

Rx Test Mode

Rx (Receive) Test mode provides access to the instrument's RF Generator functions. Rx Test mode could be used to evaluate radios that are only capable of receive operation.

5.2.2 Test Setup Summary Panel

The **Test Setup Summary panel** displays data for generator and receiver functions that are currently active (turned ON). The panel provides quick reference to generator and receiver settings as well as meter readings.

The **Test Setup Summary panel** is ideal for monitoring a test without jumping back and forth between function panels.



Figure 5-2 RF Test Setup Summary Panel



NOTE

The **Test Setup Summary panel** does not display information for plot or analyzer functions.

5.2.3 RF Generator

The CX100 RF Generator provides users with a signal source with known parameters. The RF Generator can be used to evaluate the receive performance of the Device Under Test (DUT). The CX100's internal modulation generators can be used in conjunction with the RF Generator to output modulated signals.

5.2.3.1 RF Generator Controls and Settings

The following controls and settings are used to configure the characteristics of the generated RF signal:

Table 5-1 RF Generator Controls and Settings



Control/Setting	Description
Port	<p>This menu selects the RF Generator output connector.</p> <ul style="list-style-type: none"> The DUPLEX connector should be selected as the RF output connector when the lowest level of RF Generator output is needed. The ANT/SWR connector should be selected as the RF output connector to output high power RF signals.
 NOTE	<p>When the ANT/SWR connector is selected as the RF output connector, the system disables the connector's receive capabilities.</p>
Frequency	<p>This field defines the frequency of the RF Generator signal. The RF Generator Frequency should be set to a value appropriate for the test being performed and to the receive frequency range of the DUT.</p>
Frequency Offset Field	<p>Frequency Offset is only supported in Duplex Test Mode. The Frequency Offset field defines the amount by which the RF Generator frequency is shifted when the signal is produced. A frequency offset may be applied to an RF signal to reduce possible interference with other transmitters, or to remove phase noise when performing certain types of measurements. The Frequency Offset field is disabled when the Offset soft-key is set to OFF.</p> <p>When the Offset soft-key is set to ON the following occurs:</p> <ul style="list-style-type: none"> The Frequency Offset field updates to an editable field. The Frequency field updates to a ready only field. <p>When a frequency offset value is entered, the RF Generator Frequency field updates to show the RF Generator frequency with the offset applied.</p>

Table 5-1 RF Generator Controls and Settings (Continued)

Control/Setting	Description
Output Level	This field defines the output level of the RF Generator. The RF Generator Output Level field should be set to a value appropriate for the receive capabilities of the DUT.
 ATTENTION	The output level of the RF Generator should not exceed the approved rating for the input port selected on the receiver.
Offset Soft-key	The Offset soft-key is an on/off toggle soft-key that is used to apply an offset value to the generator frequency. See the Frequency Offset Field description for information.
Output Soft-key	The Output soft-key turns the RF Generator on and off.

5.2.3.2 Configuring the RF Generator

The RF Generator should be configured according to the capabilities of the receiver. Refer to the receiver’s input ratings to ensure the output level of the RF Generator does not exceed the operational capabilities of the receiver.

Configure RF Generator Parameters

1. Open the **RF Generator panel**.
2. Define the **RF Generator Frequency**.
3. Define the **RF Generator Level**.

Apply an RF Frequency Offset

4. Set the **Freq Offset soft-key** to **ON**.
5. Define the **RF Generator Frequency Offset value**.
6. The **RF Generator Frequency field** updates to display the frequency with the offset applied (e.g. 3,001.00 MHz).



NOTE

Frequency Offset field is only supported in Duplex Test mode of operation.

To Output the RF Signal

7. Change the **RF Gen soft-key** to **ON**.
8. The CX100 is now generating an RF signal.

5.2.4 Modulation Generator

The CX100 supports two internal modulation generators which utilize the instrument's RF generator to output modulated signals. The modulation generators function independently from one another, making the CX100 capable of supporting the simultaneous output of two different modulation types. For example, **Modulation Generator 1** can be configured to output an AM signal, while **Modulation Generator 2** can be configured to output an FM signal.



NOTE

The CX100 only supports one modulation generator when Digital is selected as the Modulation Type. When Digital Modulation is selected as the modulation type on one of the modulation generators, the fields and controls on the other modulation generator are disabled.

5.2.4.1 Modulation Generator Controls and Settings

The following controls and settings are used to configure the characteristics of the outgoing modulated signal that is applied to the carrier frequency (RF generator signal).

Table 5-2 Modulation Generator Controls and Settings

Control/Setting	Description
Modulation Type	<p>The (Modulation) Type menu selects the type of modulation to be applied to the generated signal. The parameters that must be configured to produce a modulated signal are based on the type of modulation selected.</p> <ul style="list-style-type: none"> • None: No parameters • FM: Deviation, Rate, Waveform • AM: Rate, Depth, Waveform • AM USB/LSB: Rate, Waveform • Digital: File Selection
AM or FM Rate	AM or FM Rate defines the rate at which the waveform is varied (modulated) when applied to the carrier frequency.
AM Depth	AM Depth defines the a percent by which the modulated waveform varies from the carrier amplitude.
FM Deviation	FM Deviation defines the frequency by which the modulated waveform varies from the carrier frequency.
Waveform	Waveform selects the shape of the modulated waveform that is being applied to the carrier frequency.

Table 5-2 Modulation Generator Controls and Settings (Continued)

Control/Setting	Description
File Selection	The File Selection field is enabled when Digital modulation type is selected. The field is used to select a pre-recorded digital modulation file which is applied to the carrier frequency.
Mod “x” On/Off Soft-key	The Mod 1 and Mod 2 soft-key turns the corresponding modulation generator on and off. Each modulation generator is controlled independently from the other.

The CX100 supports the use of an external modulation source for some modulation types (i.e., AM, FM). The instrument must be properly configured to receive a valid incoming audio signal in order to use external modulation.

5.2.4.2 Configuring the Modulation Generator

This section provides instructions to configure the CX100 to output a modulated signal.

Configure RF Generator

1. Open the **RF Generator panel**.
2. Define the **RF Generator Frequency** to which the modulated signal will be applied.
3. Set the **RF Generator Level** to the desired value.

Configure Modulation Characteristics

1. Open the **Modulation Generator 1 panel**.
2. Select the **Modulation Type**.
3. Configure modulation parameters.
4. Turn **Mod Gen 1** or **Mod Gen 2 soft-key ON**.

To Output the RF Signal

5. Select the **RF Generator panel**.
6. Turn the **RF Gen soft-key to ON**.
7. The CX100 is now generating a modulated signal.

5.2.4.3 External Modulation Generator Controls and Settings

The following controls and settings are used to configure the characteristics of the external modulated signal that is being received by the CX100:

Table 5-3 External Modulation Controls and Settings

Control/Setting	Description
Modulation Type	<p>The external modulation parameters that must be configured depend on the type of modulation selected.</p> <ul style="list-style-type: none"> • None: No parameters • AM: Rate (%), Coupling • FM: Deviation (kHz), Coupling
Rate (AM)	<p>Defines the rate at which the waveform is varied (modulated) when applied to the carrier frequency.</p>
Deviation (FM)	<p>FM Deviation defines the frequency by which the modulated waveform varies from the carrier frequency.</p>
Coupling	<p>Coupling selects how any unwanted AC/DC components are filtered from the received signal.</p> <p>AC Coupling</p> <p>AC coupling filters the DC signal component out of a signal that contains both AC and DC components. The DC component of a signal acts as a voltage offset so removing the component may increase the resolution of signal measurements.</p> <p>DC Coupling</p> <p>DC coupling does not filter components from the signal; both AC and DC signal components are therefore present in the signal. DC coupling is typically used when any offset voltage present is $<\pm 100$ mV or if the DC content of the signal is important.</p>
Mod Ext On/Off Soft-key	<p>The Mod Ext soft-key turns the external modulation generator on and off.</p>

5.2.5 RF Receiver

The RF Receiver controls and settings are used to determine how the instrument processes an incoming signal. In order to obtain accurate test and measurement results, RF Receiver parameters must be set according to the known characteristics of the incoming signal.

The **RF Receiver Port**, **Frequency**, **Reference Level** and **External Attenuator** parameters apply to all types of incoming signals. There are additional parameters that must be configured depending on the type of modulation that has been applied to the incoming signal. The modulation type that is selected from the **RF Receiver Demodulation Type** menu enables the parameters applicable to each modulation type.

Input Overload Caution



CAUTION

Do not overload input connectors. Refer to product labeling or product specifications for maximum input ratings.

5.2.5.1 RF Receiver Controls and Settings

The following controls and settings are used to configure the CX100 RF Receiver. The RF Receiver should be configured according to the expected characteristics of the incoming signal.

Table 5-4 RF Receiver Controls and Settings

Control/Setting	Description
Port	<p>The RF Receiver Port menu selects the input connector at which the incoming signal is being received. This setting should be selected according to the properties of the incoming signal and the requirements of the test being performed.</p> <p>ANT/SWR</p> <p>ANT/SWR should be selected for performing high sensitivity, low power measurements. When ANT/SWR is selected, the RF Receiver’s pre-amplifier is available. See section , “PreAmp On/Off Soft-key”, on page 5-13 for information.</p> <p>DUPLEX</p> <p>DUPLEX should be selected for receiving high power signals.</p> <p>See “Input Overload Caution” on page 5-10.</p> <p>If the test involves a high power incoming signal that exceeds the input ratings of the RF Receiver input connectors, use an external attenuator (see “External Attenuator” description below).</p>



Table 5-4 RF Receiver Controls and Settings (Continued)


Control/Setting	Description
Frequency	The RF Receiver Frequency should be set to match the frequency being transmitted by the DUT.
External Attenuator	The External Attenuation field makes adjustments in signal processing to account for the use of an attenuator pad or adapter. The External Attenuator field should be set to a value appropriate to the attenuator pad or adapter being used.
Reference Level	Reference Level defines the signal level in relation to the RF Input of the incoming signal; the field should be set according to the expected power level of the incoming signal.
Demodulation Type	<p>The Demodulation Type selects the type of modulation that has been applied to the incoming signal, providing controls and parameters necessary to separate the data from the carrier signal. The demodulation controls and parameters that are available are determined by the following:</p> <ul style="list-style-type: none"> • The type of signal that is being demodulated • The type of AF Filter that is selected to process the incoming signal • The selected filter characteristics (when applicable) • The De-Emphasis setting (when applicable)
IF Bandwidth (BW)	<p>IF BW menu selects the IF detection bandwidth. Select the IF bandwidth appropriate for the characteristics of the incoming signal.</p> <p> A lower bandwidth reduces the interference caused by powerful narrow-band transmitters, therefore, select the lowest bandwidth possible to suit the characteristics of the incoming signal.</p>

Table 5-4 RF Receiver Controls and Settings (Continued)

Control/Setting	Description
AF Filters	<p>The parameters that are available for configuring AF Filters depends on the type of filter selected.</p> <p>Low Pass</p> <p>When Low Pass is selected, the Audio Low Pass and De-Emphasis parameters are enabled.</p> <p>High Pass</p> <p>When High Pass is selected, the Audio High Pass and De-Emphasis parameters are enabled.</p> <p>Band Pass</p> <p>When Band Pass is selected, the Low Pass Corner Frequency, High Pass Corner Frequency, and De-Emphasis parameters are enabled.</p> <p>Psophometric</p> <p>When Psophometric is selected, the Psophometric (Weight) and De-Emphasis parameters are enabled.</p>
Audio Low Pass	<p>A low-pass filter (LPF) passes signals with a frequency lower than a selected cutoff frequency. The Audio Low Pass filter selects the highest frequency that is allowed to pass through the AF filter; frequencies above the selected frequency are cut off.</p>
Audio High Pass	<p>A high-pass filter (HPF) passes signals with a frequency higher than a selected cutoff frequency. The Audio High Pass filter selects the lowest frequency that is allowed to pass through the AF filter; frequencies below the selected frequency are cut off.</p>
Audio Band Pass	<p>Audio Band Pass enables the low pass and high pass corner frequency fields which allow the user to define a frequency band to allow signals within a certain frequency band to pass, while blocking signals with frequencies on the outside of the band.</p> <p>Low Pass Corner Frequency</p> <p>The Low Pass Corner Frequency defines the lower end of the frequency band filter. Any signal that is detected that falls below this frequency is filtered out of the incoming signal.</p> <p>High Pass Corner Frequency</p> <p>The High Pass Corner Frequency defines the upper end of the frequency band filter. Any signal that is detected that is above this frequency is filtered out of the incoming signal.</p>

Table 5-4 RF Receiver Controls and Settings (Continued)

Control/Setting	Description
Psophometric	<p>Psophometric filters are typically used when measuring the residual noise in audio equipment. The Psophometric filter is included in the signal path to emphasize the audible parts of the signal and attenuate signal components that contribute less to perception of loudness. CCITT and C-message (C-MSG) weighting filters are bandpass filters used to measure audio-frequency noise on telephone circuits.</p> <p>C-MSG Filter</p> <p>The C-MSG is used for voice, audio, and telecommunication applications in the U.S.</p> <p>CCITT</p> <p>The CCITT filter is used for international telephone circuits.</p>
De-Emphasis	<p>The De-Emphasis filter attenuates signal components by the amount by which they have been amplified (PreAmp is turned ON). In some cases, the combined use of the pre-amp and de-emphasis filter may improve signal to noise ratio of an incoming signal.</p>
Autotune Soft-key	<p>When the Autotune soft-key is pressed, the CX100 sets the RF Receiver Frequency to the strongest signal detected at the active RF Input connector.</p>
PreAmp On/Off Soft-key	<p>The RF Receiver's pre-amplifier is available for use when the RF Receiver Port is set to ANT/SWR. This soft-key determines whether or not the pre-amplifier is included (ON) in the input signal path.</p> <p>The pre-amplifier (PreAmp) is typically used to boost weak incoming signals to eliminate noise and produce a clean signal that is strong enough to be processed.</p>

5.2.5.2 Configuring the RF Receiver

To Configure the RF Receiver

1. Open the **RF Receiver panel**.
2. Connect the incoming RF Signal to the **RF Receiver Port** appropriate for the characteristics of the incoming signal.
3. Select the **RF Receiver Port** selected in step 2.
4. Set the **RF Frequency** to the frequency of the incoming signal.
5. Set the **RF Frequency Reference Level** to the power level of the generator/radio.
6. Set the **RF Receiver Demodulation Type** to the modulation type of the incoming signal.

5.2.6 AF Function Generator

The CX100 contains two audio function (AF) generators that are capable of supporting the simultaneous output of two signals of different frequencies, shape and power.

The **Settings soft-key** opens a configuration menu that accesses controls and settings that are used to configure the parameters of the generated audio signal. See Table 5-5, “AF Generator Controls and Settings,” on page 5-14 for a description of these settings.

5.2.6.1 AF Generator Controls and Settings

The following controls and settings are used to configure the characteristics of the generated audio signal:

Table 5-5 AF Generator Controls and Settings

Controls/Settings	Description
Frequency	This field defines the frequency of the outgoing waveform. Each function generator can be configured to produce a waveform at a different frequency.
Level Type	<p>Level Type selects the manner in which the level is calculated and applied to the outgoing signal.</p> <p>VPP</p> <p>Peak to Peak Voltage (VPP) is measured from the top of the waveform to the bottom of the waveform. Vpp is typically used when working with instantaneous voltages.</p> <p>Vrms</p> <p>Root mean squared voltage (Vrms) is a calculation of Vpp that yields the equivalent DC voltage that would deliver the same energy to the load.</p> <p>Vrms is typically used when there is a requirement to calculate average power in an AC circuit.</p>
Level	The Level field defines to output level of the signal in either Vpp or Vrms as selected in the Level Type field .
Waveform	The Waveform field selects the type of waveform to be generated by the function generator.
Encode Type	<p>Encoding is accessed from the Settings soft-key.</p> <p>Encoding Type selects the protocol standard that is used to format that data that is included in the generated signal. Contact VIAVI for information about support for different types of signal encoding.</p>

Table 5-5 AF Generator Controls and Settings (Continued)

Controls/Settings	Description
Coupling	<p>Coupling is accessed from the Settings soft-key. Coupling selects how unwanted AC/DC signal components are filtered from the received signal.</p> <p>AC Coupling</p> <p>AC coupling filters the DC signal component out of a signal that contains both AC and DC components. The DC component of a signal acts as a voltage offset so removing the component may increase the resolution of signal measurements.</p> <p>DC Coupling</p> <p>DC coupling does not filter components from the signal; both AC and DC signal components are therefore present in the signal. DC coupling is typically used when any offset voltage present is $<\pm 100$ mV or if the DC content of the signal is important.</p>
Settings Soft-key	<p>The Settings soft-key opens a menu that accesses the following controls and settings (described above):</p> <ul style="list-style-type: none"> • Encode Type • Coupling
AF Gen “x” Soft-key	<p>The AF Gen 1 and AF Gen 2 soft-keys turn the corresponding AF Generator on and off.</p>

5.2.6.2 Configuring the AF Function Generator

To Configure the CX100 AF Function Generator:

1. Open the **AF Function Generator panel**.
2. Set **Coupling** to desired setting.
3. Set **Frequency** for AF Generator 1 and or 2.
4. Select **Level Type** for AF Generator 1 and or 2.
5. Set **Level** for AF Generator 1 and/or 2.
6. Select **Sine** for AF Generator 1 and or 2 **Waveform**.
7. Enable to AF Generator(s) being used.
8. AF signal is now being generated at the Audio Out connector.

5.2.7 RF Test Meters

The **Meters panel** displays measurement data for the device Under Test (DUT). The types of meters that are active on the **Meters panel** depend on the following selections:

- RF Test mode that is selected.
- Modulation type selected from the **RF Receiver Demodulation Type menu**. See section , “Demodulation Type”, on page 5-11 for information.
- User selections such as the type of noise measurement, or the type of power measurement to be performed.

5.2.7.1 Meter Panel Layout

The **Meters panel** is a drop-down panel that contains meter “blocks” that are grouped according to meter type. Each meter is displayed under the appropriate meter heading as a separate block; each meter block contains the following information (Figure 5-3):

- Meter Name: displayed top, center of the meter block
- Meter reading: displayed centered in the middle of the meter block
- UOM: unit of measurement (UOM) is displayed centered below the meter reading
- Measurement type: displayed in the lower right corner of the meter block
- **Offset Applied Indicator**: displayed on the power measurement meters when external attenuation is applied.





Figure 5-3 Meter “Block” Content Diagram

5.2.7.2 Meter Soft-key Panel

The contents of the **Meter soft-key panel** is determined by the selected meter group. To activate a soft-key panel, select the group title bar (e.g. Audio Measurements or Transmit Measurements). The contents of the soft-key panel will update to display soft-keys that support functions applicable to the selected meter group.

5.2.7.3 Meter Configuration Window

Each meter requires specific controls and settings necessary to configure how measurements are performed and how the results are displayed on the UI. These controls and settings are located in meter configuration block windows. Meter configuration windows are opened by pressing and holding a meter block.



Select block to open Meter Configuration Window.

Figure 5-4 Opening Meter Configuration Window


The contents of meter configuration windows varies according to the settings required to perform each measurement. This section describes meter limits and measurement type settings, which are supported in some capacity on each meter. Other meter parameters are described in the following sections:

- [5.2.7.4 Audio Measurements](#) 5-20
- [5.2.7.5 Analog Demod Measurements](#) 5-21
- [5.2.7.6 Digital Demod Measurements](#) 5-23
- [5.2.7.7 Transmit Measurements](#) 5-29

5.2.7.3.1 Meter Limits

Meter limits are used to define pass/fail criteria for measurements. CX100 meters support upper and lower limits as appropriate for the measurement. When limits are enabled for a meter, CX100 meters provide a visual indicator of pass/fail status: the background color of the meter block changes to indicate reading status as described below in [Table 5-6](#).


Table 5-6 Meter Limit Status Indicators




Example 1

Red background and fail icon  indicate the following condition:


- Above Upper Limit



Example 2

Green background and pass icon  indicate the following conditions:

- Below upper limit
- Above lower limit
- Within upper and lower limit(s)




Example 3


Blue background and fail icon  indicate the following condition:

- Below lower limit

5.2.7.3.1.A Upper Limits


The **Upper Limit field** sets a maximum acceptable reading for a specific measurement. The upper limit value must be greater than the value defined in the lower limit field, even when the lower limit is not enabled.


When a measurement exceeds the enabled upper limit value, the measurement block turns red and the  fail icon is displayed (Example 1).

When readings are under a defined Upper Limit, or within enabled upper and lower limits, the measurement block turns green and the  pass icon is displayed (Example 2).

5.2.7.3.1.B Lower Limits

The **Lower Limit field** sets a minimum acceptable reading for a specific measurement. The lower limit value must be lower than the value defined in the upper limit field, even when the upper limit is not enabled.

When a measurement falls below the enabled lower limit value, the measurement block turns blue and the  fail icon is displayed (Example 3).

When readings are above a defined lower limit, or within enabled upper and lower limits, the measurement block turns green and the  pass icon is displayed (Example 2).

5.2.7.3.2 Meter Measurement Types

Each meter supports live, maximum, minimum and average measurements. A small text indicator is located on each meter block which indicates the measurement type being displayed on the meter.

Live Measurement

When **Live** is selected, the meter displays the measured value of the signal at that given point in time. The meter updates continuously as long as the device is receiving an incoming signal.

Max Measurement

When **Max** is selected, the meters displays the highest reading detected at that point in time. The meter updates when/if a reading is detected that is higher than the currently displayed measurement.

Min Measurement

When **Min** is selected, the meters displays the lowest reading detected at that point in time. The meter updates when/if a reading is detected that is lower than the currently displayed measurement.

Average Measurement

When **Average** is selected, a field is enabled which is used to define the number of readings acquired to calculate the average measurement. The meter reading updates each time the defined number of measurements has been processed.

5.2.7.4 Audio Measurements

Audio measurements are supported in Duplex Test and Rx Test modes of operation. The CX100 contains the following Audio meters:

Audio Level Meter

The **Audio Level meter** indicates the signal voltage or power of the received audio signal. The measurement is used to evaluate the power performance of the transmit device.



Offset Applied Indicator

An offset indicator is displayed on the **Audio Level meter** measurement meters when external attenuation is applied.

(Audio) Distortion Meter

The **Distortion meter** is used to detect and isolate any frequencies that are causing distortion on the incoming audio signal. The **Distortion meter** displays the difference between the incoming audio signal in relation to the transmitted signal. The differences detected are a result of extraneous signals present in the audio signal (i.e., noise, external signals).

(Audio) SINAD Meter

SINAD measurements are typically used to determine receiver sensitivity, but they can also be used to determine how a transmit signal is degraded by noise and distortion. The **SINAD Meter** displays the ratio Signal + Noise + Distortion divided by the sum of Noise + Distortion, the result of which is displayed in dB.

(Audio) SNR Meter

Signal to Noise (SNR) measurements compare the level of a desired signal to the level of background noise. SNR is defined as the ratio of signal power to the noise power.

AF Counter

The **AF Counter** measures the number of oscillations present in the received audio signal. The **AF Counter** is used to perform tasks such as measuring the frequency of a carrier signal or measuring the frequency accuracy of the incoming signal.

5.2.7.4.1 Audio Meter Controls and Settings

The audio meters supports user selectable measurement types which are described in section 5.2.7.3.2, on page 5-19 and upper and lower limits which are described in section 5.2.7.3.1, on page 5-18. The audio meters also contain the follow controls and settings:

Table 5-7 Audio Meter Controls and Settings

Control/Setting	Description
“Noise Meter” Soft-key	This soft-key selects the type of noise measurement to be performed, Distortion or SINAD . The noise meter displayed in the Meter panel is selected using this soft-key.
Clear/Reset Soft-key	Clears meter readings, resets the measurement meter, then resumes data acquisition.
Input Range Soft-key	This toggle key switches between Audio Level Input Range .
Level Units Soft-Key	This toggle key switches the Audio Level meter between Vrms , VPP and VP units of measurement.

5.2.7.5 Analog Demod Measurements

Analog demodulation measurements are supported in Duplex Test and Tx Test modes of operation. The CX100 contains the following analog demodulation meters:

Modulation Meters

Amplitude Modulation (AM) Meter

The **AM meter** displays the percentage by which the amplitude of the incoming signal varies from the amplitude of the transmitted signal. The **AM meter** is displayed when the **RF Receiver Demodulation Type** is set to **AM** (see ["Demodulation Type" on page 5-11](#)).

Frequency Modulation (FM) Meter

The **FM meter** displays the frequency by which the frequency of the incoming signal varies from the frequency of the transmitted signal. The **FM meter** is displayed when the **RF Receiver Demodulation Type** is set to **FM** (see ["Demodulation Type" on page 5-11](#)).

(Demod) Distortion Meter

The **Distortion meter** is used to detect and isolate any frequencies that are causing distortion on the incoming RF signal. The **Distortion meter** displays the difference between the incoming signal in relation to the transmitted signal. The differences detected are a result of extraneous signals present in the RF signal (i.e., noise, external signals).

(Demod) SINAD Meter

SINAD measurements are typically used to determine receiver sensitivity, but they can also be used to determine how a transmit signal is degraded by noise and distortion. The **SINAD meter** displays the ratio Signal + Noise + Distortion divided by the sum of Noise + Distortion, the result of which is displayed in dB.

(Demod) SNR Meter

Signal to Noise (SNR) measurements compare the level of a desired signal to the level of background noise. SNR is defined as the ratio of signal power to the noise power.

AF Counter

The **AF Counter** measures the number of oscillations present in the received signal. The **AF Counter** is used to perform tasks such as measuring the frequency of a carrier signal or measuring the frequency accuracy of the incoming signal.

5.2.7.5.1 Analog Demod Meter Controls and Settings

Demod meters supports user selectable measurement types which are described in section 5.2.7.3.2, on page 5-19 and upper and lower limits which are described in section 5.2.7.3.1, on page 5-18. **Demod meters** also contain the following controls and settings:

Table 5-8 Demod Meter Controls and Settings

Control/Setting	Description
“Noise Meter” Soft-key	This soft-key selects the type of noise measurement to be performed, Distortion or SINAD . The noise meter displayed in the Meter panel is selected using this soft-key.
Clear/Reset Soft-key	Pressing this soft-key clears meter readings, resets the measurement meter, then resumes data acquisition.

5.2.7.6 Digital Demod Measurements

The CX100 contains a Vector Signal Analyzer (VSA) that processes and demodulates digital data, which is then sent to the device's Digital Demod meters. The Digital Demod meters are used to identify any impairments in the digital signal that may have been introduced by the analog parts of the digital transmitter. More common impairments that negatively impact the performance of a digital modulator are timing drift, frequency offset and amplitude imbalance.

The CX100's VSA estimates certain values in relation to the impairments in the received signal. In order to estimate the impairments, the VSA uses a perfect received signal, called a reference signal, and compares the reference signal to the actual received signal, called the measured signal. [Figure 5-5 on page 5-24](#) shows a high level block diagram of the VSA's main components.




Figure 5-5 VSA Block Diagram

5.2.7.6.1 Digital Demod Meters

The **Digital meters** are available in Duplex Test and Tx Test Mode when the **RF Receiver Demodulation Type** is set to **Digital** (see "[Demodulation Type](#)" on page 5-11). The CX100 supports the following digital meters:

(Digital) Power

The (Digital) **Power meter** is used to evaluate the transmit performance of a digital transmitter.

Error Vector Magnitude (EVM)

Error Vector Magnitude (EVM) is a measure of modulation quality and error performance of a wireless communication systems. The is used to evaluate the performance of a digital transmitter or receiver for the evaluation of software-defined radios (SDRs).

Frequency Offset

Frequency Offset is used to evaluate the frequency accuracy of the signal. The meter indicates the difference between the DUT transmitted signal and the defined RF frequency.

5.2.7.6.2 Digital Meter Controls and Settings

The **Digital meters** support user selectable measurement types which are described in section 5.2.7.3.2, on page 5-19 and upper and lower limits which are described in section 5.2.7.3.1, on page 5-18. The **Digital meters** also contain the following controls and settings:

Table 5-9 Digital Meter General Settings

Control/Setting	Description
Center Frequency	The Center Frequency field is a read only field that indicates the RF Receiver Frequency setting. This value should be set to the expected frequency of the received signal. See Table 5-4, "RF Receiver Controls and Settings," on page 5-10 for information.
Reference Level	The Reference Level field is a read only field that indicates the RF Receiver Reference Level setting. This value should be set to the expected power level of the transmitter. See Table 5-4, "RF Receiver Controls and Settings," on page 5-10 for information.

Table 5-9 Digital Meter General Settings (Continued)

Control/Setting	Description
Coarse Search Frequency	<p>The Coarse Search Frequency setting determines whether or not the digital receiver searches for the received signal if the signal is not present at the defined Center Frequency.</p> <p>When this is enabled, the coarse frequency estimation block of the VSA computes a rough estimation of the frequency offset of the received signal and searches for the signal within the estimated offset range.</p>

Table 5-10 Digital Meter Modulation Settings

Control/Setting	Description
Modulation Type	This menu selects the digital modulation type of the signal being analyzed.
Modulation Order	This field defines the number of possible symbols in the constellation of the modulation.
Symbol Rate	This field defines the number of symbols per second of the received signal.
Oversampling	This field defines the number of samples per symbol to analyze the signal.
Number of Symbols	This field defines the number of symbols used to calculate the parameters in each block of data.

Table 5-11 Digital Meter Equalizer Settings

Control/Setting	Description
Gain	The equalizer gain is used to adjust the coefficients of the equalizer filter.
Equalizer Length	This field defines the length in number of taps of the equalizer filter.
Equalizer Plot Length	This field defines the number of points of the spectrum plot of the channel estimated by the equalizer.

5.2.7.6.3 Digital Filter Types

The CX100 Digital Demod filters are used to limit bandwidth and reduce inter-symbol interference (ISI). The CX100's digital demodulator produces a measured signal and a reference signal. The measured signal is the signal that results from demodulating the waveform; the reference signal is the signal that results from demodulating a signal that contains no errors.

The Digital Filter should be configured based on how the radio/radio system under test performs filtering. Filtering will be performed at the transmitter, at the receiver, or distributed between the transmitter and the receiver.

Reference Filter

The **Reference Filter** is the combined response of the transmit and measurement filter. This filter is applied to the reference signal.

Measurement Filter

The **Measurement Filter** is the shaping filter in the receiver that is applied before demodulation. For some filters, this filter reduces the inter-symbol interference (ISI). For other filters, this filter reduces energy from other signals.

The following settings are available for the digital filters:

Table 5-12 Digital Measurement Filter Settings

Control/Setting	Description
Type	<p>The Digital meters support the following meter types:</p> <p>Reference Filter</p> <ul style="list-style-type: none"> • No Filter: No filter is included in the receive path. • Raised Cosine: Should be used in systems which perform all the filtering in the transmitter. <p>Measurement Filter</p> <ul style="list-style-type: none"> • No Filter: No filter is included in the receive path. • Square Root Raised Cosine: Should be used to test systems that perform partial filtering in the transmitter and partially filtering in the receiver.
Roll-off Factor	Defines the amount of bandwidth allowed in relation to the selected filter.
Filter Length	Defines the length of the measurement or reference filter.

5.2.7.6.4 Digital Equalizer Filter

The equalizer is a complex linear Finite Impulse Response (FIR) filter that compensates the channel; the number of “taps” is flexible. The FIR filter is estimated by the Channel Estimation block of the VSA (see [Figure 5-5 on page 5-24](#)).

The **Equalize soft-key** is used to include the FIR filter in the receive path. When the **Equalizer soft-key** is pressed, the UI updates to display another set of soft-keys, referred to as the Equalizer soft-key panel, which control the states of the equalization filter. The contents of the Digital Equalizer soft-key panel change based on the state of the equalizer. For example, **Freeze Equalizer** and **Reset Equalizer** are not enabled until the equalizer is ON (in learning state) and when **Equalizer Learn** is pressed, the soft-key updates to a status key.

Table 5-13 Equalizer Soft-key Panel

Soft-key	State/Description
Equalizer Learn Soft-key	<p>When the Learning soft-key is selected, the following actions occur:</p> <ul style="list-style-type: none"> • The equalizer learning process is initiated. • The soft key panel reverts to the Digital Demod Measurements soft-key panel. • The status line on the Equalizer soft-key updates to show <i>Equalizer Learning</i>. <p>In the Learning State, the options are to freeze, reset or stop the equalizer process.</p>
Freeze Equalizer Soft-key	<p>When the Freeze soft-key is pressed, the following actions occur:</p> <ul style="list-style-type: none"> • The equalizer filter applies the last taps values that were estimated in the learning state. • The soft key panel reverts to the Digital Demod Measurements soft-key panel. • The status line on the Equalizer soft-key updates to show <i>Equalizer Frozen</i>. <p>Actions available from this state are Learn, Reset or Off.</p>
Reset Equalizer Soft-key	<p>When the Reset soft-key is pressed, the following actions occur:</p> <ul style="list-style-type: none"> • The equalizer filter is set to an impulse response and then goes to the previous state. • The soft key panel reverts to the Digital Demod Measurements soft-key panel. • The status line on the Equalizer soft-key updates to show <i>Equalizer Learning</i>. <p>Actions available from this state are Freeze, Reset or Off.</p>
Equalizer Off Soft-key	<p>When set to OFF, the equalizer filter is bypassed. The only action available from the OFF state is Learning; all other soft-keys are disabled until the Equalizer Learn soft-key is selected.</p>

5.2.7.7 Transmit Measurements

Transmit measurements are used to evaluate the performance of the DUT transmitter. These meters are available in Duplex Test and Tx Test Mode. The CX100 supports the following transmit measurements:

5.2.7.7.1 RF Frequency Error

The **RF Frequency Error meter** measures the frequency error of the received signal in relation to the defined RF Receiver Frequency; this meter is used to evaluate the accuracy of the DUT transmitter. The CX100's RF Receiver Frequency must be set to the expected transmit frequency of the UUT in order to obtain valid RF Frequency Error measurements.

The **RF Frequency Error meter** supports user selectable measurement types which are described in section 5.2.7.3.2, on page 5-19 and lower limits which are described in section 5.2.7.3.1, on page 5-18.

5.2.7.7.2 RF Power Meter

The **RF Power meter** is used to evaluate the RF transmit performance of a DUT, most commonly to determine if the DUT's output power is meeting specification.

The **RF Power meter** supports user selectable measurement types which are described in section 5.2.7.3.2, on page 5-19 and lower limits which are described in section 5.2.7.3.1, on page 5-18. The **RF Power meter** also contains the following controls and settings:

Table 5-14 RF Power Meter Controls and Settings

Control/Setting	Description
Receiver External Attenuator	This field is used to compensate for the use of an external attenuator for high power transmitters. RF Power meter readings are compensated by the defined external attenuation value. This value should be defined as a negative value only.
Normalize Soft-key	When the Normalize soft-key is pressed, the system zeroes out the RF Receiver signal path, removing any residual power from the RF path which eliminates the system's frequency response error.

The **RF Power meter** uses the following status indicators:

Offset Applied Indicator



An offset indicator is displayed on the **RF Power meter** when external attenuation is applied. RF Offsets are applied on the **RF Generator panel** (see ["Offset Soft-key" on page 5-6](#)).

Normalize Indicator



An Attention indicator is displayed on the **Normalize soft-key** when normalize needs to be performed. When this condition occurs, Normalize should be performed to ensure accurate measurements.

5.2.8 Digital Plots Panel

The **Digital Plots panel** is used to evaluate the quality of the received digital signal. The **Digital Plots panel** is enabled when the **RF Receiver Demodulation Type** is set to receive digital signals (see ["Demodulation Type" on page 5-11](#)). The instrument supports a variety of digital plots which are dependent on the characteristics of the digital signal.

5.2.8.1 Constellation Plot

The IQ Domain, Constellation Plot displays the constellation points of the digital signal. This plot is used for evaluating signal distortion and noise.

The **Display Settings soft-key** opens a menu that contains controls and settings that affect display layout and manage how traces are displayed on plot field. See [section 5.2.8.1.2, "Constellation Plot Controls and Settings", on page 5-31](#) for a description of these settings. Read-only digital meter fields are displayed above the plot field for reference purposes; the meters are configured on the **Meters panel** (see [section 5.2.7.6, on page 5-23](#)).

5.2.8.1.1 Constellation Plot Soft-key Panel

The Constellation Plot soft-key panel contains the following controls:

Table 5-15 Constellation Plot Soft-key Panel

Control/Setting	Description
Display Settings Soft-key	The Display Settings soft-key opens a menu that contains controls and settings that affect display layout and manage how traces are displayed on plot field. See section 5.2.8.1.2, "Constellation Plot Controls and Settings", on page 5-31 for a description of these settings.
Clear/Reset Soft-key	Clears captured trace data from the plot field and resets measurement meters that are located above the plot field, then resumes data acquisition.

Table 5-15 Constellation Plot Soft-key Panel (Continued)

Control/Setting	Description
Pause/Resume Soft-key	<p>When the signal plot is displayed on the UI, the signal trace is active by default. Pressing the Pause soft-key temporarily halts data updates to the UI. When this occurs, the soft-key updates to the Resume soft-key.</p> <p>When the signal plot is paused, data that is being acquired is stored in the system's data acquisition buffer, when the Resume soft-key is pressed, the data being stored in the buffer is released and sent to the UI.</p>

5.2.8.1.2 Constellation Plot Controls and Settings

The following settings are used to configure how the trace is displayed on the plot field:

Table 5-16 Constellation Plot Controls and Settings

Control/Setting	Description
Type	<p>Type is accessed from the Display Settings soft-key. The Type menu selects the measurement plot that will be displayed on the screen. The contents of this menu are determined by the type of digital signal that is selected on the RF Receiver panel.</p>
Persistence	<p>The Persistence field is accessed from the Display Settings soft-key.</p> <p>The persistence setting specifies how many trace plots are shown simultaneously on the display field. The selectable range is 1 to 10. Selecting 1 means that only one burst or time slot is displayed on the display field. Selecting 10 means the last 10 bursts or time slots are displayed simultaneously on the display field.</p>

5.2.9 RF Analyzer

The RF Analyzer is used to evaluate the receive performance of the device under test (DUT). The RF Analyzer is an asynchronous, swept analyzer that displays the spectrum of the RF signal received by the test set over a 5 MHz bandwidth. The source of the signal is from the DUT, and the signal is routed through the test set's receiver chain, therefore the RF Analyzer is dependent on the receiver for receive settings such as connector selection, attenuation and center frequency.



NOTE

The RF Analyzer is not available when the RF Receiver Demodulation Type is set to receive digital signals (see ["Demodulation Type"](#) on page 5-11).

5.2.9.1 RF Analyzer Panel Layout

The **RF Analyzer panel** consists of the following areas or groups of controls and settings:




Figure 5-6 RF Analyzer Panel Layout

Plot Field

The plot field displays a visual representation of the received signal. Controls and settings are available that allow the user to adjust settings such as plot scale, modes of operation and the types of traces being displayed on the plot.

See section 5.2.9.3, "RF Analyzer Display Settings", on page 5-34 and section 5.2.9.4, on page 5-36 describe the controls and settings that are supported on the RF Analyzer.

Marker Controls and Data Fields

The RF Analyzer contains a variety of marker functions, controls and settings that allow the user to create custom test scenarios. See section 5.2.9.5, “RF Analyzer Marker Controls”, on page 5-39 for a description of Marker controls and settings.

Trace Legend

The trace legend indicates the trace types that are currently active and the color of the line used to represent each trace type. The types of traces that are displayed on the plot field are selected using the **Active Trace button** located in the **Display Settings menu**.

Soft-key Panel

The soft-key panel contains controls and settings that are used to configure the RF Analyzer. See section 5.2.9.2, “RF Analyzer Soft-key Panel”, on page 5-33 for a description of RF Analyzer soft-keys.


5.2.9.2 RF Analyzer Soft-key Panel

The RF Analyzer soft-key panel contains the following controls:

Table 5-17 RF Analyzer Soft-keys

Soft-key	Description
Display Settings Soft-key	The Display Settings soft-key opens a menu that contains controls and settings manage how traces are displayed on the plot field. See section 5.2.9.3, “RF Analyzer Display Settings”, on page 5-34 for a description of these settings.
Instrument Settings Soft-key	The Instrument Settings soft-key opens a menu that contains controls and settings that define how the RF Analyzer receives and processes an incoming signal. See section 5.2.9.4, “RF Analyzer Instrument Settings”, on page 5-36 for a description of these settings.
Normalize Soft-key	The Normalize soft-key opens a settings window that contains controls and settings which are used to zero out the RF Analyzer signal path, removing any residual power from the RF path which eliminates the system’s frequency response error.
Spot Frequency	The Spot Frequency field defines the frequency to be zeroed out. Pressing the Run Normalize soft-key initiates the process.

Table 5-17 RF Analyzer Soft-keys (Continued)

Soft-key	Description
	<p>An attention indicator is displayed on the Normalize soft-key when the system detects residual power on the signal path. When this condition occurs, Normalize should be performed to ensure accurate measurements.</p>
<p>Pause/Resume Soft-key</p>	<p>When the RF Analyzer is displayed on the UI, the signal trace is active by default. Pressing the Pause soft-key temporarily halts data updates to the UI. When this occurs the soft-key updates to the Resume soft-key.</p> <p>When the Analyzer is paused, data that is being acquired is stored in the system’s data acquisition buffer, when the Resume soft-key is pressed, the data being stored in the buffer is released and sent to the UI.</p>

5.2.9.3 RF Analyzer Display Settings

The **Display Settings soft-key** opens a menu that contains controls and settings that manage how traces are displayed on plot fields.

Table 5-18 RF Analyzer Display Settings

Control/Setting	Description
<p>Active Trace Button</p>	<p>The Active Trace button opens a window that selects the type of trace(s) to be displayed on the plot field. Multiple traces can be selected at any given time on each plot.</p> <ul style="list-style-type: none"> • Max: displays highest signal received • Min: displays lowest signal received • Live: displays live signal trace • Average: displays an averaged signal trace; average is defined by the Average Field.
<p>Average (Field)</p>	<p>The Average field is enabled when Average is selected as the active trace. The Average field defines the number of traces to be used to calculate an average signal trace.</p>

Table 5-18 RF Analyzer Display Settings (Continued)

Control/Setting	Description
Capture Trace Button	<p>When the Capture Trace button is pressed, a trace is “held” on the display. When more than one trace is active on a plot, only one of the active traces will be captured. When multiple trace types are enabled, traces are captured in the following priority:</p> <ul style="list-style-type: none"> • MAX Priority 1 • MIN Priority 2 • Average Priority 3 • Live Priority 4 <p>For example, if Average and Live traces are enabled, the Average trace is captured. If Max and Average traces are enabled, the Max trace is captured.</p> <p>When the Capture Trace button is pressed, the Clear Trace button is enabled which is used to remove a captured trace from the plot field.</p>
Clear Trace Button	<p>The Clear Trace button is active when a the Captured Trace button has been pressed and a trace is captured on the plot field. Pressing the Clear Trace button removes the captured trace from the plot field.</p>
Save Trace Button	<p>Pressing the Save Trace button displays a window that is used to enter a name for saving a file. The file will be saved to a user defined location. See section 4.2.7, “Specifying File Save Location”, on page 4-8.</p> <p>The Save Trace function saves x,y data in .csv file format.</p>
Recall Trace Button	<p>The Recall Trace button displays a file selection box which allows user to recall a stored trace. The stored trace file can be recalled from the device or from a USB device.</p>

5.2.9.4 RF Analyzer Instrument Settings

The **Instrument Settings menu** accesses the controls and settings that define how the RF Analyzer receives and processes an incoming signal.

Table 5-19 RF Analyzer Instrument Settings

Control/Setting	Description
Port	<p>The Port menu selects the input connector that is used for analyzing incoming signals.</p> <p>ANT/SWR</p> <p>The ANT/SWR connector should be selected to perform over the air testing using an external antenna or when test parameters require maximum input sensitivity. This connector should be used when analyzing low level RF signals.</p> <p>DUPLEX</p> <p>The DUPLEX connector is a combined (Duplexed) connector that provides an RF generator output connection and an RF receiver input connection. This connector should be used when analyzing high power RF signals.</p>
Coupling	<p>The Coupling menu accesses settings that define the Resolution Bandwidth (RBW) and acquisition time that the Analyzer uses to filter the signal. Acquisition time is used in combination with the RBW setting to improve frequency resolution. Acquisition time and RBW bandpass filter should be inversely proportional to one another. Making the acquisition time longer, while keeping the sampling rate the same, results in the ability to use a narrower RBW.</p> <p>Resolution Bandwidth (RBW)</p> <p>RBW filters are the bandpass filters in the IF path that determine the RF noise floor and how close two signals can be and still be viewed separately on the analyzer.</p> <p>A narrower RBW setting more clearly displays close signals as separate signals, however, a narrower bandwidth setting results in a longer sweep time.</p> <p>An RBW setting that is too wide causes signals that are close together to appear as one signal.</p> <p>Auto Mode: system sets RBW to a filter appropriate to the characteristics identified in the received signal</p> <p>Manual Mode: allows the user to manually define the RBW.</p>

Table 5-19 RF Analyzer Instrument Settings (Continued)

Control/Setting	Description
Coupling (cont)	<p>Acquisition Time</p> <p>Acquisition Time field defines the length of time that samples are acquired from the time domain.</p> <p>Auto Mode: system sets Acquisition time to a value appropriate to the characteristics identified in the received signal as well as the RBW setting.</p> <p>Manual Mode: allows the user to manually define acquisition time.</p>
Reference Level	<p>The Reference Level field defines the top value on the plot field's vertical scale. Reference Level can be set to any value within the specified range, but should be set to a value above the expected power level of the incoming signal in order to view the full signal waveform.</p>
Frequency Mode	<p>Frequency Mode selects the method used to define the span of the analyzer plot field. Parameters update according to the type of mode selected.</p> <p>Full Span Frequency Mode</p> <p>When Full Span is selected, the span defaults to the instrument's full frequency range. The UI updates to display the Start and Stop frequencies as read-only data fields.</p> <p>Center/Span Frequency Mode</p> <p>Center/Span Frequency mode of operation specifies the center frequency value as well as the frequency span setting.</p> <p>When Center/Span is selected, the UI displays a Center Frequency and Span setting. Center/Span mode uses the sweep Center Frequency value and Span setting to define the frequency span.</p> <p>Start/Stop Frequency Mode</p> <p>Start-Stop frequency mode of operation defines the sweep start and sweep end frequencies of the swept measurement range.</p> <p>When Start/Stop is selected, the UI displays a Start Frequency and Stop Frequency fields. The sweep start and sweep stop frequencies define the frequency span.</p>

Table 5-19 RF Analyzer Instrument Settings (Continued)

Control/Setting	Description
Frequency Mode (cont)	<p>Zero Span Frequency Mode</p> <p>In Zero Span mode the Analyzer does not perform a frequency sweep: it detects the power level at the set frequency. The trace shows detected power against time. When operating in Zero-Span mode, marker position is specified in time.</p>
Amplitude	<p>Amplitude settings affect how the plot field’s vertical scaling and how the signal appears when displayed on the plot field.</p> <p>Scale</p> <p>The RF Analyzer uses logarithmic scaling to display the signal amplitude on the analyzer vertical axis. Differences in signal amplitudes are compressed because low amplitude signals are amplified and high amplitude are compressed. This allows signal with widely varying amplitudes to be displayed on the same plot. Log scale is used to view both low amplitude and high amplitude frequencies with same clarity.</p> <p>Vertical Scale</p> <p>Selects the dB division between the vertical scaling on the plot field.</p>
Detector Type	<p>The RF Analyzer uses detectors in order to accurately map the correct signal power to the correct frequency point on the display.</p>

5.2.9.5 RF Analyzer Marker Controls

The RF Analyzer supports two markers, referred to as Marker 1 and Marker 2. When the RF Analyzer is first opened, Marker 2 will be displayed on the plot field on top of Marker 1: Marker 1 tick box will be selected. [Figure 5-7](#) identifies the RF Analyzer marker controls.








Figure 5-7 RF Analyzer Marker Controls

Table 5-20 RF Analyzer Marker Controls and Settings

Control/Setting	Description
Marker Selection Tick Boxes	The M1 and M2 tick boxes are used to select a marker. The tick box that is selected specifies the marker to which any settings or configuration changes are applied.
Set Marker Position Button	Pressing the Set Marker Position button displays a window that is used to define a specific frequency at which to place the selected marker.
Marker Indicator Line	Markers are attached to a vertical line which provides a visual indicator of the marker's position on the plot field. The Marker Indicator Line is locked to the marker, and moves whenever the marker is repositioned on the plot field. The Marker Indicator Line can also be used to move the marker on the plot field. See section 5.2.9.7, "Setting Marker Position", on page 5-41.

Table 5-20 RF Analyzer Marker Controls and Settings (Continued)

Control/Setting	Description
Marker Navigation Buttons	Pressing one of the Marker Navigation buttons moves the selected marker as described below.
	Marker Left to Peak When pressed, the selected marker is moved left to the next peak on the signal.
	Marker to Peak When pressed, the selected marker is moved to the highest peak on the signal.
	Marker Right to Peak When pressed, the selected marker is moved right to the next peak on the signal.
	Marker Set CF When pressed, the signal's center frequency is set to the selected marker's position.

5.2.9.6 Marker Data Fields

Markers are displayed when the RF Analyzer is opened, but data is not displayed until the trace is enabled. Marker 1 and Marker 2 Data Boxes display the following information:




Figure 5-8 Identifying Marker Data Fields

Table 5-21 Marker Data Field Description

Data Field	Description
Marker Position	Indicates the frequency at which the marker is positioned on the plot field.
Marker Reading	Indicates the power level of the signal at the marker position.
Delta Position	Indicates the difference between Marker 1 and Marker 2 position.

Table 5-21 Marker Data Field Description (Continued)

Data Field	Description
Measurement Type	Marker 1 only displays Live trace data; Marker 2 displays Live trace data, as well as Max and Min trace data when these measurement types traces are enabled.

5.2.9.7 Setting Marker Position

Marker position can be defined using one of the following methods:

Using the Set Marker Position Button

1. Select the marker tick box for the marker that you want to move.
2. Press the **Set Marker Position button**.
3. When the parameter field is displayed, enter the frequency where the marker is to be placed on the plot field.
4. Select the **OK button** to apply the change.

Drag and Drop Marker to Position

1. Select the marker tick box for the marker that you want to move.
2. Press and hold the **Marker Indicator Line** for the marker.
3. When the Marker Indicator Line appears fuzzy as shown in [Figure 5-9](#), **drag the line to the desired position** on the plot field.
4. **Release the Indicator Line** when the marker is at the desired position.




Figure 5-9 Marker Indicator Line - Drag and Drop

Using the Marker Reading Window

1. Select the marker tick box for the marker that you want to move.
2. Press and hold the marker's Marker Data Box.
3. When parameter field is displayed, enter the frequency where the marker is to be placed on the plot field.
4. Select the **OK** button to apply the change.

Marker Navigation Buttons

1. Select the marker tick box for the marker that you want to move.
2. Press the desired **Marker Navigation** button. See section , "Marker Navigation Buttons", on page 5-40 for information about marker navigation buttons.

5.2.10 AF Analyzer

The AF Analyzer provides users with the ability to examine a signal in either the time domain or frequency domain.

The Time Domain plot represents how the signal changes over time; the Frequency Domain plot represents the signal within each frequency band over a given frequency span. The AF Analyzer is used to evaluate a variety of aspects of audio signals such as level, frequency response, noise and distortion.

5.2.10.1 AF Analyzer Frequency Domain Tab

The AF Analyzer **Frequency Domain tab** consists of the following areas or groups of controls and settings:




Figure 5-10 AF Analyzer Frequency Domain Tab Layout

Plot Field

The plot field displays a visual representation of the received signal. Controls and settings are available that allow the user to adjust settings such as plot scale, modes of operation and the types of traces being displayed on the plot.

See section 5.2.10.1.2, “AF Analyzer Frequency Domain Instrument Settings”, on page 5-45 for a description of the controls and settings that are supported on the AF Analyzer.

Marker Controls and Data Fields

The AF Analyzer contains a variety of marker functions, controls and settings that allow the user to create custom test scenarios. AF Analyzer markers operate in the same manner as the RF Analyzer markers. See section 5.2.9.5, “RF Analyzer Marker Controls”, on page 5-39 for information about marker controls, navigation and configuration.

Trace Legend

The trace legend indicates the trace types that are currently active, and the color of the line used to represent each trace type. The types of traces that are displayed on the plot field are selected using the **Active Trace button** located in the **Displays Settings menu**.

Soft-key Panel

The soft-key panel contains controls and settings that are used to configure the AF Analyzer. soft-keys are described below in section 5.2.10.1.1.

5.2.10.1.1 AF Analyzer Frequency Domain Soft-key Panel

The AF Analyzer Frequency Domain soft-key panel contains the following controls:

Table 5-22 AF Analyzer Frequency Domain Soft-keys

Soft-key	Description
Display Settings Soft-key	The AF Analyzer Frequency Domain Plot uses the same display settings found in the AF Analyzer. See section 5.2.9.3, on page 5-34 for a description of these settings.
Instrument Settings Soft-key	The Instrument Settings menu accesses the controls and settings that define how the AF Analyzer receives and processes an incoming signal. See section 5.2.10.1.2, on page 5-45 for a description of these settings.
Pause/Resume Soft-key	Pressing the Pause soft-key temporarily halts data updates to the UI. When this occurs, the soft-key updates to the Resume soft-key . Pressing the Resume soft-key restarts measurements.

5.2.10.1.2 AF Analyzer Frequency Domain Instrument Settings

The **Frequency Domain Instrument Settings menu** accesses the controls and settings that define how the AF Analyzer receives and processes an incoming signal.

Table 5-23 Frequency Domain Instrument Settings

Control/Setting	Description
Port	<p>The AF Analyzer Port menu selects which input port is being used to receive the incoming signal.</p> <p>Audio In</p> <p>Audio In should be selected to analyze an incoming audio signal.</p> <p>Demod</p> <p>Demod should be selected to analyze the demodulated portion of an incoming RF signal</p>
Coupling	<p>The Coupling menu accesses settings that define the Resolution Bandwidth (RBW) and acquisition time that the Analyzer uses to filter the signal.</p> <p>Resolution Bandwidth (RBW)</p> <p>RBW filters are the bandpass filters in the IF path that determine the RF Noise floor and how close two signals can be and still be viewed separately on the analyzer.</p> <p>A narrower RBW setting more clearly displays close signals as separate signals, however, a narrower bandwidth setting results in a longer sweep time.</p> <p>An RBW setting that is too wide causes signals that are closed together to appear as one signal.</p> <p>Auto: When Auto is selected, the system sets RBW to a filter appropriate to the characteristics identified in the received signal</p> <p>Manual: When Manual is selected, the user can manually define the RBW.</p>
Reference Level	<p>The Reference Level field sets the top value on the display graph. The Reference Level can be set to any value within the specified range. The Reference Level of the display must be set so that the RF signal level falls within the display area.</p>
Frequency Mode	<p>Frequency Mode selects the method used to define the span of the analyzer plot field. Parameters update according to the type of mode selected.</p> <p>Full Span Frequency Mode</p> <p>When Full Span is selected, the span defaults to the instrument's full frequency range. The UI updates to display the start and stop frequencies as read-only data fields.</p>

Table 5-23 Frequency Domain Instrument Settings (Continued)

Control/Setting	Description
Frequency Mode (cont)	<p>Center/Span Frequency Mode</p> <p>Center/Span Frequency mode of operation specifies the center frequency value as well as the frequency span setting.</p> <p>When Center/Span is selected, the UI displays a Center Frequency and Span setting. Center/Span Mode uses the sweep Center Frequency value and span setting to define the frequency span.</p> <p>The maximum span of the display is 5 MHz, which is equal to the channel width of the instrument's receiver.</p>
Amplitude	<p>Start/Stop Frequency Mode</p> <p>Start-Stop Frequency mode of operation defines the sweep start and sweep end frequencies of the swept measurement range.</p> <p>When Start/Stop is selected, the UI displays Start Frequency and Stop Frequency fields. The sweep start and sweep stop frequencies define the frequency span.</p> <p>Amplitude settings affect how the plot field's vertical scaling and how the signal appears when displayed on the plot field.</p> <p>Scale</p> <p>The AF Analyzer uses logarithmic scaling to display the signal amplitude on the analyzer vertical axis. Differences in signal amplitudes are compressed because low amplitude signals are amplified and high amplitude are compressed. This allows signal with widely varying amplitudes to be displayed on the same plot. Log scale is used to view both low amplitude and high amplitude frequencies with same clarity.</p> <p>Vertical Scale</p> <p>Selects the dB division between the vertical scaling on the plot field.</p>
Detector Type	<p>The AF Analyzer uses detectors to accurately map the correct signal power to the correct frequency point on the display. Future development will support selectable detector types.</p>

5.2.10.1.3 AF Analyzer Frequency Domain Markers

AF Analyzer Frequency Domain markers operate in the same manner as the RF Analyzer markers. See section 5.2.9.5, "RF Analyzer Marker Controls", on page 5-39 for information about marker controls, navigation and configuration.

5.2.10.2 AF Analyzer Time Domain Tab

The AF Analyzer **Time Domain** tab contains a plot field and soft-key panel.




Figure 5-11 AF Analyzer Time Domain Tab Layout

Plot Field

The plot field displays a visual representation of the received signal. Controls and settings are available that allow the user to adjust settings such as plot scale, modes of operation and the types of traces being displayed on the plot.

See section 5.2.10.2.2, on page 5-48 for a description of the controls and settings that are supported on the AF Analyzer.

Soft-key Panel

The soft-key panel contains controls and settings that are used to configure the AF Analyzer. See section 5.2.10.1.1, on page 5-44 for a description of the AF Analyzer soft-keys.

5.2.10.2.1 AF Analyzer Time Domain Soft-key Panel

The AF Analyzer Time Domain soft-key panel contains the following controls:

Table 5-24 AF Analyzer Time Domain Soft-keys

Soft-key	Description
Display Settings Soft-key	The AF Analyzer Time Domain Plot uses the same display settings found in the RF Analyzer. See section 5.2.9.3, “RF Analyzer Display Settings”, on page 5-34 for a description of these settings.
Instrument Settings Soft-key	The Instrument Settings menu accesses the controls and settings that define how the AF Analyzer receives and processes an incoming signal. See section 5.2.10.2.2, “AF Analyzer Time Domain Instrument Settings”, on page 5-48 for a description of these settings.
Pause/Resume Soft-key	Pressing the Pause soft-key temporarily halts data updates to the UI. When this occurs the soft-key updates to the Resume soft-key . Pressing the Resume soft-key restarts measurements.

5.2.10.2.2 AF Analyzer Time Domain Instrument Settings

The **Time Domain Instrument Settings menu** accesses the controls and settings that define how the AF Analyzer receives and processes an incoming signal.

Table 5-25 AF Analyzer Time Domain Instrument Settings

Control/Setting	Description
Port	The AF Analyzer Port menu selects which input port is being used to receive the incoming signal. Audio In Audio In should be selected to analyze an incoming audio signal. Audio Filters are selected on the RF Receiver panel (see “AF Filters” on page 5-12). Demod Demod should be selected to analyze an incoming demodulated RF audio signal.

Table 5-25 AF Analyzer Time Domain Instrument Settings (Continued)

Control/Setting	Description
Coupling	<p>The Coupling menu accesses settings that define the Resolution Bandwidth (RBW) and acquisition time that the Analyzer uses to filter the signal.</p> <p>AC Coupling</p> <p>AC coupling filters the DC signal component out of a signal that contains both AC and DC components. The DC component of a signal acts as a voltage offset so removing the component may increase the resolution of signal measurements.</p> <p>DC Coupling</p> <p>DC coupling does not filter components from the signal; both AC and DC signal components are therefore present in the signal. DC coupling is typically used when any offset voltage present is $<\pm 100$ mV or if the DC content of the signal is important.</p>
Reference Level	<p>The Reference Level field defines the top power level line on the plot field's vertical scale. Power levels can be measured at any point on the trace in conjunction with the Horizontal Time/div setting.</p>
Horizontal	<p>The horizontal setting defines the scale and position of the time axis of the display.</p> <p>Unit</p> <p>Unit selects whether the horizontal scale is represented in seconds (s), milliseconds (ms) or microseconds (μs).</p> <p>Time/Div</p> <p>The horizontal scale selects the amount of time represented by each division (Time/Div) on the plot's horizontal axis.</p>
Vertical	<p>The vertical scale selects the number of units of measurements per division on the plot's vertical axis.</p> <p>When Audio In is selected as the input port, the unit of measurement is Volts or milliVolts.</p> <p>When Demod is selected as the input port, the units will be as follows based on the RF Received Demodulation Type:</p> <ul style="list-style-type: none"> • FM or Digital: Hz • AM: % (percent)

5.3 Spectrum Analyzer

5.3.1 Introduction

The Spectrum Analyzer measures various performance characteristics of an applied (incoming) signal across the full frequency range of the CX100. The Spectrum Analyzer can be used to evaluate performance parameters such as power, harmonics, sidebands and phase noise of a DUT.

The Spectrum Analyzer is typically used to measure parameters of known signals, as well as locate the power and frequency of unknown signals.

5.3.2 Spectrum Analyzer Screen Layout

The **Spectrum Analyzer screen** consists of the following areas or groups of controls and settings:




Figure 5-12 Spectrum Analyzer Screen Layout

Plot Field

The plot field displays a visual representation of the received signal. Controls and settings are available that allow the user to adjust settings such as plot scale, modes of operation and the types of traces being displayed on the plot.

See section 5.3.2.3, on page 5-52 and section 5.3.2.4, on page 5-54 for a description of the controls and settings that are supported on the Spectrum Analyzer.

Marker Controls and Data Fields

The Spectrum Analyzer contains a variety of marker functions, controls and settings that allow the user to create custom test scenarios. Spectrum Analyzer markers operate in the same manner as the RF Analyzer markers. See section 5.2.9.5, “RF Analyzer Marker Controls”, on page 5-39 for information about marker controls, navigation and configuration.

Trace Legend

The trace legend indicates the trace types that are currently active, and the color of the line used to represent each trace type. The types of traces that are displayed on the plot field are selected using the **Active Trace button** located in the **Display Settings menu**.

Soft-key Panel

The soft-key panel contains controls and settings that are used to configure the RF Analyzer. See section 5.3.2.2, on page 5-51 for a description of RF Analyzer soft-keys.

5.3.2.1 Spectrum Analyzer Markers

Spectrum Analyzer markers operate in the same manner as the RF Analyzer markers. See section See section 5.2.9.5, “RF Analyzer Marker Controls”, on page 5-39 for information about marker controls, navigation and configuration.


5.3.2.2 Spectrum Analyzer Soft-key Panel

The Spectrum Analyzer soft-key panel contains the following controls:

Table 5-26 Spectrum Analyzer Soft-keys

Soft-key	Description
Display Settings Soft-key	The Display Settings soft-key opens a menu that contains controls and settings that affect display layout and manages how traces are displayed on plot fields. See section 5.3.2.3, “Spectrum Analyzer Display Settings”, on page 5-52 for a description of these settings.
Instrument Settings Soft-key	The Instrument Settings menu accesses the controls and settings that define how the Spectrum Analyzer receives and processes an incoming signal. See section 5.3.2.4, “Spectrum Analyzer Instrument Settings”, on page 5-54 for a description of these settings.

Table 5-26 Spectrum Analyzer Soft-keys (Continued)

Soft-key	Description
Normalize Soft-key	<p>The Normalize soft-key opens a settings window that contains controls and settings which are used to zero out the Spectrum Analyzer signal path, removing any residual power from the RF path which eliminates the system’s frequency response error.</p> <p>Spot Frequency</p> <p>The Spot Frequency field defines the frequency to be zeroed out. Pressing the Run Normalize soft-key initiates the process.</p>
	<p>An attention indicator is displayed on the Normalize soft-key when the system detects residual power on the signal path. When this condition occurs, Normalize should be performed to ensure accurate measurements.</p>
Pause/Resume Soft-key	<p>When the Spectrum Analyzer is displayed on the UI, the signal trace is active by default.</p> <p>Pressing the Pause soft-key stops data updates to the UI and the soft-key updates to the Resume soft-key.</p> <p>Pressing the Resume soft-key displays live trace data.</p>

5.3.2.3 Spectrum Analyzer Display Settings

The **Display Settings soft-key** opens a menu that contains controls and settings that affect display layout and manages how traces are displayed on plot fields.

Table 5-27 Spectrum Analyzer Display Settings

Control/Setting	Description
Rotate Screen	<p>The Rotate Screen soft-key switches the UI between Portrait or Landscape orientation.</p> <p>Changes orientation of plot field on the device (updates remote session when using VNC application to view the UI).</p> <p>Orientation is not stored as part of Save Trace settings.</p>

Table 5-27 Spectrum Analyzer Display Settings (Continued)

Control/Setting	Description
Active Trace Button	<p>The Active Trace button opens a window that selects the type of trace(s) to be displayed on the plot field. Multiple traces can be selected at any given time on each plot.</p> <ul style="list-style-type: none"> • Max: displays highest amplitude received • Min: displays lowest amplitude received • Live: displays live signal trace • Average: displays an averaged signal trace; average is defined by value defined in the Average field. <p>The UI contains a trace legend which shows the trace types that are currently being displayed on the plot field and the color used to represent the signal on the plot field.</p>
Average (Field)	<p>The Average field is enabled when Average is selected as the active trace. The Average field defines the number of traces to be used to calculate an average signal trace.</p>
Capture Trace Button	<p>When the Capture Trace button is pressed, a trace is “held” on the display. When more than one trace is active on a plot, only one of the active traces will be captured. When multiple trace types are enabled, traces are captured in the following priority:</p> <ul style="list-style-type: none"> • MAX Priority 1 • MIN Priority 2 • Average Priority 3 • Live Priority 4 <p>For example, if Average and Live traces are enabled, the Average trace is captured. If Max and Average traces are enabled, the Max trace is captured.</p> <p>When the Capture Trace button is pressed, the Clear Trace button is enabled which is used to remove a captured trace from the plot field.</p>
Clear Trace Button	<p>The Clear Trace button is active when a the Captured Trace button has been pressed and a trace is captured on the plot field. Pressing the Clear Trace button removes the captured trace from the plot field.</p>
Save Trace Button	<p>The Save Trace button displays a window that is used to enter a name for saving a file. The file will be saved to the location defined in System Settings. See section 4.2.7, “Specifying File Save Location”, on page 4-8.</p> <p>The Save Trace function saves x,y data in .csv file format.</p>

Table 5-27 Spectrum Analyzer Display Settings (Continued)

Control/Setting	Description
Recall Trace Button	The Recall Trace button displays a file selection box which allows user to recall a stored trace. The stored trace file can be recalled from the device or from a USB device.

5.3.2.4 Spectrum Analyzer Instrument Settings

The **Instrument Settings menu** accesses the controls and settings that define how the Spectrum Analyzer receives and processes an incoming signal.

Table 5-28 Spectrum Analyzer Instrument Settings

Control/Setting'	Description
Port	<p>The Spectrum Analyzer Port menu selects the input connector for analyzing incoming signals.</p> <p>ANT/SWR</p> <p>ANT/SWR should be selected to perform over the air testing using an external antenna or when test parameters require maximum input sensitivity. The ANT/SWR connector should be used when analyzing low level RF signals.</p> <p>DUPLEX</p> <p>DUPLEX should be used when analyzing high power RF signals. The DUPLEX connector is a combined (Duplexed) connector that provides an RF Gen output connection and an RF Receiver input connection.</p> <p>Coupling</p> <p>Resolution Bandwidth (RBW)</p> <p>RBW filters are the bandpass filters in the IF path that determine the RF Noise floor and how close two signals can be and still be viewed separately on the analyzer.</p> <p>A narrower RBW setting more clearly displays close signals as separate signals; a narrower bandwidth setting results in a longer sweep time.</p> <p>An RBW setting that is too wide causes signals that are close together to appear as one signal.</p> <p>Auto: system sets RBW to a filter appropriate to the characteristics identified in the received signal</p> <p>Manual: allows the user to manually define the RBW.</p>

Table 5-28 Spectrum Analyzer Instrument Settings (Continued)

Control/Setting	Description
	<p>Video Bandwidth (VBW)</p> <p>The Analyzer includes a low pass filter, called the video filter, in the signal path following the detector. The video filter reduces high frequency noise on the detected signal and allows low level signals to be identified which would otherwise be buried in the noise.</p> <p>The bandwidth of the video filter is called the video bandwidth, or VBW. The VBW defines the high frequency cutoff point of the filter. Any frequencies that are above the VBW value are clipped.</p> <p>VBW helps improve resolution of weak signals in the presence of the noise signal. The narrower the VBW, the less noise there is in the output signal; however, the narrower the bandwidth, the longer the sweep time.</p>
Reference Level	<p>The Reference Level field defines the top value on the plot field's vertical scale. Reference Level can be set to any value within the specified range, but should be set to a value above the expected power level of the incoming signal in order to view the full signal waveform.</p>
Frequency Mode	<p>Frequency Mode selects the method used to define the span of the analyzer plot field. Parameters update according to the type of mode selected.</p> <p>Full Span Frequency mode</p> <p>When Full Span is selected, the span defaults to the instrument's full frequency range. The UI updates to display the Start and Stop frequencies as read-only data fields.</p> <p>Center/Span Frequency Mode</p> <p>Center/Span Frequency mode of operation specifies the center frequency value as well as the frequency span setting.</p> <p>When Center/Span is selected, the UI displays a Center Frequency and Span setting. Center/Span Mode uses the sweep Center Frequency value and span setting to define the frequency span.</p>

Table 5-28 Spectrum Analyzer Instrument Settings (Continued)

Control/Setting	Description
Frequency Mode (cont)	<p>Start/Stop Frequency Mode</p> <p>Start-Stop Frequency mode of operation defines the sweep start and sweep end frequencies of the swept measurement range.</p> <p>When Start/Stop is selected, the UI displays a Start Frequency and Stop Frequency fields. The start and stop frequencies define the frequency span.</p> <p>Zero Span Frequency Mode</p> <p>In Zero Span Mode the Channel Analyzer does not perform a frequency sweep: it detects the power level at the set frequency. The trace shows detected power against time. When operating in Zero-Span Mode, marker position is specified in time.</p>
Amplitude Settings	<p>Amplitude settings affect how the plot field's vertical scaling and how the signal appears when displayed on the plot field.</p> <p>Scale</p> <p>The Spectrum Analyzer uses logarithmic scaling to display the signal amplitude on the analyzer vertical axis. Differences in signal amplitudes are compressed because low amplitude signals are amplified and high amplitude are compressed. This allows signal with widely varying amplitudes to be displayed on the same plot. Log scale is used to view both low amplitude and high amplitude frequencies with same clarity.</p> <p>Vertical Scale</p> <p>Selects the dB division between the vertical scaling on the plot field.</p>
Detector Type	<p>The Spectrum Analyzer uses detectors in order to accurately map the correct signal power to the correct frequency point on the display. The Detector Type selects the type of math that is used to identify specific information in a received signal.</p> <p>The CX100 Spectrum Analyzer provides the following detector selections:</p> <p>Peak</p> <p>When Peak is selected, the Spectrum Analyzer displays the maximum value of data sampled within the corresponding time interval for each trace point. Peak would typically be used to measure the peak power of a signal.</p>

Table 5-28 Spectrum Analyzer Instrument Settings (Continued)



Control/Setting	Description
Detector Type (cont)	<p data-bbox="651 367 850 396">Negative Peak</p> <p data-bbox="699 413 1458 579">When Negative Peak is selected, the Spectrum Analyzer displays the minimum value of data sampled within the corresponding time interval for each trace point. Negative Peak could be used to help identify CW and pulsed signals by comparing positive and negative peak values.</p> <p data-bbox="651 604 753 634">Normal</p> <p data-bbox="699 651 1433 783">For the Normal detector, if a continuously rising or falling value is detected, the most positive value is returned, otherwise the bucket processor alternates between most positive and most negative peak.</p> <p data-bbox="651 808 756 837">Sample</p> <p data-bbox="699 854 1471 1056">When Sample is selected, the Spectrum Analyzer displays the power level corresponding to the data point of the corresponding time interval. A sample detector provides a sample for each trace point on the plot field; each trace point represents a single sample evenly spaced across the Span of the frequency domain.</p> <p data-bbox="699 1073 1468 1169">A sample detector is effective for measuring noise-like signals or low power continuous wave (CW) signals that are near the Analyzer's noise floor.</p> <p data-bbox="363 1207 418 1266"> A sample detector can show an inaccurate reading for the amplitude of a CW signal if the RBW is set too narrow (reading will be too low).</p> <p data-bbox="651 1295 716 1325">RMS</p> <p data-bbox="699 1341 1468 1438">When RMS is selected, the Spectrum Analyzer displays the average power measurement calculated over the specified number of trace points.</p> <p data-bbox="699 1455 1468 1518">RMS detector would typically be used when performing EMI testing.</p> <p data-bbox="363 1556 418 1614"> NOTE</p> <p data-bbox="451 1610 1468 1673">The number of trace points is defined by the Number Points field in the Sweep controls and settings (see below).</p>

Table 5-28 Spectrum Analyzer Instrument Settings (Continued)

Control/Setting'	Description
Sweep	<p>Sweep time defines how quickly trace data is acquired and updated to the display. This setting must be fast enough to provide quick measurement results, but slow enough to allow the power values at each point to be measured.</p> <p>Number Points</p> <p>This field defines the number of data points that the Spectrum Analyzer gathers during a single measurement sweep. A higher setting results in more accurate measurement; however, a higher number of data points may result in longer acquisition time.</p> <p>Sweep Type</p> <p>When set to Auto, the instrument optimizes the Sweep Time based on the characteristics of the incoming signal.</p> <p>When set to Manual, a sweep time setting can be entered using the Sweep Time field.</p> <p>Sweep Time</p> <p>This field is enabled when Sweep Type is set to Manual. The setting allows the user to manually define the sweep time setting.</p> <p>When Sweep Type is set to Auto; the field displays the system defined sweep time setting.</p> <p>Sweep Mode</p> <p>This toggle switch selects whether the analyzer performs signal sweeps continuously, or if the analyzer performs a single sweep before being switched off.</p> <p>In Single sweep mode, the measurement is stopped after a single signal sweep.</p> <p>In Continuous mode, the analyzer measures continuously, repeating the signal sweep as long as the analyzer is ON.</p>

5.4 VSWR/DTF

5.4.1 Introduction

The VSWR/DTF test function supports Voltage Standing Wave Ratio (VSWR), Return Loss and Distance to Fault (DTF) measurements, providing the tools necessary to analyze, troubleshoot and characterize cable and antenna systems.

A cable database is provided for DTF testing. The cable database contains a list of standardized cables for quick test setup and also allows the user to add cables for customer test requirements.

5.4.2 VSWR/DTF Screen Layout and Behavior

The **VSWR/DTF screen** uses a tabbed layout which allows for quick selection between available functions. Test function screens are displayed by selecting the tab at the top of the screen, or by swiping the screen left or right. Screen layout contents are described under each test function.

5.4.3 VSWR Test Function

The VSWR test function provides users with the ability to select VSWR or Return Loss modes for calculating reflection (see [“Measurement Mode” on page 5-63](#)).

VSWR

Voltage Standing Wave Ratio (VSWR) is a measurement that represents how well an antenna's impedance is matched to the radio or transmission line to which it is connected.

The smaller the VSWR measurement, the better the antenna and transmission line match, and therefore less loss and better signal strength on the transmission line. The minimum VSWR is 1.0, which means no power is being reflected.

Return Loss

Return loss (RL) is the ratio of the reflected signal to the transmitted signal. A low return loss indicates less signal reflection and better signal strength. A high return loss indicates more signal reflection and less signal strength, indicating an issue along the transmission line.

When Return Loss is selected measurements are displayed in dB.

5.4.3.1 VSWR Screen Layout

The **VSWR screen** consists of the following areas or groups of controls and settings:




Figure 5-13 VSWR Screen Components

Function Tabs

The tabs at the top of the screen select the measurement mode or access the cable database controls and settings.

Plot Field

The plot field displays a visual representation of the received signal. Controls and settings are available that allow the user to adjust settings such as plot scale and modes of operation.

See section 5.4.3.3, on page 5-62 and section 5.4.3.4, on page 5-63 for a description of the controls and settings that are supported for VSWR tests.


Soft-key Panel

The soft-key panel contains controls and settings that are used to configure VSWR measurements. See section 5.4.3.2, on page 5-61 for a description of VSWR soft-keys.

5.4.3.2 VSWR Soft-key Panel

The VSWR soft-key panel contains the following controls:

Table 5-29 VSWR Soft-keys

Soft-key	Description
Display Settings Soft-key	<p>The Display Settings soft-key opens a menu that contains controls and settings that affect display layout and manages how traces are displayed on plot fields.</p> <p>See section 5.4.3.3, “VSWR Display Settings”, on page 5-62 for a description of these settings.</p>
Instrument Settings Soft-key	<p>The Instrument Settings menu accesses the controls and settings that define how VSWR measurements are performed.</p> <p>See section 5.4.3.4, “VSWR Instrument Settings”, on page 5-63 for a description of these settings.</p>
Calibrate Soft-key	<p>Pressing the Calibrate soft-key opens a window that contains radio buttons that select the following:</p> <p>Internal Calibration</p> <p>The internal calibration procedure is an automated procedure that utilizes the devices internal Short/Open/Load (SOL).</p> <p>External Calibration</p> <p>The external calibration procedure requires use of external equipment and connections. External procedure is a manual procedure that requires the user to configure hardware connections at various stages in the procedure. On-screen instructions are provided at various stages of the calibration procedure which guide the user through the procedure.</p>
	<p>An attention symbol is displayed on the Calibrate soft-key when calibration needs to be performed. When this condition occurs, calibration should be performed to ensure accurate measurements.</p>
Pause/Resume Soft-key	<p>Pressing the Pause soft-key temporarily halts data updates to the UI. When this occurs the soft-key updates to the Resume soft-key. Pressing the Resume soft-key restarts the VSWR measurement.</p>

5.4.3.3 VSWR Display Settings

The **Display Settings soft-key** opens a menu that contains controls and settings that affect display layout and manages how traces are displayed on plot fields.

Table 5-30 VSWR Display Settings

Control/Setting	Description
Rotate Screen	<p>The Rotate Screen soft-key switches the UI between Portrait or Landscape orientation.</p> <p>Changes orientation of plot field on the device (updates remote session when using VNC application to view the UI). Orientation is not stored as part of Save Trace settings.</p>
Active Trace Button	<p>The Active Trace button opens a window that selects the type of trace(s) to be displayed on the plot field. Multiple traces can be selected at any given time on each plot.</p> <ul style="list-style-type: none"> • Max: displays highest signal received • Min: displays lowest signal received • Live: displays live signal trace • Average: displays an averaged signal trace; average is defined by the value in the Average field.
Average (Field)	<p>The Average field is enabled when Average is selected as the active trace. The Average field defines the number of traces to be used to calculate an average signal trace.</p>
Capture Trace Button	<p>When the Capture Trace button is pressed, a trace is “held” on the display. When more than one trace is active on a plot, only one of the active traces will be captured. When multiple trace types are enabled, traces are captured in the following priority:</p> <ul style="list-style-type: none"> • MAX Priority 1 • MIN Priority 2 • Average Priority 3 • Live Priority 4 <p>For example, if Average and Live traces are enabled, the Average Trace is captured. If Max and Average traces are enabled, the Max trace is captured.</p> <p>When the Capture Trace button is pressed, the Clear Trace button is enabled which is used to remove a captured trace from the plot field.</p>
Clear Trace Button	<p>The Clear Trace button is active when a the Captured Trace button has been pressed and a trace is captured on the plot field. Pressing the Clear Trace button removes the captured trace from the plot field.</p>

Table 5-30 VSWR Display Settings (Continued)

Control/Setting	Description
Save Trace Button	The Save Trace button displays a window that is used to enter a name for saving a file. The file will be saved to the location defined in System Settings. See section 4.2.7, “Specifying File Save Location”, on page 4-8. The Save Trace function saves x,y data in .csv file format.
Recall Trace Button	The Recall Trace button displays a file selection box which allows user to recall a stored trace. The stored trace file can be recalled from the device or from a USB device.

5.4.3.4 VSWR Instrument Settings

The **Instrument Settings menu** accesses the controls and settings that define how VSWR measurements are performed.

Table 5-31 VSWR Instrument Settings

Control/Setting	Description
Measurement Mode	Measurement Mode allows the user to perform either VSWR or Return Loss (RL) measurements.
Frequency	The start and stop frequencies define the span of the plot field. Parameters update according to the type of mode selected. Start Frequency Defines the lower end of the measurement range. Stop Frequency Defines the upper end of the measurement range.
Number of Points	Defines the number of data points acquired to perform the measurement.
Vertical Scale	The Vertical Scale button opens a settings window that allows the user to manually define the vertical scale of the plot field or to use autoscale to allow the system to define the vertical scale according to detected signal characteristics. Autoscale Autoscale sets the top and bottom scale to values appropriate for the detected signal characteristics. Top of Scale Top of Scale manually defines the upper value of the plot fields vertical scale.

Table 5-31 VSWR Instrument Settings (Continued)

Control/Setting	Description
	Bottom of Scale
	This field is used to manually defines the lower value of the plot fields vertical scale.

5.4.4 DTF Test Function

Distance to Fault (DTF) is an analysis that is used to identify signal path degradation in cables and transmission lines that may be a result of conditions such as poor connections, damaged cables, or faulty antennas.

5.4.4.1 DTF Tab Layout

The **DTF Tab** consists of the following areas or groups of controls and settings:




Figure 5-14 DTF Tab Layout

Cable File Field

The field located above the plot identifies the cable file being used for performing the DTF test. This is a read only field that displays the name of the cable file that is selected on the **Cable DB tab** (see section 5.4.5, on page 5-68).

Plot Field

The plot field displays a visual representation of the measurement. Controls and settings are available that allow the user to adjust settings such as plot scale and the types of traces being displayed on the plot.

See section 5.4.3.3, on page 5-62 and section 5.4.3.4, on page 5-63 for a description of the controls and settings that are supported for DTF measurements.

Marker Controls and Data Fields

The plot field supports a variety of marker functions, controls and settings that allow the user to create custom test scenarios. DTF markers operate in the same manner as the RF Analyzer markers. See section 5.2.9.5, “RF Analyzer Marker Controls”, on page 5-39 for information about marker controls, navigation and configuration.

Trace Legend

The trace legend indicates the trace types that are currently active, and the color of the line used to represent each trace type. The types of traces that are displayed on the plot field are selected using the Active Trace button located in the Display Settings Menu.

Soft-key Panel

The soft-key panel contains controls and settings that are used to configure DTF Measurements. See section 5.4.4.2, on page 5-65 for a description of soft-keys that are supported for DTF measurements.


5.4.4.2 DTF Soft-key Panel

The DTF soft-key panel contains the following controls:

Table 5-32 DTF Soft-keys

Soft-keys	Description
Display Settings Soft-key	The Display Settings soft-key opens a menu that contains controls and settings that affect display layout and manages how traces are displayed on plot fields. DTF test function uses the same display settings that are supported in VSWR test. See section 5.4.3.3, “VSWR Display Settings”, on page 5-62 for information about Display Settings.
Instrument Settings Soft-key	The Instrument Settings menu accesses the controls and settings that define how DTF measurements are performed. See section 5.4.4.3, “DTF Instrument Settings”, on page 5-66 for a description of these settings.

Table 5-32 DTF Soft-keys (Continued)

Soft-keys	Description
Calibrate Soft-key 	<p>Calibration should be performed to ensure the accuracy of DTF measurements.</p> <p>An attention symbol is displayed on the Calibrate soft-key when the specified frequency values are outside of the calibrated frequency range and therefore a calibration needs to be performed.</p> <p>Pressing the Calibrate soft-key opens a window that contains radio buttons that select the following:</p> <p>Internal Calibration</p> <p>The internal calibration procedure is an automated procedure that utilizes the devices internal Short/Open/Load (SOL).</p> <p>External Calibration</p> <p>The external calibration procedure requires use of external equipment and connections. External procedure is a manual procedure that requires the user to configure hardware connections at various stages in the procedure. On-screen instructions are provided at various stages of the calibration procedure which guide the user through the procedure.</p> <p>Pressing the Pause soft-key temporarily halts data updates to the UI. When this occurs the soft-key updates to the Resume soft-key. Pressing the Resume soft-key restarts the VSWR measurement.</p>

5.4.4.3 DTF Instrument Settings

The Instrument Settings menu accesses the controls and settings that define how distance to fault measurements are performed.

Table 5-33 DTF Instrument Settings

Control/Setting	Description
Horizontal Range	<p>The horizontal range allows the user to specify the distance unit to use in the measurement. The selection is displayed on horizontal axis.</p>
Distance Settings	<p>Distance settings define the parameters used to evaluate the transmission line.</p> <p>Start</p> <p>The Start field defines the beginning point along the length of the cable which is the lower value of the measurement range.</p>

Table 5-33 DTF Instrument Settings (Continued)

Control/Setting	Description
Distance Settings (cont)	<p>Stop</p> <p>The Stop field defines the end point along the length of the cable which is the upper value of the measurement range.</p> <p>Step</p> <p>This Step field specifies the number of points for the measurement.</p> <p>IF Bandwidth</p> <p>This menu selects the IF bandwidth used for collecting raw data.</p> <p>Auto Alias Free Range</p> <p>Alias free distance span is used to prevent aliasing (false signals) that can occur when a fault is outside of the desired span. A larger alias free span makes it less likely for a false signal to occur, but may make the measurement take longer. When Auto Alias Free Range is selected (auto mode), the Stop Setting is multiplied by 2 to calculate the free distance span.</p> <p>When Auto Alias Free Range is not selected (manual mode), DTF measurements use the value in the Alias Free Span field.</p> <p>Alias Free Span</p> <p>This field is enabled when Auto Alias Free Range is not selected (manual mode). This field defines the Alias Free Span setting when Auto Alias Free Range is off.</p>
Vertical Scale	<p>The Vertical Scale button opens a settings window that allows the user to manually define the vertical scale of the plot field or to use autoscale to allow the system to define the vertical scale according to detected signal characteristics.</p> <p>Autoscale</p> <p>Autoscale sets the top and bottom scale to values appropriate for the detected signal characteristics.</p> <p>Top of Scale</p> <p>Top of Scale manually defines the upper value of the plot fields vertical scale.</p>

Table 5-33 DTF Instrument Settings (Continued)

Control/Setting	Description
	Bottom of Scale
	This field is used to manually defines the lower value of the plot fields vertical scale.

5.4.5 Cable Database (DB)

The Cable Database (DB) contains pre-defined cable files that allow the user to quickly select a cable to be used for performing DTF measurements. Users can also create new cable files to meet specific test scenarios and requirements.

5.4.5.1 Cable DB Tab Layout

The **Cable DB tab** consists of the following main screen components:




Figure 5-15 Cable DB tab Components

Cable Table

The cable table lists the cable configurations that are available for performing distance to fault (DTF) measurements. The table contains pre-defined cable setup files; controls and settings are provided to allow the user to configure custom cables.

Soft-key Panel

The soft-key panel contains controls that are used to manage and configure the cable database. See section 5.4.5.2, on page 5-69 for a description of the soft-keys supported in the Cable Database.

5.4.5.2 Cable DB Soft-key Panel

The **Cable Database soft-key panel** contains the following soft-keys:

Table 5-34 Cable DB Soft-keys

Soft-key	Description
Delete Soft-key	Pressing this soft-key deletes the selected cable configuration file. A confirmation dialog box will be generated which requires the user to confirm the deletion.
View/Edit Soft-key	Pressing this soft-key opens a window that displays the characteristics of the selected cable configuration file. When a user-created cable file is opened, the user can edit information as desired. Pre-configured cable files cannot be edited.
Add Soft-key	Pressing this soft-key opens a window that allows the user to create a custom cable configuration file.
Load Soft-key	Pressing this soft-key loads the selected cable file.

5.4.5.3 Cable DB Controls and Settings

The following controls and settings are used to manage the cables saved in the cable database:

Table 5-35 Cable DB Controls and Settings

Control/Setting	Description
Cable Radio Buttons	The radio button located to the left of each cable name selects the cable for editing, loading, viewing or deletion. Only one cable can be selected at any given time.
Cable Name	This field indicates the name of the cable. When editing or adding a cable, the field accepts up to 50 alphanumeric characters.
Velocity	This field is the speed (velocity of propagation) at which an electrical signal is expected to travel through a cable (in comparison to the speed of light). Velocity of propagation is calculated as a percent (%); Velocity (factor) is displayed as a decimal value.

Table 5-35 Cable DB Controls and Settings (Continued)

Control/Setting	Description
Loss	This field defines the power that a cable is expected to lose per every 100 feet traveled.

5.4.5.4 Managing Cable Database

This section provides instructions for viewing, adding, deleting, and modifying the cables information stored in the cable database.



NOTE

See [Appendix C “DTF Cable DB - Cable Values”](#) for Pre-defined cable parameters. Pre-defined cables cannot be edited or deleted.

5.4.5.4.1 Viewing Cable Information

To View Cable Data

1. Select the cable (radio button).
2. Press the **View/Edit soft-key**.
3. A window is displayed the shows cable data.

5.4.5.4.2 Editing Cable Information

To Edit a User-created Cable File

1. Select the cable (radio button).
2. Press the **View/Edit soft-key**.
3. Make desired changes.

5.4.5.4.3 Creating New Cable

To Create a Cable File

1. Press the **Add soft-key**.
2. Enter a name in the data entry field.
3. Enter the velocity of the cable that is to be tested.
4. Enter the expected loss factor.
5. Press the **Save button** to save the file.

5.4.5.4.4 Deleting a Cable

To Delete a User-created Cable File

1. Select the cable (radio button).
2. Press the **Delete** soft-key.
3. At prompt, confirm deletion.

5.5 Autotest Function

The Autotest function supports radio specific automated test scripts. The Autotest function also provides the interface to load and run the CX100's Automated Self Test procedure.

5.5.1 Autotest Screen Layout

The **Autotest** screen consists of the following areas:




Figure 5-16 AutoTest Screen Layout and Functions

User Information

Fields which identify the user and test information.

Test Table

The test table lists the test script information and provides controls and indicators for test selection and test status.

Progress Bar

The progress bar provides a visual indicator of test progress.

Soft-key Panel

The soft-key panel contains controls that are used to perform different functions within AutoTest. See section 5.4.5.2, on page 5-69 for a description of the soft-keys that are supported in Autotest.

5.5.2 Autotest Soft-key Panel

The Autotest soft-key panel contains the following soft-keys:

Table 5-36 Autotest Soft-keys

Soft-key	Description
Run Selected Soft-key	When the Run Selected Tests soft-key is pressed, the selected tests are performed.
Select All/ Unselect All	When the Select All soft-key is pressed, all tests in the table will be selected. When the Unselect All soft-key is pressed, all tests in the table will be unselected.
Pause Test Soft-key	When the Pause Test soft-key is pressed, the test sequence stops at the end of the test that is currently in progress.
Resume Soft-key	Pressing the Resume soft-key starts the test sequence from the point at which the test was paused.
Abort Soft-key	Pressing the Abort soft-key displays a user prompt which requires the user to confirm the request to stop the test. When the test is aborted, all data is lost and not retrievable.
Test Results Soft-key	When the Test Results soft-key is pressed, the screen updates to display a scrollable screen with test data. Test results cannot be viewed while a test is in progress; tests must be paused or completed before the soft-key is enabled.
Save Results Soft-key	When the Save Results soft-key is pressed, test results are automatically saved in XML format. Test results are also saved in formats that are selected using the Report Formats soft-key
Report Formats	Pressing the Report Formats soft-key displays a list of file formats that the user can select and save the test results as. The supported report formats are: PDF, HTML, JSON, and TXT.
Open Reports	Pressing the Open Reports soft-key displays a list of test results from previously run tests. The user can select a file to view. When a file is opened for viewing, other functions are available such as saving the file in a different file format or deleting the test result.

Table 5-36 Autotest Soft-keys (Continued)

Soft-key	Description
Delete Results Soft-key	Pressing Delete Results soft-key display a user prompt which requires user to confirm request to delete the results. Deleted results cannot be recovered.
SCA Settings Soft-key	The SCA Settings soft-key accesses controls and parameters that are used to configure the CX100 for operating in an SCA environment. See section 5.6.2, on page 5-75 for information.

5.5.3 Autotest Controls and Settings

The following controls and settings are used to control Autotest operation and manage and review test results:

Table 5-37 Autotest Controls and Settings

Control/Setting	Description
Tick Boxes	The tick boxes are used to select specific tests to be run; pressing the Select All soft-key enables all tick boxes.
Test Table	The test table lists separate test sequences which may be included in the loaded script/file.
Status Indicators	Indicator to the right of the test table color coded as follows to indicate individual test status: <ul style="list-style-type: none"> • Grey: when test is not selected to be included in the test run • Light blue: indicates test has been selected and has not yet been completed. • Green: indicates completed test has passed test criteria • Red: indicates completed test has failed test criteria

5.5.4 Automated Self Test

The CX100 contains an automated built in test (BIT) called the Self Test. The Self Test procedure evaluates the general functionality of the test set's generate and receive functions, instruments, and switches, to ensure the device is operating properly.

See section 6.1, "CX100 Self Test Procedure", on page 6-2 for instructions to run the CX100 self test.



NOTE

Self Test does not verify that the device is operating to performance specifications.

5.5.4.1 Self Test Descriptions

5.5.4.1.1 RF Loop-back Test

The RF Loop-back test performs a series of RF Frequency Error and RF Power measurements at various frequencies to determine if the RF Generator and RF Receiver are functioning properly.

5.5.4.1.2 Analog Modulation/Demodulation Test

The Analog Modulation/Demodulation test uses the CX100 internal modulation generators and RF Receiver to determine if the modulation generators and demodulation meters are functioning properly.

5.5.4.1.3 Audio Loop-back Test

The Audio Loop-back test compares CX100 audio measurements with the CX100's AF Generator settings to determine if the AF Generators and audio meters are functioning properly.



NOTE

This test requires an external loop-back connection between the Audio Out and Audio In connector.

5.5.4.1.4 RF Analyzer Test

The RF Analyzer test uses the CX100 RF Generator and RF Receiver to evaluate the RF Analyzer's trace data to determine if the RF Analyzer is functioning properly.

5.5.4.1.5 Digital Modulation/Demodulation Test

The Digital Modulation/Demodulation test uses the CX100 RF Generator and Modulation Generator to play a sample .aiq waveform file of known parameters to determine if digital playback and digital meters are functioning properly.

5.5.4.1.6 Spectrum Analyzer Test

The Spectrum Analyzer test uses the CX100 RF Generator and RF Receiver to evaluate Spectrum Analyzer trace data to ensure the Spectrum Analyzer is functioning properly.

5.5.4.1.7 VSWR/DTF Test

5.6 SCA Capability

The CX100 hosts a Software Communication Architecture (SCA) Core Framework that implements the latest SCA version 4.1 full profile and supports backwards compatibility profile for SCA version 2.2.2. The CX100 offers a version of the Autotest function that has been implemented as a SCA application.

5.6.1 Launch SCA Autotest

To Launch SCA Autotest

1. Open the AutoTest application.
2. Select **SCA Self Test** from the **Model List menu**.
3. The SCA application implements the standard test table interface. From this interface it is possible to use an SCA compliant runtime tool like *eCo Inspector* to launch the different self tests and obtain results.

5.6.2 SCA Controls and Settings

The SCAAutotest function uses the same controls and settings use in the CX100 AutoTest function.

Control/Setting	Description
SCA Settings soft-key	The SCA Settings soft-key opens a settings window that displays the IP address being used by the SCA Core Framework. The IP address is required for connecting an SCA compliant runtime tool like <i>eCo Inspector</i> to launch the different self tests and obtain results.
Domain Manager IP Address	This field defines the IP Address of the CX100 port to which the SCA Core Framework is connected.

5.6.2.1 Establish SCA Connection

The following procedure is used to connect the CX100 to an external computer in order to run SCA test scripts on the device.

To Establish an SCA connection

1. Connect the CX100 to the computer on which the SCA tools have been installed.
2. Identify the CX100 port IP address.
3. Press the **SCA Settings soft-key**.
4. Enter the IP address of the CX100 port.

5.7 Settings


The RF Instrument **Settings button** accesses device test and measurement settings. These controls and settings are applicable to all RF Instrument test and measurement functions.

5.7.1 Frequency Reference

The **10 MHz Reference Clock button** accesses the controls for configuring the internal/external frequency reference. The CX100 can be configured to use the device's internal frequency reference or an external frequency reference as a timing reference.

Table 5-38 Frequency Reference Controls/Settings

Control/Setting	Description
Internal	Uses the device's internal frequency reference as a timing source.
Internal w/Ref Out	Routes the device's internal frequency reference to the Reference Out connector .
External Reference	Selects an external reference as timing source.

 A valid 10 MHz external reference must be connected to the CX100 **10 MHz Frequency Reference I/O connector** to use the External option.

Performing Tests and Measurements

This chapter provides step by step instructions for configuring the CX100 to perform the following tests:

- [CX100 Self Test Procedure](#) 6-2
- [FM Transmitter Testing](#) 6-3
- [AM Transmitter Testing](#) 6-10
- [FM Receiver Performance Tests](#) 6-16
- [AM Receiver Tests](#) 6-22
- [Performing VSWR/DTF Testing](#) 6-28
- [Performing Distance to Fault \(DTF\) Tests](#) 6-31

This chapter does not provide instructions for navigating or accessing functions, nor does it contain detailed information about test and measurement functions and settings. Refer to the following chapters for applicable information:

See [Chapter 3 “System and Utility Function Descriptions”](#) for detailed descriptions of the system utility panels and parameters.

See [Chapter 4 “Configuring System Settings”](#) for procedures to configure system settings.

See [Chapter 5 “RF Instrument Function Descriptions”](#) for detailed descriptions of the RF test and measurements panels and parameters.

6.1 CX100 Self Test Procedure

6.1.1 Scope of Test

The following procedure runs the CX100 automated self-test procedure.



NOTE

Self Test is intended to verify the device is operating properly; Self Test does not verify that the device is operating to performance specifications.

6.1.2 Equipment Needed

An external audio cable is required for the audio loopback test.

6.1.3 Running Self-test

To Run the Self Test Procedure

1. Power on the CX100.
2. Expand **RF Instrument tab** on the CX100.
3. Press the **AutoTest button** to open the AutoTest application.
4. Select **Self Test** from the test list.
5. Press the **Select All soft-key**.
6. Press the **Run Selected soft-key**.
7. Wait while the device performs a series of automated test process. Do not interrupt this process or the self test will fail.
8. Status indicators show when self test is finished.

6.2 FM Transmitter Testing

6.2.1 Scope of Test

This test is used to evaluate the following performance characteristics of an FM Transmitter:

- Transmitter Power
- Transmitter Frequency
- Transmitter Distortion
- Voice Modulation Level
- Squelch Tone Frequency
- Squelch Tone Modulation Level

6.2.2 UUT Parameters/Characteristics

The example in this section assumes the following UUT characteristics and settings; adjust settings according to the operational capabilities of the UUT.

Table 6-1 FM Transmitter Test - UUT Settings

Parameter	Setting
Transmit Frequency	151.1 MHz
Transmit Power	5 Watts
Transmit Modulation	FM
Maximum Deviation	2.5 kHz
Maximum Modulation Frequency	3 kHz
Microphone/Mod Input	AC Coupled, Hi-Z
Modulation Input Level for Test Deviation	20 mV
Squelch Tone Deviation	500 Hz
Squelch Tone Frequency	67 Hz

6.2.3 Equipment Needed

The following equipment is required to perform the test procedures defined in this section:

- CX100 ComXpert
- Audio cable and MIC/Audio Adapter combination capable of interfacing an audio signal from the CX100 audio output to the transmitter modulation input (typically the microphone input on the transmitter).
- RF Coaxial Cable

6.2.4 Test Setup

6.2.4.1 Hardware Setup Diagram

Connect the CX100 and UUT as shown in Figure 6-1, then proceed to the next section.




Figure 6-1 FM Transmitter Test Setup Diagram

6.2.4.2 Configure the CX100 Receiver

In this example, the CX100 RF Receiver uses the following settings:

Table 6-2 FM Transmitter Test - RF Receiver Settings

Parameter	Setting
Rx Port	DUPLEX
Rx Frequency	151.100000 MHz
Rx External Attenuator	0.0 dB
Reference level	37.0 dBm
Demodulation Type	FM
IF Bandwidth	12.5 kHz
AF Filter	Band-Pass
Low-Pass Corner Frequency	300 Hz
High-Pass Corner Frequency	3 kHz
De-Emphasis	0 μ s

To Configure the CX100 RF Receiver:

1. Power on the CX100.
2. Launch the **RF Instrument** application on the CX100.
3. Select **RF Test**.
4. Select either **Duplex** or **Tx Test tab**.



NOTE

If operating in Duplex Mode, verify RF Generator is turned OFF.

5. Open the **RF Receiver panel**.
6. RF Receiver **Port**: select **DUPLEX**.
7. RF Receiver **Frequency**: set to **151.1 MHz**.
8. RF Receiver **External Attenuator**: set to **0.0 dB**.



NOTE

The expected transmit power of the UUT is 5 Watts (37 dBm), which is well below the maximum input power of the CX100 (47 dBm), so no external attenuator is required for this test.

9. RF Receiver **Reference Level**: set to **37.0 dBm**.

- 10. RF Receiver **Demodulation Type**: select **FM**.
- 11. RF Receiver **IF Bandwidth**: select **12.5 kHz**.



NOTE

To Calculate Proper Bandwidth

The UUT Transmitter Bandwidth can be determined with Carson's Rule (Sinusoidal Tone):

$$2 \times [\text{Maximum Deviation} + \text{Maximum Audio Frequency}]$$
$$2 \times [3 \text{ kHz} + 3 \text{ kHz}] = 12 \text{ kHz}$$

The formula above provides the value, which in this example is 12 kHz, that is used to determine the proper setting for the CX100 IF Bandwidth. In this example, the closest CX100 IF Bandwidth greater than 12 kHz is 12.5 kHz IF Bandwidth, therefore, in this example procedure, 12.5 kHz is selected for the CX100 RF Receiver IF Bandwidth.

AF Filter Selection

When the UUT is keyed, it generates a 67 Hz squelch tone. To determine the voice modulation level and distortion, the 67 Hz tone must be filtered out so that only the 1 kHz test tone is received by the CX100 when measuring these parameters.

In this example, a Band Pass filter is selected so that frequencies lower than 300 Hz will not be received by the CX100 Receiver, and frequencies higher than 3 kHz are also blocked so as not to interfere with the 1 kHz test tone.

6.2.4.3 Configure the CX100 AF Function Generator

In this example, the CX100 AF Function Generator uses the following settings:

Table 6-3 FM Transmitter Test - AF Function Generator Settings

Parameter	Setting
Encode Type	Single Tone
Coupling	AC
Load Impedance	HiZ
AF Generator 1	
Frequency	1.0000 kHz
Level Type	Vrms
Level	0.02 V
Waveform	Sine
AF Gen 1	OFF
AF Generator 2	
AF Gen 2	OFF

To Configure the CX100 AF Function Generator:

1. Open the **AF Function Generator** panel.
2. Select the **Settings** soft-key.
3. AF Function Generator **Coupling**: select **AC**.
4. AF Function Generator **Load Impedance**: select **HiZ**.
5. AF Generator 1 **Frequency**: set to **1 kHz** (test modulation frequency).
6. AF Generator 1 **Level Type**: select **Vrms**.
7. AF Generator 1 **Level**: set to **0.02 V**.
8. AF Generator 1 **Waveform**: select **SINE**.
9. Set **AF Gen 1** soft-key to **OFF**.
10. Set **AF Gen 2** soft-key to **OFF**.

6.2.4.4 Configure the CX100 Meters



NOTE

This example does not use upper and lower limits to define pass/fail criteria. Pass/fail criteria can be entered as upper and lower limit values in each meter menu for visual feedback of pass/fail status.

To Configure the CX100 Meters

1. Open the **Meters panel**.
2. Use the **Analog Demod Measurements > Distortion/SINAD/SNR soft-key** to display the **Distortion Meter**.
3. Open the **RF Power Meter configuration window**.
4. Upper and Lower Limit values can be assigned if pass/fail criteria are known.
5. **Power Meter Measurement Type**: select **Live**.



NOTE

Before proceeding to Step 8, cease transmitting signals to the CX100.

6. Set the **Measurement Type** on the following meters to **Live**:
 - Modulation
 - Distortion
 - AF Counter
 - RF Frequency Error
7. Select RF Analyzer and press the **Normalize** key.
8. Press the **Run Normalize** soft-key to normalize the **RF Power Meter**.

6.2.5 Gathering Test Data

6.2.5.1 Viewing Test Data

Open either the **Test Setup Summary panel** or the **Meters panel**.



NOTE

If upper and lower limits are being used, recommendation is to view results on the Meters panel instead of the Test Setup Summary panel in order to utilize the color coded pass/fail indicators on meters.

6.2.5.2 Test UUT Power and Frequency

1. Key the UUT.
2. Review the **RF Power Meter** reading along with overall settings.
3. Review the **RF Frequency Error** reading.
4. Unkey the UUT.

6.2.5.3 Test UUT Modulation Level and Transmitter Distortion

1. Open the **AF Function Generator** panel.
2. Set **AF Gen 1 soft-key** to **ON**.
3. Open the **Test Setup Summary** panel.
4. Key the UUT and hold.
5. Review the **Modulation Meter** reading.
6. Review the **Distortion Meter** reading along with overall settings.
7. Unkey the UUT.

6.2.5.4 Test UUT Squelch Tone Modulation Level and Frequency

1. Open the **RF Receiver** panel.
2. Open the **Test Setup Summary** panel.
3. Key the UUT and hold.
4. Review the **Modulation Meter** reading.
5. Review the **AF Counter** reading along with overall settings.
6. Unkey the UUT.

6.3 AM Transmitter Testing

6.3.1 Scope of Test

This section explains how to configure the CX100 to evaluate the transmit performance of an AM device. The test setup in this section can be used to evaluate the following UUT parameters:

- AM Transmitter Power
- AM Transmitter Frequency
- Modulation Level
- Transmitter Distortion

6.3.2 UUT Parameters/Characteristics

The example in this section assumes the following UUT characteristics and settings; adjust settings according to the operational capabilities of the UUT.

Table 6-4 AM Transmitter Test - UUT Settings

Parameter	Setting
Transmit Frequency	116.5 MHz
Transmit Power	50 Watts
Transmit Modulation	AM
Maximum Modulation Index	100%
Maximum Modulation Frequency	3 kHz
Microphone/Mod Input	DC Coupled, 600 Ohm
Modulation Input Level for Test Modulation	30 mVrms

6.3.3 Equipment Needed

The following equipment is required to perform the test procedures defined in this section:

- CX100 ComXpert
- Audio cable and MIC/Audio Adapter combination capable of interfacing an audio signal from the CX100 audio output to the transmitter modulation input (typically the microphone input on the transmitter).
- Two RF Coaxial Cables
- 10 dB RF Attenuator

6.3.4 Test Setup

6.3.4.1 Hardware Setup Diagram

Connect the CX100 and UUT as shown in Figure 6-2, then proceed to the next section.




Figure 6-2 AM Transmitter Test Setup Diagram

6.3.4.2 Configure the CX100 Receiver

In this example, the CX100 RF Receiver uses the following settings:

Table 6-5 CX100 Settings - RF Receiver Settings

Parameter	Setting
Rx Port	DUPLEX
Rx Frequency	116.500000 MHz
Rx External Attenuator	10.0 dB
Reference level	37.0 dBm
Demodulation Type	AM
IF Bandwidth	6.25 kHz
AF Filter	Band-Pass
Low-Pass Corner Frequency	3 kHz
High-Pass Corner Frequency	300 kHz
De-Emphasis	0 μ s

To Configure the CX100 RF Receiver:

1. Power on the CX100.
2. Launch the **RF Instrument** application on the CX100.

3. Select **RF Test**.
4. Select either **Duplex** or **Tx Test** tab.



NOTE

If operating in Duplex Mode, verify RF Generator is turned OFF.

5. Open the **RF Receiver panel**.
6. RF Receiver **Port**: select **DUPLEX**.
7. RF Receiver **Frequency**: set to **116.5 MHz**.
8. RF Receiver **Reference Level**: set to **37 dBm**.



NOTE - Use of External Attenuator

The expected transmit power of the UUT is 50 Watts (47 dBm) which is the maximum input power of the CX100, so an external attenuator is required for this test.

The UUT transmits at 47 dBm through the 10 dB external attenuator, reducing the amplitude received by the CX100 to 37 dBm (5 W), therefore the Reference Level of the CX100 is set to 37 dBm so that the power measurements factor in external attenuation to reflect the actual power generated by the UUT.

9. RF Receiver **Demodulation Type**: select **AM**.
10. RF Receiver **IF Bandwidth**: select **6.25 kHz**.



NOTE - IF Bandwidth Selection

For this test, the UUT will generate AM using a 1 kHz tone, which is a narrow-band signal, so the IF Bandwidth is set to the narrowest setting of 6.25 kHz.



NOTE - AF Filter Selection

The UUT distortion is specified as being measured with a 300 Hz to 3 kHz band pass filter, so the AF Filter field is set to Band Pass to filter.

6.3.4.3 Configure the CX100 AF Function Generator

In this example, the CX100 AF Function Generator uses the following settings:

Table 6-6 AM Transmitter Test - AF Function Generator Settings

Parameter	Setting
Encode Type	Single Tone
Coupling	DC
Load Impedance	600 Ω
AF Generator 1	
Frequency	1.0000 kHz
Level Type	Vrms
Level	0.03 V
Waveform	Sine
AF Gen 1	OFF
AF Generator 2	
AF Gen 2	OFF

To Configure the CX100 AF Function Generator:

1. Open the **AF Function Generator** panel.
2. AF Function Generator **Coupling**: press the settings soft key and select **coupling DC**.
3. AF Generator 1 **Load Impedance**: select **600 Ω** .
4. AF Generator 1 **Frequency**: set to **1 kHz**.
5. AF Generator 1 **Level Type**: select **Vrms**.
6. AF Generator 1 **Level**: set to **0.03 V**.
7. AF Generator 1 **Waveform**: select **Sine**.
8. Set **AF Gen 1 soft-key** to **OFF**.
9. Verify **AF Gen 2 soft-key** is set to **OFF**.

6.3.4.4 Configure the CX100 Meters



NOTE

This example does not use upper and lower limits to define pass/fail criteria. Pass/fail criteria can be entered as upper and lower limit values in each meter menu for visual feedback of pass/fail status.

RF Power Meter

1. Open the **Meters Configuration Window**.
2. Use the **Analog Demod Measurements > Distortion/SINAD/SNR soft-key** to display the **Distortion Meter** on the **Meters panel**.
3. Open the **RF Power Meter configuration window**.
4. Upper and Lower Limit values can be assigned if pass/fail criteria are known.
5. **Power Meter Measurement Type**: select **Live**.



NOTE

Before proceeding to Step 8, cease transmitting signals to the CX100.

6. Set the **Measurement Type** on the following meters to **Live**:
 - Modulation Meter
 - Distortion Meter
 - AF Counter Meter
 - RF Frequency Error Meter
7. Select RF Analyzer and press the **Normalize** key.
8. Press the **Run Normalize** soft-key to normalize the **RF Power Meter**.

6.3.5 Gather Test Data

6.3.5.1 Viewing Test Data

Open either the **Test Setup Summary** panel or the **Meters** panel.



NOTE

If upper and lower limits are being used, recommendation is to view results on the Meters panel in order to utilize the color coded pass/fail indicators on meters.

6.3.6 Test UUT Power and Frequency

1. Key the UUT.
2. Review the **RF Power Meter** reading along with overall settings.
3. Review the **RF Frequency Error Meter** reading.
4. Unkey the UUT.

6.3.7 Test UUT Modulation Level and Distortion

1. Open the **AF Function Generator** panel.
2. Set **AF Gen 1 soft-key** to **ON**.
3. Open the **Test Setup Summary** panel.
4. Key the UUT and hold.
5. Review the **Modulation Meter** reading.
6. Review the **Distortion Meter** reading along with overall settings
7. Unkey the UUT.

6.4 FM Receiver Performance Tests

6.4.1 Scope of Test

This test is used to evaluate the following performance characteristics of an FM Receiver:

- Radio Receive Sensitivity
- Squelch Tone Response
- Audio Level

6.4.2 UUT Parameters/Characteristics

The example in this section assumes the following UUT characteristics and settings; adjust settings according to the operational capabilities of the UUT.

Table 6-7 FM Receiver Test - UUT Parameters

Parameter	Setting
FM Receiver	Narrowband
FM Receiver Frequency	151.1 MHz
Rate Deviation	2.5 kHz
Distortion	Less than 1% at 700 mV audio level
12 dB SINAD	-118 dBm
Squelch Tone Deviation	350 Hz
Squelch Tone Frequency	67 Hz

6.4.3 Equipment Needed

The following equipment is required to perform the test procedures defined in this section:

- CX100 ComXpert
- Audio cable and MIC/Audio Adapter combination capable of interfacing an audio signal from the UUT demodulated output (typically speaker out signal) to the CX100 audio input connector.
- RF Coaxial Cable

6.4.4 Test Setup

6.4.4.1 Hardware Setup Diagram

Connect the CX100 and UUT as shown in [Figure 6-3](#), then proceed to the next section.




Figure 6-3 FM Receiver Test Setup Diagram

6.4.4.2 Configure the CX100 RF Generator

In this example, the CX100 RF Generator uses the following settings:

Table 6-8 CX100 Settings - RF Generator Settings

RF Generator	
Frequency	151.100000 MHz
Output Level	-50 dBm

To Configure the CX100 RF Generator:

1. Power on the CX100.
2. Launch the **RF Instrument** application on the CX100.
3. Select **RF Test**.
4. Select either **Duplex** or **Rx Test** tab.
5. Open the **RF Generator** panel.
6. RF Generator **Frequency**: set to **151.1 MHz**.
7. RF Generator **Output Level**: set to **-50 dBm**.
8. Turn on **RF Generator**.

6.4.4.3 Configure the CX100 Modulation Generators

In this example, the CX100 Modulation Generators use the following settings:

Table 6-9 FM Receiver Test- Modulation Generator Settings

Modulation Generator 1	
Type	FM
Deviation	1.8 kHz
Rate	1 kHz
Waveform	Sine
Mod 1 soft-key	Mod 1 ON
Modulation Generator 2	
Type	FM
Deviation	350 Hz
Rate	0.067 kHz
Waveform	Sine
Mod 2 soft-key	Mod 2 ON
External Modulation	
Mod Ext soft-key	Mod Ext OFF

To Configure the CX100 Modulation Generators:

1. Open the **Modulation Generator 1** panel.
2. Modulation Generator 1 **Modulation Type**: select **FM**.
3. Modulation Generator 1 **Deviation**: set to **1.8 kHz** (60% of 2.5 kHz max deviation rating of radio).
4. Modulation Generator 1 **Rate**: set to **1.000 kHz**.
5. Modulation Generator 1 **Waveform**: select **Sine**.
6. **Mod 1 soft-key**: set to **ON**.
7. Open the **Modulation Generator 2** panel.
8. Modulation Generator 2 **Modulation Type**: select **FM**.
9. Modulation Generator 2 **Deviation**: set to **350 Hz**.
10. Modulation Generator 2 **Rate**: set to **0.0670 kHz**.
11. Modulation Generator 2 **Waveform**: select **Sine**.
12. **Mod 2 soft-key**: set to **ON**.

13. Open the **External Modulation** panel.
14. **Mod Ext soft-key**: set to **OFF**.

6.4.5 Configure the CX100 Meters



NOTE

Meter parameters should be configured according to UUT performance characteristics and test requirements.

In this example, the CX100 Meters are configured as follows:

Table 6-10 FM Receiver Test - Meter Settings

SINAD Meter	
Enable Lower Limit	Enabled
Lower Limit	12.0 dB
Measurement Type	Average
Average Count	20
Distortion Meter	
Enable Upper Limit	Enabled
Upper Limit	1%
Measurement Type	Live
Audio Level Meter	
Enable Upper Limit	Enabled
Upper Limit	+0.710 V
Enable Lower Limit	Enabled
Lower Limit	+0.690 V
Measurement Type	Live
AF Counter	
Enable Upper Limit	Disabled
Enable Lower Limit	Disabled
Measurement Type	Live

To Configure the CX100 Meters:

1. Open the **Meters** panel.
2. Use the **Audio Measurements > Distortion/SINAD/SNR** soft-key to display the **SINAD Meter** on the **Meters** panel.
3. Open the **SINAD Meter configuration window**.
4. Enable the **Lower Limit**.
5. Set the **Lower Limit** to **12.0 dB**.
6. Select **Average** from the **Measurement Type** menu.
7. Set **Average Count** to **20**.
8. Close the **SINAD Meter configuration window**.
9. Use the **Audio Measurements > Distortion/SINAD** soft-key to display the **Distortion Meter**.
10. Open the **Distortion Meter configuration window**.
11. Enable the **Upper Limit**.
12. Set the **Upper Limit** to **1%**.
13. Select **Live** from the **Measurement Type** menu.
14. Close the **Distortion Meter configuration window**.
15. Open the **Audio Level Meter configuration window**.
16. Enable the **Upper Limit**.
17. Set the **Upper Limit** to **+0.710 V**.
18. Enable the **Lower Limit**.
19. Set the **Lower Limit** to **+0.690 V**.
20. Select **Live** from the **Measurement Type** menu.
21. Close the **Audio Level Meter configuration window**.
22. Set the **Audio Level Meter Vrms/Vpp** toggle soft-key to **Vrms**.
23. Open the **AF Counter Meter configuration window**.
24. Select **Live** from the **Measurement Type** menu.
25. Close the **AF Counter Meter configuration window**.

6.4.6 Gather Test Data

6.4.6.1 Viewing Test Data



Open either the **Test Setup Summary** panel or the **Meters** panel.



NOTE

If upper and lower limits are being used, recommendation is to view results on the Meters panel in order to utilize the color coded pass/fail indicators on meters.


6.4.6.2 UUT Audio Level and Distortion Tests

1. Adjust the UUT volume until the **Audio Level Meter** displays approximately 700 mV and the meter background color is green and the pass  icon is displayed.
2. Verify the **Distortion Meter** displays less than 1% distortion and the meter background color is green and the pass  icon is displayed.

6.4.6.3 UUT Squelch Tone Function Tests

1. Turn **Mod 2 soft-key** to **OFF**.
2. Observe the **Audio Level Meter** to verify the UUT is quieted, and that the **AF Counter** does not display 1.000 kHz audio.
3. Turn **Mod 2 soft-key** to **ON**.
4. Use the **Audio Level Meter** to verify the UUT is demodulating the CX100 modulation, and that the **AF Counter** displays 1.000 kHz audio.

6.4.6.4 UUT Receiver Sensitivity Tests

1. Set the CX100 **RF Generator Level** to -118.000 dBm.
2. **Audio Measurements > Distortion/SINAD soft-key** - select **SINAD** to display the **SINAD Meter** on the **Rx Test Meters** panel.
3. Press the **Rx Test Meters Clear/Reset soft-key**.
4. Observe the **SINAD Meter** and verify its reading is 12 dB or greater, and that the meter background color is green and the pass  icon is displayed.

6.5 AM Receiver Tests

6.5.1 Scope of Test

This test is used to evaluate the following performance characteristics of an AM Receiver:

- Radio Receive Sensitivity
- Squelch Tone Response
- Audio Level

6.5.2 UUT Parameters/Characteristics

The example in this section assumes the following UUT characteristics and settings; adjust settings according to the operational capabilities of the UUT.

Table 6-11 AM Receiver Test - UUT Parameters

Parameter	Setting
AM Receiver	Narrowband
AM Receiver Frequency	151.1 MHz
Distortion	Less than 1% at 700 mV audio level
12 dB SINAD	-118 dBm

6.5.3 Required Equipment

The following equipment is required to perform the test procedures defined in this section:

- CX100 ComXpert
- Audio cable and MIC/Audio Adapter combination capable of interfacing an audio signal from the UUT demodulated output (typically speaker out signal) to the CX100 audio input connector.
- RF Coaxial Cable

6.5.4 Configuring the Equipment

6.5.4.1 Hardware Configuration

Connect the CX100 and UUT as shown in Figure 6-4, then proceed to the next section.




Figure 6-4 AM Receiver Test - Setup Diagram

6.5.4.2 Set Up the CX100 RF Generator

In this example, the CX100 RF Generator uses the following settings:

Table 6-12 AM Receiver Test - RF Generator Settings

RF Generator	
Frequency	151.100000 MHz
Output Level	-50 dBm

To Set Up the CX100 RF Generator:

1. Power on the CX100.
2. Launch the **RF Instrument** application on the CX100.
3. Select **RF Test**.
4. Select either **Duplex** or **Rx Test** tab.
5. Open the **RF Generator** panel.
6. RF Generator **Frequency**: set to **151.1 MHz**.
7. RF Generator **Output Level**: set to **-50 dBm**.

6.5.4.3 Set Up the CX100 Modulation Generators

In this example, the CX100 Modulation Generators use the following settings:

Table 6-13 AM Receiver Test - Modulation Generator Settings

Modulation Generator 1	
Type	AM
Rate	1 kHz
Depth	60%
Waveform	Sine
Mod 1 soft-key	Mod 1 ON
Modulation Generator 2	
Type	AM
Rate	0.067 kHz
Depth	50%
Waveform	Sine
Mod 2 soft-key	Mod 1 ON
External Modulation	
Mod Ext soft-key	Mod Ext OFF

To Set Up the CX100 Modulation Generators:

1. Open the **Modulation Generator 1** panel.
2. Modulation Generator 1 **Modulation Type**: select **AM**.
3. Modulation Generator 1 **Rate**: set to **1.000 kHz**.
4. Modulation Generator 1 **Depth**: set to **60%**.
5. Modulation Generator 1 **Waveform**: select **Sine**.
6. **Mod 1 soft-key**: set to **ON**.
7. Open the **Modulation Generator 2** panel.
8. **Mod 2 soft-key**: set to **OFF**.
9. Open the **External Modulation** panel.
10. **Mod Ext soft-key**: set to **OFF**.

6.5.5 Configure CX100 Meters



NOTE

Meter parameters should be configured according to UUT performance characteristics and test requirements.

In this example, the CX100 Meters are configured as follows:

Table 6-14 AM Receiver Test - Meter Settings

SINAD Meter	
Enable Lower Limit	Enabled
Lower Limit	10.0 dB
Measurement Type	Average
Average Count	20
Distortion Meter	
Upper Lower Limit	Enabled
Upper Limit	1%
Measurement Type	Live
Audio Level Meter	
Enable Upper Limit	Enabled
Upper Limit	+0.710 V
Enable Lower Limit	Enabled
Lower Limit	+0.690 V
Measurement Type	Live
AF Counter	
Enable Upper Limit	Disabled
Upper Limit	N/A
Enable Lower Limit	Disabled
Measurement Type	Live

To Set Up the CX100 Meters:

1. Open the **Meters** panel.
2. Use the **Audio Measurements > Distortion/SINAD** soft-key to display the **SINAD Meter**.
3. Open the **SINAD Meter configuration window**.
4. Enable the **Lower Limit**.
5. Set the **Lower Limit** to **12.0 dB**.
6. Select **Average** from the **Measurement Type** menu.
7. Set **Average Count** to **20**.
8. Close the **SINAD Meter configuration window**.
9. Use the **Audio Measurements > Distortion/SINAD** soft-key to display the **Distortion Meter**.
10. Open the **Distortion Meter configuration window**.
11. Enable the **Upper Limit**.
12. Set the **Upper Limit** to **1%**.
13. Select **Live** from the **Measurement Type** menu.
14. Close the **Distortion Meter configuration window**.
15. Open the **Audio Level Meter configuration window**.
16. Enable the **Upper Limit**.
17. Set the **Upper Limit** to **+0.710 V**.
18. Enable the **Lower Limit**.
19. Set the **Lower Limit** to **+0.690 V**.
20. Select **Live** from the **Measurement Type** menu.
21. Close the **Audio Level Meter configuration window**.
22. Set the **Audio Level Meter Vrms/Vpp** toggle soft-key to **Vrms**.
23. Open the **AF Counter Meter configuration window**.
24. Select **Live** from the **Measurement Type** menu.
25. Close the **AF Counter Meter configuration window**.

6.5.6 Gather Test Data

6.5.6.1 Viewing Test Data



Open either the **Test Setup Summary panel** or the **Meters panel**.




NOTE

If upper and lower limits are being used, recommendation is to view results on the Meters panel in order to utilize the color coded pass/fail indicators on meters.

6.5.6.2 Test UUT Audio Level and Distortion

1. Adjust the UUT volume until the **Audio Level meter** displays reading around 700 mV and the meter background color is green and the pass  icon is displayed.
2. Verify the **Distortion meter** reading is less than 1% Distortion and that the background color is green and the pass  icon is displayed.

6.5.6.3 Test UUT Receiver Sensitivity

1. Change the CX100 **RF Generator Level** to **-118.000 dBm**.
2. Use the **Audio Measurements > Distortion/SINAD soft-key** to display the **SINAD Meter** on the **Rx Test Meters panel**.
3. Press the **Rx Test Meters Clear/Reset soft-key**.
4. Observe the **SINAD Meter** and verify its reading is 12 dB or greater, and that the meter background color is green and the pass  icon is displayed.

6.6 Performing VSWR/DTF Testing

6.6.1 Scope of Test

This test is used to evaluate how well an antenna’s impedance matches the impedance of the radio or transmission line to which it is connected.

6.6.2 UUT Parameters/Characteristics

The example in this section assumes the following UUT characteristics and settings; adjust settings according to the operational capabilities of the UUT.

Table 6-15 VSWR Test - Example Cable Characteristics

Parameter	Setting
Frequency Range	30 to 85 MHz

6.6.3 Equipment Needed

The following equipment is required to perform the procedures defined in this section:

- CX100 ComXpert
- Cable to be tested
- Calibration Kit

6.6.4 Calibrate the CX100 Before VSWR Testing

6.6.4.1 Hardware Setup Diagram

Connect the CX100 and UUT as shown in [Figure 6-5](#), then proceed to the next section.




Figure 6-5 VSWR Calibration Setup Diagram

6.6.4.2 Running VSWR Calibration

1. Power on the CX100.
2. Select the **Home icon** on the CX100.
3. Select the **RF Instrument** tab at the top of the application on the CX100 screen.
4. Select **VSWR/DTF**.
5. Select the **VSWR** tab.
6. Open the **Instrument Settings** menu.
7. Press the **Calibrate** soft-key.
8. Select **External Standards**. Select **OK** button to confirm.
9. Follow the instructions on the UI to configure the device for external calibration.
10. Press the **OK** button to run the calibration. See [Figure 6-6](#).
11. When external calibration has been completed, the calibration plot should resemble data in [Figure 6-6](#).




Figure 6-6 Calibration running and complete

6.6.5 To Perform VSWR Test

6.6.5.1 Hardware Setup Diagram

Connect the CX100 and UUT as shown in Figure 6-7, then proceed to the next section.




Figure 6-7 VSWR Test Setup Diagram

6.6.5.2 Configure the CX100 VSWR Settings

In this example, the CX100 uses the following VSWR settings:

Table 6-16 CX100 VSWR Test Settings

Parameter	Setting
Start Frequency	20 MHz
Stop Frequency	100 MHz
Step Frequency	100 (points)

To Configure the CX100 for VSWR Test

1. Power on the CX100.
2. Select the **RF Instrument** tab at the top of the application on the CX100 screen.
3. Select **VSWR/DTF**.
4. Select the **VSWR** tab.
5. Open the **Instrument Settings** menu.
6. Set the **Start Frequency** to **20 MHz**.
7. Set the **Stop Frequency** to **100 MHz**.
8. Set measurement mode to **VSWR** and Press the OK button.

9. Ensure the **VSWR soft key** is set to **VSWR On**.

6.6.5.3 Gather Test Data

To Gather Test Data

This is used to gather the required Test Data.

1. Observe the VSWR trace.
2. Adjust the markers to display the VSWR measurement at the desired frequency.
3. To observe Return Loss measurement, open the Instrument Settings menu and set the measurement mode to Return Loss.

6.7 Performing Distance to Fault (DTF) Tests

6.7.1 Scope of Test

Distance to Fault (DTF) measurements, provides the capability to analyze, troubleshoot and identify signal path degradation in cables and transmission lines. Faults are a result of conditions such as poor connections, damaged cables, or faulty antennas.

This test is used to evaluate the following performance issues:

- The distance to fault of a coaxial cable.

6.7.2 UUT Parameters/Characteristics

The example in this section assumes the following UUT characteristics and settings; adjust settings according to the operational capabilities of the UUT.

Table 6-17 DTF Test - Example Cable Characteristics

Parameter	Setting
Coaxial cable type	RG58
Coaxial cable length	20 ft

6.7.3 Equipment Needed

The following equipment is required to perform the test procedures defined in this section:

- CX100 ComXpert
- Cable to best tested

6.7.4 Configuring the Equipment

6.7.4.1 Hardware Setup Diagram

Connect the CX100 and UUT as shown in Figure 6-8, then proceed to the next section.




Figure 6-8 DTF Test Setup Diagram

6.7.4.2 Configure the CX100 DTF Settings

In this example, the CX100 uses the following DTF settings:

Table 6-18 DTF Test Settings

Parameter	Setting
Start Frequency	20 MHz
Stop Frequency	100 MHz
Step Frequency	100 (points)

To Configure the CX100

1. Power on the CX100.
2. Launch the **RF Instrument** application on the CX100.
3. Select **VSWR/DTF**.
4. Select **RG-58 cable type**.
5. Select the cable file to be used for the test.
6. Select the **DTF tab**.
7. Open the instrument settings menu.
8. Set measurement mode to Return Loss
9. Select the distance key.
10. Set the start distance to 1 ft.

11. Set the stop distance to 30 ft.
12. Set number of points to 500.
13. Close the **instrument settings tab** and ensure the **DTF enable soft key** displays **DTF on**. See [Figure 6-9](#) and [Figure 6-10](#) for screen examples.




Figure 6-9 DTF (Distance to Fault) and Calibration




Figure 6-10 Return Loss

6.7.4.3 Gather Test Data

To Gather Test Data

This is used to gather the required Test Data.

1. Observe DTF trace.
2. See [Figure 6-9](#) for screen example.

Managing Files and Reports

This chapter describes how to generate reports and manage file transfer to and from the CX100. This chapter reviews the following information:

- [Generating Reports](#) 7-2
 - [Custom Report Fields](#) 7-2
 - [Enforcing Report Entry](#) 7-3
 - [Saving a Report](#) 7-3
- [Managing Files](#) 7-4
 - [Accessing the File Browser](#) 7-4
 - [Selecting Files or Folders](#) 7-5
 - [Opening Files or Folders](#) 7-5
 - [Copying and Pasting Files or Folders](#) 7-5
 - [Downloading Files via Web Browser](#) 7-6
 - [Uploading Files Using FTP/HTTP](#) 7-6
- [Viewing the User's Guide on the Device](#) 7-6

7.1 Generating Reports

Test results, configuration settings and graphs can be saved as a report using the **Save Report** function. The **Save Report** function creates reports based on the configuration settings and test results for the currently active test.



NOTE

The Save Reports button is only enabled when a test is active; the button is disabled unless a test is running.

7.1.1 Custom Report Fields

When a test report is saved, values can be configured for up to five custom “customer” report fields and five custom “technician” report fields. The values that are specified for the fields are included in the generated report output.



NOTE

Custom fields are available for selection in associated StrataSync templates.

To Add Custom Report Fields

1. Navigate to the **Save Report menu** (Utility Tray > Save Report button).
2. Perform one of the following:
 - To select and specify values for custom customer fields, select **Add Customer Report Fields**. The Customer Information menu appears.
 - To select and specify values for custom technician fields, select **Add Technician Report Fields**. The Technician Information menu appears.
3. Perform the following to create up to five custom customer fields and up to five custom technician fields:
 - a Press the field(s) that you want to include in your report.
 - b The field is selected and displayed on the Customer Information menu with a check mark (indicating that it has been selected for the report).
 - c Select the field to display a data entry screen.
 - d Enter a value for the field, then press **OK**.
 - e The specified value appears directly under the field name on the Customer Information menu.

7.1.2 Enforcing Report Entry

The test set can be configured to require that custom report fields be populated before generating and saving a report.

To Require Report Field Entry

1. Open the **System Settings** menu.
2. Select the check box next to **Enforce Report Field Entry**.
3. Press the **Back** button to save and exit the menu.

Entry of values for the custom report fields will be required before a report is saved.

7.1.3 Saving a Report

To Save a Report

1. Open the **Utility Tray**.
2. Select the **Save Report** button. The Save Report window is displayed.
3. Enter the name of the report. The default file name uses the type of test followed by a three-digit number that increments with each file saved (for example, cablecheck001 or DSL002).
4. Specify the format (PDF, XML, or HTML).



NOTE

VIAVI offers a proprietary XML schema definition file (XSD) available online (referenced in the XML report).

5. To include custom fields in the report, enable, then specify values for the fields.
6. To immediately view the report, select **Save and View**.
7. To save the report without viewing it, select **Save**.

The current test results, configuration settings, and, if applicable, graphs and custom report fields are saved as a report. If “**Save and View**” was selected, the report output also appears on the UI.

Technician report values will be saved until the values are changed. Custom report fields need to be completed for every test report saved, but you can apply the values specified the last time the report was saved.

7.1.4 Viewing a Report

Saved reports can be viewed on the device's UI.



NOTE

The **View Report** button is disabled when there are no reports saved on the device.

To View a Report

1. Open the **Utility Tray**.
2. Select **View Report button**. A View Report window appears, showing all of the saved reports.
3. Select a report to view. The report is displayed on the screen.

7.2 Managing Files

The CX100 File Browser is used to open, rename, copy, or delete saved result files, screen shots, or other files stored on device, or on a USB flash drive that is connected to device.



NOTE

When copying files to the device, note the available memory on the device's hard-drive. If the device's hard-drive is selected as the save location for all test results, and there is insufficient space available on the device's internal hard-drive, the device will not be able to save test data and test data may be lost.

7.2.1 Accessing the File Browser

Files are copied to and from the device using the File Browser.

To Open the File Browser

1. Open the **Utility Tray**.
2. Select the **File Browser button**.

7.2.2 Selecting Files or Folders

To select one or more files or folders

1. Open the **File Browser**. See section 7.2.1, “Accessing the File Browser”, on page 7-4.
2. Use the up and down arrow keys to navigate folders or files.
3. Perform the one of the following to select a folder:
 - To select a single file or folder, select the check box to the left of the file or folder.
 - To select multiple files or folders (for example, to copy multiple files to USB, or upload multiple files using FTP/ HTTP), touch the check box to the left of each folder.
4. The files or folders are selected.

7.2.3 Opening Files or Folders

To Open a File or Folder

1. Open the **File Browser**. See section 7.2.1, “Accessing the File Browser”, on page 7-4.
2. Select a file or folder. See section 7.2.2, “Selecting Files or Folders”, on page 7-5.
3. Select the **Open button**.
The contents of the folder appear or the file is displayed on the screen.

7.2.4 Copying and Pasting Files or Folders

To Copy Files or Folders

1. Open the **File Browser**. See section 7.2.1, “Accessing the File Browser”, on page 7-4.
2. Select a file or folder. See section 7.2.2, “Selecting Files or Folders”, on page 7-5.
3. Press the **File Options** system key and perform one of the following:
 - Select Copy, navigate to another folder or drive.
 - Press the **File Options** key, then select **Paste**.
 - Select either **Copy to USB** if you are using File Browser, or **Copy to Internal** if you are using the **USB File Browser**.
The file is copied and the File Browser menu appears.

7.2.5 Downloading Files via Web Browser

To Download Files from CX100 via Web Browser

1. Connect the CX100 to a network. [See section 4.4, "Establishing a Network Connection", on page 4-10.](#)
2. Record the CX100's IP Address.
3. Navigate to the **Remote screen** (System Settings > Remote).
4. Select the **Enable HTTP File Server check box**.
5. Open a web browser window.
6. Enter the CX100's IP Address in the web browser URL field.

7.2.6 Uploading Files Using FTP/HTTP

To Upload Files

1. Open the **File Browser**. [See section 7.2.1, "Accessing the File Browser", on page 7-4.](#)
2. Select a file or folder. [See section 7.2.2, "Selecting Files or Folders", on page 7-5.](#)
3. Select **File Options**.
4. Select **Upload FTP/HTTP**.
5. The Upload settings appear. Specify the Upload URL, User name, and Password.
6. Select the **Apply button** to start the upload.
7. When the upload finishes, a message appears stating that the selected files were uploaded. Press **OK** to close the dialog window.

7.3 Viewing the User's Guide on the Device

The CX100 Operation Manual can be viewed in PDF format on the device. The file must be located on a USB memory device or copied to the CX100 using File Manager.

To View the Product Manual

1. Open the **File Browser**. [See section 7.2.1, "Accessing the File Browser", on page 7-4.](#)
2. Navigate to the directory containing the pdf file.
3. Select the file name to open the document.
4. The PDF reader application launches the document.

Care, Maintenance, and Troubleshooting

This chapter reviews storage and shipping instructions as well as care and maintenance procedures for the CX100 ComXpert as well as operator level troubleshooting procedures. This chapter reviews the following topics:

- Recharging the Battery 8-2
- Replacing the Battery..... 8-2
- Storing the Module..... 8-2
- Shipping Instructions 8-2
 - Return Material Authorization (RMA) 8-3
 - Tagging the Device 8-3
 - Shipping Containers 8-3
 - Freight Costs 8-3
 - Packing Procedure 8-4
- Operator Level Maintenance 8-5
 - Visual Inspections 8-5
 - External Cleaning 8-5
 - Updating Software..... 8-6
 - CX100 ComXpert Self Test Procedure 8-6
- Troubleshooting 8-7
 - Troubleshooting Symptom Index 8-7
 - Troubleshooting Procedures 8-8

8.1 Recharging the Battery

The CX100 is designed to be powered by an internal battery or by an external AC power supply. The internal battery supports up to 3 hours of continuous operation, after which time the battery needs recharging.

To recharge the battery

1. Connect the power cord to the AC Adapter/Charger.
2. Connect the DC connector to the device's DC Input Connector. [See section 1.5.9, "DC Input Connector", on page 1-10](#) for information.
3. Connect the power cord to a grounded AC power supply.
4. Verify the device's Battery LED flashes green to indicate the battery is charging.
5. The Battery LED turns and stays green when the battery is fully charged.



CAUTION

Do not use the power cord if it is damaged or frayed. Replace damaged power cords with cable of the same ratings.

Do not position the power cord in a manner that makes it difficult to disconnect from the main voltage.

Do not allow anything to rest on the power cord.

Do not locate the product where persons can walk on or trip over the power cord.

8.2 Replacing the Battery

The CX100's RF Module and internal components are ESD sensitive and can be damaged by disassembling the device in a non-ESD environment. For this reason, the device's battery should only be replaced by qualified service personnel.

[See section B.2, "Battery Replacement Information", on page B-2](#) for battery replacement instructions.

8.3 Storing the Module

Store the module in a clean, dry place according to product specifications.

8.4 Shipping Instructions

Any device returned to factory for calibration, service or repair must be repackaged and shipped subject to the following conditions:

8.4.1 Return Material Authorization (RMA)

Do not return any products to the factory without prior authorization from VIAVI.

Refer to the following links for relevant information:

To request an RMA

<https://www.viavisolutions.com/en-us/support/customer-care/return-material-authorization-rma-request-RF-Duplexma-request-avionics-radio-test-us>

For general shipping information

<https://www.viavisolutions.com/en-us/general-shipping-instructions-avionics-radio-test-rmas>

8.4.2 Tagging the Device

All items shipped to VIAVI must be tagged with:

- Owner's Identification and contact information
- Nature of service or repair needed
- Model Number and Serial Number
- Return Authorization (RA) Number

8.4.3 Shipping Containers

Devices must be repackaged in original shipping containers using VIAVI packing materials. If original shipping containers and materials are not available, contact VIAVI for shipping instructions. Failure to properly package items being returned for warranty repair voids product warranty.

8.4.4 Freight Costs

All freight costs on non-warranty shipments are assumed by the customer. VIAVI recommends that customers obtain freight insurance with the freight carrier when shipping the device. VIAVI is not responsible for cost of repairs for damages that occur during shipment on warranty or non-warranty items.

8.4.5 Packing Procedure

8.4.5.1 Packaging CX100 for Shipping

The following procedure is for shipping the CX100 or the OneExpert base.

How to Package the device for Shipping

1. Contact VIAVI to obtain a Return Authorization number, return address and for questions about proper packaging.
2. Tag the device.
3. Place device between foam inserts.
4. Place secured device in shipping container.
5. Seal shipping container with tape.
6. Include Return Authorization number on the packaging label.

8.4.5.2 Packaging Module for Shipping

The following procedure is for shipping the RF Module independently from the base unit.

How to package the Module for shipping

1. Contact VIAVI to obtain a Return Authorization number, return address and for questions about proper packaging.
2. Tag the Module.
3. Place Module in ESD protective packaging.
4. Place packaged Module between foam inserts.
5. Place secured Module in shipping container.
6. Seal shipping container with tape.
7. Include Return Authorization number on the packaging label.



CAUTION

Modules are ESD sensitive and should only be installed, removed and/or serviced by Qualified Service Personnel.

Mise en Garde

Les modules sont sensibles aux DES et ils doivent seulement être installés, enlevés ou entretenus par du personnel de service qualifié.

8.5 Operator Level Maintenance

The following procedures may be performed by the Operator. All other service must be performed by Qualified Service Personnel.



CAUTION

This device does not contain user serviceable parts. Servicing should only be performed by Qualified Service Personnel.

Mise en Garde

Cet appareil ne contient pas de pièces pouvant être entretenues par l'utilisateur. L'entretien doit seulement être effectué par du personnel de service qualifié.



CAUTION

Do not operate this device with the case/cover open. Opening the case/cover exposes the operator to electrical hazards which can result in electrical shock or damage to the device.

Mise en Garde

N'utilisez pas cet appareil avec le boîtier/couvercle ouvert. L'ouverture du boîtier/couvercle expose l'utilisateur à des risques électriques qui peuvent entraîner un choc électrique ou des dommages à l'appareil.

8.5.1 Visual Inspections

Visual inspections should be performed periodically depending on operating environment, maintenance and use.

- Check for presence and condition of all warning labels and markings and supplied safety information.
- Inspect connectors for dirt, dust, corrosion or rust.
- Inspect the device and accessories for damage. Do not use if there is damage to the exterior of the unit or power accessories.

8.5.2 External Cleaning

- Remove grease, fungus and ground-in dirt from surfaces with soft lint-free cloth dampened (not soaked) with isopropyl alcohol.
- Remove dust and dirt from connectors with soft-bristled brush.
- When not in use, cover the connectors with suitable dust cover to prevent tarnishing of connector contacts.

8.5.3 Updating Software

The device is shipped from the factory with the operating system and firmware installed in the device. Regular checks should be performed to ensure the device contains the most current software, drivers and or firmware.

See section 4.7, “Updating the Device’s Software”, on page 4-18 for instructions to update system software.

8.5.4 CX100 ComXpert Self Test Procedure

The CX100 has an automated Built-in-Test (BIT) procedure, referred to as a Self Test, which evaluates system operation to ensure the device is operating properly.

To Run the Self Test Procedure

1. Launch the **AutoTest function** (Home > RF Instrument > Autotest button).
2. **Select the File Field** located at the top of the screen.
3. **Select Self Test** from the test list.
4. If desired, enter name in the Operator field.
5. Press the **Select All soft-key**.
6. Press the **Run Selected soft-key**.
7. Wait while the device performs a series of automated test process. Do not interrupt this process of the self test will fail.
8. Status indicators show when self test is finished.



NOTE

Self Test is intended to verify the device is operating properly; Self Test does not verify that the device is operating to performance specifications.

8.6 Troubleshooting

This sections lists Operator Level corrective actions for malfunctions which may occur during normal device operation. This section cannot list all malfunctions that may occur, nor all tests or inspections and corrective actions. Perform tests/inspections and corrective actions in order listed. If a malfunction is not listed, or is not corrected by the listed corrective actions, contact customer support.

8.6.1 Troubleshooting Symptom Index

Description	Page
Device does not power on when operating on battery power.	8-8
Device does not power on when connected to an AC power supply.	8-8
No receiving a signal at ANT/SWR or DUPLEX connector.	8-9
No generator output at ANT/SWR or DUPLEX Connector.	8-11
No input signal received at Audio In connector.	8-11
No signal output at Audio Out connector.	8-12
No input signal received or trace frozen on the Spectrum Analyzer.	8-12

8.6.2 Troubleshooting Procedures

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

Device does not power on when operating on battery power.

- 1 Is the battery charged?
 - No, charge battery. If problem persists, proceed to next step.
 - Yes, proceed to next step.
- 2 Is battery properly installed and seated in battery chamber?
 - No, reinstall battery. If problem persists, proceed to next step.
 - Yes, contact VIAVI's Technical Assistance Center (TAC).
- 3 Does the test set power on when connected to an AC Power Supply?
 - No, contact TAC.
 - Yes - probable cause of failure is old or defective battery. Contact TAC.

Device does not power on when connected to an AC power supply.

- 1 Is the AC Power Adapter/power cord the approved part for the device?
 - No, use approved part. If problem persists, proceed to next step.
 - Yes, proceed to next step
- 2 Is AC/DC Power Adapter cord securely connected to device and AC power supply?
 - No, secure AC/DC Power Adapter cord. If problem persists, proceed to next step.
 - Yes, proceed to next step.
- 3 Is AC/DC Power Adapter connected correct rated power supply?
 - No, connect to correct power supply. If problem persists, proceed to next step.
 - Yes, proceed to next step.

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

If a charged, CX100 lithium battery is available, perform the following:

- 4 Install battery in the test set. Does the test set power on?
 - Yes, probable cause is failure at AC/DC input connector, contact TAC.
 - No, contact TAC.

Display touchscreen is unresponsive.

- 1 Reboot device.
- 2 If the device is configure for VNC access, determine if the UI is operable using a VNC viewing application.

No receiving a signal at ANT/SWR or DUPLEX connector.

- 1 Is test set Receiver Port set to correct input (ANT/SWR or DUPLEX)?
 - No, set Receiver Port to correct input. If problem persists, proceed to next step.
 - Yes, proceed to next step.

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

- 2 Is cable properly connected to selected connector (ANT/SWR or DUPLEX)?
 - No, properly connect cable. If problem persists, proceed to next step.
 - Yes, proceed to next step.
- 3 Is test set Receiver Frequency set to expected receive frequency?
 - No, set Receiver Frequency to correct frequency. If problem persists, proceed to next step.
 - Yes, proceed to next step.
- 4 Is test set Receiver Bandwidth set appropriately for input signal type?
 - No, set Receiver Bandwidth correctly. If problem persists, proceed to next step.
 - Yes, proceed to next step.
- 5 Is test set Receiver Reference Level set appropriately for the input signal?
 - No, set Receiver Reference Level correctly. If problem persists, proceed to next step.
 - Yes, proceed to next step.
- 6 Is Frequency Reference set to External?
 - No, connect a valid external reference. If problem persists, contact TAC.
 - Yes, verify a valid source is connected to the test set's the 10 MHz Frequency Reference connector. If yes, contact TAC.

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

No generator output at ANT/SWR or DUPLEX Connector.

- 1 Is correct output connector selected on device (ANT/SWR or DUPLEX)?
 - No, select correct output connector. If problem persists, proceed to next step.
 - Yes, proceed to next step.
- 2 Is RF Generator output turned ON?
 - No, turn on RF Generator. If problem persists, proceed to next step.
 - Yes, proceed to next step.
- 3 Is RF Generator Frequency set to correct frequency?
 - No, set RF Generator Frequency to correct frequency. If problem persists, proceed to next step.
 - Yes, proceed to next step.
- 4 Is RF Generator Level set appropriately for UUT?
 - No, set RF Generator Level to correct setting. If problem persists, contact TAC.
 - Yes, contact TAC.

No input signal received at Audio In connector.

- 1 Is input cable properly connected to Audio In connector?
 - No, properly connect the cable. If problem persists, proceed to next step.
 - Yes, proceed to next step.
- 2 Are Audio In settings appropriate for the characteristics of the incoming audio signal (e.g. Range, Coupling, Input Sensitivity)?
 - No, adjust settings. If problem persists, contact TAC.
 - Yes, contact TAC.

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

No signal output at Audio Out connector.

- 1 Is CX100 AF Generator enabled?
 - No, turn on AF Generator. If problem persists, proceed to next step.
 - Yes, proceed to next step.
- 2 Is cable properly connected to Audio Output Connector?
 - No, properly connect the cable. If problem persists, proceed to next step.
 - Yes, proceed to next step.
- 3 Is DUT properly configured to receive signal?
 - No, correct DUT configuration. If problem persists, contact TAC.
 - Yes, contact TAC.

No input signal received or trace frozen on the Spectrum Analyzer.

- 1 Is the Spectrum Analyzer trace turned ON?
 - No, turn on trace. If problem persists, proceed to next step.
 - Yes, proceed to next step.
- 2 Is input cable properly connected to ANT/SWR or DUPLEX connector?
 - No, properly connect the cable. If problem persists, proceed to next step.
 - Yes, proceed to next step.
- 3 Is the RF input connector to which the input cable is connected selected as the Spectrum Analyzer signal source?
 - No, select correct input connector. If problem persists, proceed to next step.
 - Yes, proceed to next step.
- 4 Are RBW and Span settings set to values that provide optimal sweep time?
 - No, adjust settings to obtain optimal sweep time. If problem persists, proceed to next step.
 - Yes, proceed to next step.

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

5 Review the RF Generator Port selection.

6 Is ANT/SWR selected as the RF Generator output connector?

- Yes, reconfigure the RF Receiver and RF Generator input/output selections to avoid a configuration conflict.

The **ANT/SWR connector** does not support duplex input/output capabilities. When the **ANT/SWR connector** is selected as the RF output connector, the system disables the connector's receive capabilities. If the problem persists, contact TAC.

[See section 5.2.5.1, "RF Receiver Controls and Settings", on page 5-10](#) for more information about configuring the RF Receiver.

- No, contact TAC.

This page intentionally left blank.

Specifications

This section contains product safety and compliance specifications for the CX100 ComXpert Handheld Radio Test Set.

• RF Generator Specifications	A-2
• Modulation Generator Specifications	A-3
• Audio Frequency (AF) Function Generator Specifications	A-4
• RF Receiver Specifications	A-5
• Measurement Specifications	A-6
• AF Analyzer Specifications	A-9
• VSWR and DTF Measurement Specifications	A-10
• Audio Filter Specifications	A-11
• RF Analyzer Specifications	A-11
• Spectrum Analyzer Specifications	A-12
• Zero-Span Analyzer Specifications	A-13
• Connector Specifications	A-13
• Frequency Standard and Timebase Specifications	A-15
• Power Specifications	A-16
• Hardware Specifications	A-16
• Environmental Specifications	A-17
• Safety and Compliance Standards	A-18



NOTE

Product specifications subject to change without notice.

A.1 RF Generator Specifications

Table A-1 RF Generator Specifications

Parameter	Specification
Frequency	
Range	1.0 MHz to 6.0 GHz
Resolution	1 Hz
Accuracy	See Table A-27, Frequency Standard I/O on page A-15
Output Level	
Range	DUPLEX: -120 to -30 dBm (CW) ANT/SWR: -100 to 0 dBm (CW) (leveled/unleveled)
Resolution	0.1 dB
Accuracy After normalize	Duplex: +/- 1dB
Bandwidth	
VSG	100 MHz
VSWR	
DUPLEX Port	≤ 1.2 (1 MHz to 6 GHz)
Spectral Purity	
Phase Noise	500 MHz < -120 dBc/Hz @ 10 kHz offset 1 GHz < - 105 dBc/Hz @ 10 kHz offset 6 GHz < - 100 dBc/Hz @ 10 kHz offset
Residual AM	< 0.015% RMS, post detection BW 15 kHz
Residual FM	< 6 Hz RMS, post detection BW 3kHz
Harmonics	< -30 dBc
Non Harmonics	< -60 dBc, output level > -50 dBm

A.2 Modulation Generator Specifications

Table A-2 Modulation Generators

Parameter	Specification
Internal Modulation Specifications	
Sources	2
Types	None AM FM Digital (Arbitrary Waveform)
Waveforms	Sine/Square
Range	
Sine Wave	1 Hz to 100 kHz
Internal AM Specifications	
Range	0.1% to 100%
Resolution	0.10%
Accuracy (internal source)	< ±3% of setting from 10% to 90%
Rate	0 to 100 kHz
AM THD	<1%
Internal FM Specifications	
Range	0 to 150 kHz
Resolution	0.1 Hz
Accuracy (Internal Source)	<±3% of setting (from 1 kHz to 100 kHz deviation, 20 Hz to 15 kHz rate)
Modulation Rate	0 to 100 kHz
FM THD	<1%
Digital (Arb) Specifications	
Sampling Rate	100 MSPS max
Sample Length	16 Bit I and 16 Bit Q
Modes	Continuous or Burst
Memory Depth	1MSP (I/Q) 10 ms @ max sampling rate
Bandwidth	100 MHz
Duplex Operation	for rate < 25 MSPS full duplex operation permitted

Table A-2 Modulation Generators (Continued)

Parameter	Specification
External Modulation Specifications	
Sources	1
Port	Audio In
Frequency range	DC to 100 kHz
Coupling	AC/DC
Level range	2 mV to 20 Vpk
Input Sensitivity	(%, Hz) per Volts

A.3 Audio Frequency (AF) Function Generator Specifications

Table A-3 AF Function Generator

Output	
Impedance	< 4 Ω
Maximum Output Current	20 mA
Frequency	
Range	DC to 100 kHz (± 0.5 dB), 20 Hz to 20 kHz (± 0.1 dB)
Resolution	0.1 Hz
Accuracy	timebase + 0.1 Hz
Level (Sine)	
Range	0 to ± 8 Vpk into 600 Ω , 4 Vpk into 50 Ω
AC Accuracy:	$\pm 2\%$ (> 200 mV, 20 Hz to 20 kHz), $\pm 5\%$ (> 2 mV, 20 Hz to 100 kHz)
Distortion	
THD+N	< 60 dB (20 Hz to 20 kHz)
AF Composite Signals	Sine Square

A.4 RF Receiver Specifications

Table A-4 RF Receiver Specifications

Parameter	Specification
Frequency	
Range	1 MHz to 6 GHz
VSWR	
ANT/SWR	≤ 1.8 (1 MHz to 6 GHz) (for ANT/SWR Port)
DUPLEX	≤ 1.4 (1 MHz to 6 GHz)
Harmonic Response	
2nd Harmonic	< -30 dB
3rd Harmonic	< -50 dB
Spurious Response	
1 MHz to 1 GHz	< -45 dB
1 GHz to 6 GHz	< -55 dB
DANL (Displayed Average Noise Level)	
1000 MHz	<-142 dBm (0 dB attenuation), <-160 dBm (preamp)
Sensitivity (Analog) 10dB SINAD with -100dBm input	
5% BER (Digital)	< -113 dBm with preamp
Min Input Level	-65 dBm (-80 dBm with preamp)
Bandwidth	100 MHz (wideband VSA)
IF Filters	
Analog	5 kHz 8.33 kHz 10 kHz 12.5 kHz 25 kHz 30 kHz 100 kHz 300 kHz
Digital	5 kHz 8.33 kHz 10 kHz 12.5 kHz 25 kHz 30 kHz 100 kHz 300 kHz up to 100 MHz

A.5 Measurement Specifications

A.5.1 RF Power Measurement Specifications

Table A-5 RF Power Meter Specifications

Parameter	Specification
Frequency Range	1 MHz to 6 GHz
Measurement Modes	Live Min Max Average
Measurement Type	Absolute Relative
Measurement Units	Watt dBm
Input VSWR	≤ 1.4 on DUPLEX Port
Level	
Range	0.02 mW to 20 Watts continuous
Resolution	1% of full scale or 1 mW
Accuracy	
DUPLEX Port	±10% After Normalize

A.5.2 RF Counter Specifications

Table A-6 RF Counter Specifications

Parameter	Specification
Frequency	
Range	1 MHz to 6 GHz
Resolution	1 Hz
Accuracy	Same as Frequency Reference
Meter Range	0 to 6000 MHz
Input Level Range	
Duplex Port	-20 to 43 dBm
ANT/SWR Port	-60 to +10 dBm -80 to -20 dBm w/pre-amp and over-the-air)

A.5.3 FM Measurement Specifications

Table A-7 FM Measurement Specifications

Parameter	Specification
Modes	Average Live
Measurement Range	0 to 100 kHz
Resolution	1Hz
Accuracy	± 1.0% from 1.5 to 3 kHz, at 1 kHz rate
AF Frequency Range	10 Hz to 20 kHz

A.5.4 AM Measurement Specifications

Table A-8 AM Measurement Specifications

Parameter	Specification
Modes	Average Live
Measurement Range	0 to 100%
Resolution	1.0%
Accuracy	< 1%
AM Distortion	< 1%, 1 to 5 kHz Deviation (50 Hz to 3 kHz Rate) ≤0.5%, 1.5 to 3 kHz Deviation (1 kHz rate)
AF Frequency Range	20 Hz to 40 kHz
Residual AM	< 0.1%

A.5.5 Distortion Measurement Specifications

Table A-9 Distortion Meter Specifications

Parameter	Specifications
Frequency range	DC to 100 kHz
Level range	2mV to 20 Vpk
Measurement Range	0 to 100%
Resolution	0.1%
Accuracy	< 3% of reading + 0.1% Distortion, 1% to 20%

A.5.6 SINAD Measurement Specifications

Table A-10 SINAD Meter Specifications

Parameter	Specification
Frequency range	DC to 100 kHz
Level range	2mV to 20Vpk
Measurement Range	0 to 63 dB
Resolution	0.1 dB
Accuracy	< 1 dB @ 12 dB SINAD

A.5.7 Signal to Noise (SNR) Measurement Specifications

Table A-11 SNR Meter Specifications

Parameter	Specification
Frequency range	DC to 100 kHz
Level range	2mV to 20 Vpk
Measurement Range	0 to 63 dB
Resolution	0.01 dB
Accuracy	< 1 dB

A.5.8 AF Counter Specifications

Table A-12 AF Counter Specifications

Parameter	Specification
Frequency range	DC to 100 kHz
Level range	2 mV to 20 Vpk
Resolution	0.1 Hz
Accuracy	Timebase + 0.1 Hz

A.6 AF Analyzer Specifications

A.6.1 Frequency Domain Specifications

Table A-13 AF Analyzer Frequency Domain

Parameter	Frequency
Frequency	
Range	DC to 100 kHz
FFT	
Windows	Flat Top
Level	
Range	2 mV to 20 Vpk
Accuracy	
DC	±1% of reading (> 200 mV), ±2 mV (< 200 mV)
AC	±2% of reading (200 mV to 2 V, 20 Hz to 20 kHz), ±5% (200 mV to 20V, 20 Hz to 100 kHz)
Input impedance	100 kΩ
Purity	
THD+Noise	<80 dB (20 Hz to 20 kHz)

A.6.2 Time Domain Specifications

Table A-14 AF Analyzer Time Domain

Parameter	Specification
Display	
Traces	2
Markers	2
Horizontal	
Sweep	20 us to 1 s/div
Bandwidth	100 kHz
Input Range	up to 20 Vp
Coupling	AC DC
Input Impedance	
Impedance	100 kΩ
Accuracy	< 5%
Amplitude	
Scale Modes	Logarithmic
Vertical Scale	1.0 dB 2.0 dB 5.0 dB 10.0 dB 20.0 dB (dB/Div)

A.7 VSWR and DTF Measurement Specifications

Table A-15 VSWR/DTF Specifications)

Parameter	Specification
Modes	VSWR RL (S11) DTF
Frequency Range	1 MHz to 6 GHz
Measurement	
Range	100m for DTF
Accuracy	+/-3ft for DTF, 20% for VSWR
Display	
Graph Types	RL (dB) RL (Linear) VSWR
Domains	Frequency Time Distance

A.8 Audio Filter Specifications

Table A-16 Audio Filters

Parameter	Description
Filter Types	None Bandpass LowPass Highpass Psophometric De-Emphasis
Filter Selections	(per Filter Type)
Lowpass	300 Hz to 40 kHz
Highpass	20Hz to 300Hz
Psophometric	CCITT C-MSG
De-Emphasis	n/a

A.9 RF Analyzer Specifications

Table A-17 RF Analyzer Specifications

Parameter	Specification
Frequency	
Range	1 MHz to 6 GHz
IF Bandwidth	
Range	20MHz or 100 MHz
RBW Bandwidth	
Range	30 kHz to 3 MHz
FFT	
Length	8192
Detector	
Types	Normal
Level	
Accuracy	< 0.8 dB (1 MHz to 1 GHz), < 1.0 dB (1 to 6 GHz) After normalize

A.10 Spectrum Analyzer Specifications

Table A-18 Spectrum Analyzer Specifications

Parameter	Specification
Frequency	
Range	1MHz to 6 GHz
Span	
Modes	Start/Stop Center/Span Zero Span
Range Selection	Freq Selection, full span and zero span
Resolution Bandwidth (RBW)	
Range	100 Hz to 5 MHz in 1,3,5 sequence
Video Bandwidth (VBW)	
Range	100 Hz to 5 MHz in 1,3,5 sequence
Sweep Time	
Range	0.4 ms to 1000 s
Detector	
Types	Normal
Input Signal	
Range	-100 dBm to +43dBm on DUPLEX port
Amplitude Accuracy	+/-1dB after normalize
Input Related Spurious	
	<-60 dBc (excluding ½-IF and other crossovers)
Dynamic Average Noise Level (DANL)	
1000 MHz	<-142 dBm (0 dB attenuation), <-160 dBm (preamp)
Display Features	
Accuracy	Freq Accuracy +50% of RBW
Trace Modes	Live Average Min Max
Markers	
Quantity	2
Function	Marker to Peak, Marker Left/Right to Peak, Center Frequency (CF) to Marker

Table A-18 Spectrum Analyzer Specifications (Continued)

Parameter	Specification
Reference Level	
Range	DUPLEX: -50 to +50 dBm ANT/SWR: -90 to +10 dBm
Resolution	0.1 dB
Units	dBm
Vertical	
Scale	1 2 5 10 dB/division
Range	100dB

A.11 Zero-Span Analyzer Specifications

Table A-19 Zero Span Analyzer Specifications

Parameter	Specification
Sweep Time	
Range	24 us to 200 s

A.12 Connector Specifications

Table A-20 ANT/SWR Connector Specifications

Parameter	Specification
Connector Type	Simplex, Type TNC
Function	RF Input/Output connector
Max Input Power	+27dBm (de-rated below 50 MHz)

Table A-21 DUPLEX Connector Specifications

Parameter	Specification
Connector Type	Duplex, Type N
Function	RF Input/Output connector
Max Input Power	+43 dBm (Continuous)
Input Protection	
Continuous	20 W or until thermal alarm
Duty Cycle	30s ON 2min OFF
Shutdown	alarm sounds (followed by auto shutdown)

Table A-22 Audio In Connector Specifications

Parameter	Specification
Connector Type	Type BNC, Input connector
Function	Audio Input
Max Input Voltage (AC mode)	20 Vpk
Max Input Power	50 mW

Table A-23 Audio Out Connector Specifications

Parameter	Specification
Connector Type	Type BNC, Output connector
Function	Audio Output

Table A-24 Ethernet Connector Specifications

Parameter	Specification
Connector Type	8-pin modular, RJ-45 connector
Function	10/100 Base-T Network Connection

Table A-25 USB Connector Specifications

Parameter	Specification
Connector Type	Type A 3.0, USB Connector
Function	USB 3.0 interface

Table A-26 DC Input Connector Specifications

Parameter	Specification
Connector Type	12 VDC input connector
Function	Charge battery, power device

A.13 Frequency Standard and Timebase Specifications

Table A-27 Frequency Standard I/O

Parameter	Specification
Internal Frequency Standard Output (TCXO)	
Frequency	10 MHz (nominal)
Output Level	2 Vpp (Nominal) into 50 Ω
Temperature Stability (0 to 50° C)	± 0.2 ppm
Aging Rate	0.1ppm/year after 1 month continuous use.
Warm Up Time	Less than 15 min. to ± 0.05 ppm
External Frequency Input	
Frequency	10 MHz
Input Level	1 to 5 Vpp for Sine waves 3.3/5 V TTL for Square waves
Connector	SSMB Jack

A.14 Power Specifications

Table A-28 Power Specification

Parameter	Specification
Battery Operation	>3 hours continuous
Charging Time	5 hours
Power Supply Input	100-240VAC, 1.5A, 50-60 Hz
Power Supply Output	12 VDC, 5.0A max, DC Input Connector

Table A-29 Battery Specifications

Parameter	Specification
Operating Temperature	-10 to 40 °C
Charging Temperature	0 to 45 °C (32 to 113 °F) ≤ 85% RH
Operating Time	~3 hours
Recharging Time	5 hours
Low Charge Status	Battery charge is critically low, <10%, ~18 minutes

A.15 Hardware Specifications

Table A-30 Dimensions and Weight

Parameter	Specification
Height	12.0 in (30.48 cm)
Width	5.7 in (14.48 cm)
Depth	5.0 in (12.70 cm)
Weight	
Without Battery	7.5 lbs (3.4 kg)
With Battery	8.5 lbs (3.9 kg)

A.16 Environmental Specifications

Table A-31 Environmental Specifications

Parameter	Specification
Storage Temperature	-40 to +71 °C without battery (-20 to +60 °C with battery)
Operating Temperature	-10° to +40°C (+14° to +104° F)
	Dripproof MIL-PRF-28800F Class 2
	Splashproof MIL-PRF-28800F Class 2
Relative humidity	95% RHNC (relative humidity, non-condensing)
Altitude	4600 meters (15092 feet)
Vibration	MIL-PRF-28800F Class 2
Shock, Functional	MIL-PRF-28800F Class 2
Bench Handling	MIL-PRF-28800F Class 2
Transit Drop	MIL-PRF-28800F Class 2
Use	Pollution Degree 2
Explosive Atmosphere	No
Reliability	MIL-HDBK-217 or >2500 hours



NOTE

Environmental performance tested in accordance with MIL-STD-28800F, Class 2.

A.17 Safety and Compliance Standards

Table A-32 Miscellaneous Standards

Type	Standard
EMC	EN 61326-1: 2013, Class A
	FCC 47 CFR, Part 15 Subpart B
Product Safety	EN/IEC 61010-1, 3rd Edition (Pollution Degree 2)
	CAN/CSA C22.2 No. 61010-1, 3rd Ed.
EU Standards	EU Regulation 1907/2006
	EU Directive 2011/65/EU
	EU Directive 2014/30/EU
	EU Directive 2014/35/EU
	EU Directive 93/68/EEC

Module and Battery Replacement Procedures

This appendix covers the removal and installation of the CX100 ComXpert RF Module and battery. These instructions contain the following information:

- [Intended Audience](#) B-2
- [Battery Replacement Information](#) B-2
- [Tool Requirements](#) B-2
- [Safety Information](#) B-2
- [Removing the RF Module](#) B-4
- [Installing the RF Module](#) B-6
- [Removing the Battery](#) B-7
- [Installing the Battery](#) B-7

B.1 Intended Audience

These instructions are intended for Qualified Service Personnel only.

B.2 Battery Replacement Information



CAUTION

Only replace the battery with the VIAVI approved replacement part. Contact VIAVI for approved replaced parts.

Battery Part Number: 22071316-002, Battery, Lithium Ion, 7.3V, 13Ah, OneExpert

B.3 Tool Requirements

Table B-1 Battery Replacement Tool Requirements

TOOL	SIZE
Phillips	#2
- OR -	
Flathead screwdriver	1/2"

B.4 Safety Information

B.4.1 ESD Precautions



CAUTION

This device is ESD sensitive and should only be installed, removed and/or serviced by Qualified Service Personnel.



Mise en Garde

Cet appareil est sensible aux DES et ils doivent seulement être installés, enlevés ou entretenus par du personnel de service qualifié.

B.4.2 Battery Handling and Disposal

Unpacking the Battery

The CX100 battery is a Lithium Ion battery that is shipped in special protective packaging.

When removing the packaging, use care not to damage the packaging; the protective packaging can be used for returning the old battery to VIAVI for disposal.



CAUTION

A Lithium Ion battery is used in this equipment. Lithium is a toxic substance. The following warnings concerning Lithium Ion Batteries must be observed:

- Do not crush, incinerate or dispose of in normal waste.
- Do not short circuit or force discharge since this might cause the battery to vent, overheat or explode.

Mise en Garde

Une batterie au lithium-ion est utilisée dans cet équipement. Le lithium est une substance toxique.

Les avertissements suivants concernant les batteries au lithium-ion doivent être respectés:

- Ne pas écraser, incinérer ou jeter avec les déchets normaux.
- Ne pas court-circuiter ni forcer la décharge car cela pourrait entraîner la ventilation, la surchauffe ou l'explosion de la batterie.

WEEE and Battery Statement

This product, and the batteries used to power the product, should not be disposed of as unsorted municipal waste and should be collected separately and disposed of according to your national regulations.

VIAVI has established a take-back process in compliance with the EU Waste Electrical and Electronic Equipment (WEEE) Directive, 2012/19/EU, and the EU Battery Directive, 2006/66/EC.

Information and instructions for returning waste equipment and batteries to VIAVI can be found on the VIAVI website in the WEEE section of the VIAVI Standards and Policies web page at: <https://www.viavisolutions.com/en-us/corporate/legal/policies-standards#sustain>.

B.5 Removing the RF Module

The following procedure provides step by step instructions for removing the RF Application Module from the OneExpert base.



CAUTION


Modules are ESD sensitive and should only be installed, removed and/or serviced by Qualified Service Personnel.

Mise en Garde

Les modules sont sensibles aux DES et ils doivent seulement être installés, enlevés ou entretenus par du personnel de service qualifié.

To Remove the RF Module

1. Power down the device.
2. Disconnect any cables and connectors from the device.
3. Remove 6 screws securing the RF Module to the Base (Figure B-1). The screws are indicated by a battery symbol.



Screw Locations



RF Module Removal

Figure B-1 RF Module Removal Process Diagrams

4. Pull module straight off the back of unit to avoid damaging the PCB assembly.



NOTE
If module sticks to the Base, insert a screw driver where shown and gently pry until module releases (see [Figure B-2](#)).



Figure B-2 Separating RF Module and Base

5. Place the OneExpert Base on an ESD work surface with the display side down.



CAUTION
To avoid damaging hardware, do not place pressure against the Base PCB Assemblies.



Figure B-3 Base Unit - RF Module Removed



NOTE
If the RF Module is being returned to the factory. [See section 8.4, "Shipping Instructions"](#), on [page 8-2](#) for shipping instructions.

B.6 Installing the RF Module

The following procedure provides step by step instructions for installing the RF Application Module on the OneExpert base.



CAUTION


Modules are ESD sensitive and should only be installed, removed and/or serviced by Qualified Service Personnel.

Mise en Garde


Les modules sont sensibles aux DES et ils doivent seulement être installés, enlevés ou entretenus par du personnel de service qualifié.

How to Install the CX100 RF Module

1. Remove the back cover from the Base.
2. Install the RF Module to the Base by aligning the parts and feeding the backplane connector on the Base through the connector opening of the RF Module. Verify the RF Module is flush on the Base before proceeding.



Base Cover Removal



Module and Base Alignment

Figure B-4 CX100 RF Module Installation Diagram

3. Firmly press the RF Module together with the Base.
4. Install 6 screws securing the RF Module to the Base (Figure B-1). Torque screws to 6 in-lbs.



CAUTION

Do not over tighten the screws, doing so may crack the device's cover.

3. Install the RF Module. [See section B.6, “Installing the RF Module”, on page B-6.](#)
4. The replacement battery is shipped in a partially charged state. The battery should be fully charged before using the device. [See section 8.1, “Recharging the Battery”, on page 8-2](#) for battery recharging instructions.

DTF Cable DB - Cable Values

This appendix lists the pre-defined cables that are found in the DTF Cable Database (DB) and each cable's parameters.

Table C-1 RG-115A Cable Values

Parameter	Value
Velocity	0.70
Loss	5.2 dB/100ft

Table C-2 RG-142B Cable Values

Parameter	Value
Velocity	0.70
Loss	8.9 dB/100ft

Table C-3 RG-174 Cable Values

Parameter	Value
Velocity	0.66
Loss	19.1 dB/100ft

Table C-4 RG-213 Cable Values

Parameter	Value
Velocity	0.66
Loss	4.9 dB/100ft

Table C-5 RG-214 Cable Values

Parameter	Value
Velocity	0.66
Loss	4.9 dB/100ft

Table C-6 RG-223 Cable Values

Parameter	Value
Velocity	0.66
Loss	9.2 dB/100ft

Table C-7 RG-400 Cable Values

Parameter	Value
Velocity	0.66
Loss	10.1 dB/100ft

Table C-8 RG-55 Cable Values

Parameter	Value
Velocity	0.66
Loss	9.2 dB/100ft

Table C-9 RG-55A Cable Values

Parameter	Value
Velocity	0.66
Loss	9.2 dB/100ft

Table C-10 RG-55B Cable Values

Parameter	Value
Velocity	0.66
Loss	9.2 dB/100ft

Table C-11 RG-58 Cable Values

Parameter	Value
Velocity	0.66
Loss	10.6 dB/100ft

Table C-12 RG-58A Cable Values

Parameter	Value
Velocity	0.66
Loss	10.6 dB/100ft

Table C-13 RG-58B Cable Values

Parameter	Value
Velocity	0.66
Loss	10.6 dB/100ft

Table C-14 RG-58C Cable Values

Parameter	Value
Velocity	0.66
Loss	10.6 dB/100ft

Table C-15 RG-58foam Cable Values

Parameter	Value
Velocity	0.79
Loss	10.6 dB/100ft

Table C-16 RG-8 Cable Values

Parameter	Value
Velocity	0.66
Loss	4.9 dB/100ft

Table C-17 RG-8A Cable Values

Parameter	Value
Velocity	0.66
Loss	4.9 dB/100ft

Table C-18 RG-8foam Cable Values

Parameter	Value
Velocity	0.80
Loss	4.9 dB/100ft

Table C-19 USER Cable Values

Parameter	Value
Velocity	0.75
Loss	8.7 dB/100ft

Keyboard Mapping

This appendix shows the keyboard mapping of computer function keys to the corresponding CX100 keypad/buttons. Some of the CX100's buttons and keypads have been mapped to function keys that can be found on a computer keyboard.

[Table D-1](#) shows the keyboard mapping of computer function keys to the corresponding CX100 keypad/buttons.

Table D-1 Computer to CX100 Keyboard Mapping

Computer Keyboard	CX100 Keypad/Button
F1 through F4	Correspond to the device system keys
F5	Home
F6	Utility Tray
Escape	Cancel
Enter	OK
Up, Down, Left, Right Arrows	Used to navigate menu contents.

This page intentionally left blank.



Glossary

- A**
- A2D** — Analog to Digital
 - ACLR** — Adjacent Channel Leakage Power Ratio
 - AM** — Amplitude Modulation
 - AF** — Audio Frequency
 - ANT** — Antenna
- B-C**
- BER** — Bit Error Rate
 - BPF** — Band Pass Filter
 - bps** — bits per second
 - BW** — Bandwidth
 - CW** — Carrier Waveform
- D**
- D2A** — Digital to Analog
 - DST** — Daylight Savings Time
 - DTF** — Distance to Fault
 - DUT** — Device Under Test

E - G

- Ethernet TE** — Ethernet Throughput Efficiency
- EVM** — Error Vector Magnitude
- Ext** — External
- FIR** — Finite Impulse Response
- FM** — Frequency Modulation
- GEN** — Generator
- GHZ** — Gigahertz
- GPS** — Global Positioning Satellite
- GUI/UI** — Graphic User Interface/User Interface

H - K

- HZ** — Hertz
- I/O** — Input/Output
- kbps** — kilo bits per second
- kHz** — kilohertz

L

- LAN** — Local Area Network
- LCD** — Liquid Crystal Display
- LED** — Light Emitting Diode
- LIT** — Line Item Test
- LPF** — Low Pass Filter
- LSB** — Lower Sideband
- LRU** — Line Replaceable Unit

M**mA** — milliampere**MHz** — Megahertz**mHz** — millihertz**Mod** — Modulation**mW** — milliwatt**N - R****NRZ** — Non-return to Zero**NTP** — Network Time Protocol**OBW** — Occupied Bandwidth**UOM** — unit of measurement**PM** — Phase Modulation**RA/RMA** — Return Authorization/Return Material Authorization**RBW** — Resolution Bandwidth**Ref** — Reference**RMS** — Root Mean Square**Rx** — Receive**S - T****SCA** — Software Communications Architecture**Spec** — Specifications**SSB** — Single Sideband**SWR** — Standing Wave Ratio**TAC** — Technical Assistance Center for customer support**TPS** — Test Program Set**T/R** — Transmit/Receive for (Duplex Connector)**Tx** — Transmit

U - Z

USB — Universal Serial Bus

USB — Upper Sideband

UUT — Unit Under Test

Vrms — Volts Root Mean Square

VSWR — Voltage Standing Wave Ratio

W — Watt



CX100 ComXpert Handheld Radio Test Set Operation Manual

22144015 Rev 002

Part of CD 22144014

August 2023

English

VIAVI Solutions

North America: 1.844.GO VIAVI / 1.844.468.4284

Latin America +52 55 5543 6644

EMEA +49 7121 862273

APAC +1 512 201 6534

All Other Regions: viavisolutions.com/contacts