


# Avionics

## SI-1404 MK12/Mode S IFF Accessory Unit

**AEROFLEX**  
A passion for performance.



SI-1404 provides a comprehensive 3rd Line/Depot Level test solution for next generation MK12/Mode S IFF transponders

- Comprehensive Mode S (level 4) and Mode 4 interrogator simulation
- Accurate measurement of transponder reply pulse parameters
- Configuration memory stores 5 complete SI-1404 configurations
- Extended squitter DF17 capability
- Mode 4 crypto simulation plus external crypto interface
- Built-in self test
- LCD display with adjustable back-light
- IEEE-488.2 GPIB & RS-232 interface
- Two-year limited warranty

*Aeroflex is a leader in the design, manufacture and marketing of Avionics test systems.*

### SI-1404

The SI-1404 is a Depot Level/3rd Line test accessory, used in conjunction with the ATC-1400A Transponder/ DME test set, for testing IFF transponders in a maintenance or production environment.

The SI-1404/ATC-1400A may also be utilized by OEMs to perform most of the MOP (Minimum Operational Performance) tests defined in RTCA/DO-181A, required in the Mode S transponder certification process.

The SI-1404 and ATC-1400A form a comprehensive SSR ground station simulator capable of parametric and protocol testing MK10A (Mode 1, 2, 3/A, C), MK12 (Mode 1, 2, 3/A, 4, C) and MK12/Mode S transponders.

### OPERATION

#### Display

Operation of the SI-1404 is via a menu system displayed on a 40 column x 4 row alphanumeric LCD display. The display has an adjustable illumination backlight, which provides viewable screens under all ambient lighting conditions.

#### Keypad

Menu selection and data entry is provided via a 4 x 5 main key pad, four directional cursor keys and a slew knob. Dedicated keys are provided for commonly used functions.

#### SI-1404/ATC-1400A Interface

The SI-1404 is interfaced to the ATC-1400A via two rear panel bus cables and three RF coaxial cables.

The SI-1404 provides the ATC-1400A with Mode S DPSK modulation and monitors replies on Ant A (ATC-1400A).

The ATC-1400A provides UUT power and frequency measurement and has a fully synthesized RF generator for performing receiver bandwidth and selectivity tests.

For the very latest specifications visit [www.aeroflex.com](http://www.aeroflex.com)

ATC mode selection and SLS testing is provided via the ATC-1400A controls.

### Remote Control

The SI-1404 may be controlled via the ATC-1400A IEEE-488 GPIB interface as an integrated system, or via a separate high speed GPIB interface available on the SI-1404 rear panel.

A RS-232 interface is provided for a screen dump to an external printer.

### Test Menus and Screens

Testing under manual control is via a series of menus. Menu types are 'C' (Control), 'S' (Sequence) and 'T' (Test). C10 menus relate to control and monitoring of the 'A' antenna RF I/O port (ATC-1400A) and C20 menus relate to the control and monitoring of the 'B' antenna RF I/O port (SI-1404).

The C10 and C20 menus contain a number of 'f' or function screens. The function screens are structured for manual testing.

Control fields are provided for Ant A RF level vernier and Ant A to Ant B diversity time delay.

Measured parameters displayed are, percent reply for Ant A (ATC and Mode S), Ant B (all replies), reply delay and Mode S squitter period.

### Main C Menu

Access to all menus and screens is provided via the main 'C' control menu.

### ATC Screen

Displays Mode 1,2,3/A code or Mode C altitude and provides  $P_3$  control field.

### Mode S Sequence Screen

Provides selection of  $P_6$  control, pulse width and deviation,  $P_2$  control, SPR control and deviation. Mode S formats are configured in the sequence menu.

### ACS (All-Call Short) Screen

Provides selection of  $P_4$  control, pulse width and deviation. Displays DF11 all-call reply and transponders discrete address.

### ACL (All-Call Long) Screen

### Interlace Screen

Provides selection of ATC to Mode S interlace ratio.

### Double Interrogation Screen

Provides selection for 1st and 2nd interrogation modes. Interrogation spacing control is provided by the ATC-1400A.

### Burst Screen

Select desired burst format ATC, ASC, ACL or SEQ. Select burst number 1 to 9999. Press burst key to send burst.

### ATC Monitor Screen

Displays the same parameters as the f01 ATC screen plus  $F_1/F_2$  framing pulse spacing and pulse width, reply jitter and emergency replies.

### Mode 4 Screen

Displays TDV jitter (from external crypto), triplet reply delay and jitter. Provides selection of Mode 4  $P_2$ ,  $P_3$ ,  $P_4$  control and  $P_4$  deviation.

### Mode 4 Monitor Screen

Displays  $P_4$  to enable trigger spacing, trigger width, Triplet  $T_1$  to  $T_2$  spacing,  $T_1$  to  $T_3$  spacing and  $T_1$ ,  $T_2$ ,  $T_3$  widths.

## S Menu

Allows the input of Uplink Formats in a programmable sequence of up to 1000 items. Downlink Formats are read-only.

### Uplink Format

The following Mode S 'D' formats are provided with predefined data fields: UF00, UF04, UF05, UF11, UF16, UF20, UF21 and UF24.

Formats 'S' & 'L' allow the user to define 56-bit and 112-bit words consisting of 5 bits octal/hex formatted data, 27 bits (S) and 83 bits (L) of octal/hex formatted data and 24 bits of octal/hex address data.

### Downlink Format

The following Mode S 'D' formats are provided with predefined data fields: DF00, DF04, DF05, DF11, DF16, DF20, DF21 and DF24.

Formats 'S' & 'L' are three fields of generic data consisting of 5 bits octal/hex formatted data, 27 bits (S) and 83 bits (L) of octal/hex formatted data and 24 bits of octal/hex address data.

### Percent Reply Screen

Displays Ant A and Ant B, statistical percent replies for ATC, Mode S Mode 4 groups, plus Bad or No Replies.

### Reply Delay Screen

Displays Min and Max reply delays for ATC, Mode S and Mode 4 replies.

### Set up Mode 4 Menu

Provides selection of Mode 4 disparity pulse control, sync source, delay, deviation, and pulse width. Also provides selection of Mode 4 reply type, sync source, delay, deviation, and triplet pulse width.

### Set up PPMG Menu

Provides Peak Power Measurement Gate pulse selection for ATC, Mode S, DELM and Mode 4 replies.

### Squitter Screen 1

Displays squitter address in hex/octal, tail number and country (if algorithm available), squitter type DF11 (all-call), DF17 (extended squitter).

### Squitter Screen 2

Displays DF11 and selected DF17 (A, I, O, P, S, or T), content, Ant and squitter period.

### Set up Screen

Provides selection of S menu data type in octal or hex. A factory set of default formats may also be selected plus the discrete address utilized in the S menus can be selected as User defined or Xpdr (obtained from DF11/DF17 squitters).

### MISC - MTL Screen

Displays pre-programmed MTL test

---

## GENERAL

---

### Calibration Interval

1 year

### AC Supply

100 to 120 VAC, 220 to 240 VAC, 50 Hz to 60 Hz,  $\leq \pm 10\%$  of the nominal voltage

48 W maximum (180 W maximum with ATC-1400A)

### AC Output

Line output, fused at 3 amps and switched

## ENVIRONMENTAL

### Temperature

5° to 40°C

### Relative Humidity

$\leq 80\%$  for temperature up to 31°C decreasing linearly to 50% at 40°C (Non-condensing)

### Altitude

$\leq 4000$  m (13,124 ft.)

### Electromagnetic Compatibility

Complies with the limits in the following standards:

EN55011 Class B

EN50082-1

### Safety

Complies with EN61010-1:1993 for class 1 portable equipment and is for use in a pollution degree 2 environment. The instrument is designed to operate from an installation category 1 or 2 supply.

### Dimensions

425 mm wide x 89 mm high x 467 mm deep

16.8 in. wide x 3.5 in. high x 18.4 in. deep

### Weight

6.75 kg (15 lbs.)

---

## VERSIONS AND ACCESSORIES

---

When ordering please quote the full ordering number information.

### Ordering Numbers

1404-110

1404-220

### Versions

SI-1404 Modes S & 4 Transponder with MLD, 110 VAC Certificate of Calibration

SI-1404, 220 VAC Operation

---

All Aeroflex Avionics products delivered with Factory Certificate Of Calibration

### EXPORT CONTROL:

This product is controlled for export under the International Traffic in Arms Regulations (ITAR). A license from the U.S. Department of State is required prior to the export of this product from the United States.

### EXPORT WARNING:

Aeroflex's military products are controlled for export under the International Traffic in Arms Regulations (ITAR) and may not be sold or proposed or offered for sale to certain countries including: Belarus, Burma, China, Cuba, Haiti, Iran, Liberia, Libya, North Korea, Somalia, Syria, Sudan, and Vietnam. See ITAR 126.1 for complete information.

**FINLAND**

Tel: [+358] (9) 2709 5541  
Fax: [+358] (9) 804 2441

**FRANCE**

Tel: [+33] 1 60 79 96 00  
Fax: [+33] 1 60 77 69 22

**GERMANY**

Tel: [+49] 8131 2926-0  
Fax: [+49] 8131 2926-130

**INDIA**

Tel: [+91] 80 5115 4501  
Fax: [+91] 80 5115 4502

**KOREA**

Tel: [+82] (2) 3424 2719  
Fax: [+82] (2) 3424 8620

**SCANDINAVIA**

Tel: [+45] 9614 0045  
Fax: [+45] 9614 0047

**SPAIN**

Tel: [+34] (91) 640 11 34  
Fax: [+34] (91) 640 06 40

**UK Burnham**

Tel: [+44] (0) 1628 604455  
Fax: [+44] (0) 1628 662017

**UK Cambridge**

Tel: [+44] (0) 1763 262277  
Fax: [+44] (0) 1763 285353

**UK Stevenage**

Tel: [+44] (0) 1438 742200  
Fax: [+44] (0) 1438 727601  
Freephone: 0800 282388

**USA**

Tel: [+1] (316) 522 4981  
Fax: [+1] (316) 522 1360  
Toll Free: 800 835 2352



As we are always seeking to improve our products, the information in this document gives only a general indication of the product capacity, performance and suitability, none of which shall form part of any contract. We reserve the right to make design changes without notice. All trademarks are acknowledged. Parent company Aeroflex, Inc. ©Aeroflex 2006.

[www.aeroflex.com](http://www.aeroflex.com)  
[info-test@aeroflex.com](mailto:info-test@aeroflex.com)



Our passion for performance is defined by three attributes represented by these three icons: solution-minded, performance-driven and customer-focused.

Part No. 46891/042, Issue 4, 04/05